







# Hisense



## CORDLESS VACUUM CLEANER Hi-Style II

### INSTRUCTION MANUAL

|                     |                  |                        |               |                 |               |
|---------------------|------------------|------------------------|---------------|-----------------|---------------|
| Sesalnik<br>za prah | Usisavač prašine | Usisivač za<br>prašinu | Правосмукалка | Vacuum cleaner  | Staubsauger   |
| Aspirator           | Vysávač          | Porszívó               | Odkurzac      | Vysavač         | Прахосмукачка |
| Пилосос             | Пылесос          | Шаңсорғыш              | Pölynimuri    | Støvsuger       | Støvsuger     |
| Dammsugare          | Pastrues vakumi  | Aspirapolvere          | Aspiradora    | Aspirador de pó | Aspirateur    |





|              |                   |                          |              |                     |                   |              |              |              |              |              |              |
|--------------|-------------------|--------------------------|--------------|---------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|
| SI<br>- 3 -  | HR / BIH<br>- 6 - | SRB / BIH / MNE<br>- 9 - | MK<br>- 12 - | <b>GB</b><br>- 15 - | DE / AT<br>- 18 - | RO<br>- 21 - | SK<br>- 24 - | HU<br>- 27 - | PL<br>- 30 - | CZ<br>- 33 - | BG<br>- 36 - |
| UA<br>- 39 - | RU<br>- 42 -      | KZ<br>- 45 -             | FI<br>- 48 - | DK<br>- 51 -        | NO<br>- 54 -      | SE<br>- 57 - | SQ<br>- 60 - | IT<br>- 63 - | ES<br>- 66 - | PT<br>- 69 - | FR<br>- 72 - |

1. Handle

2. Electrical brush

3. Handy vacuum cleaner

4. Extra attachments

5. Adapter with power cord

## GENERAL PRECAUTIONS

**When using the vacuum cleaner always observe the following basic safety precautions:** Carefully read this instruction manual and only use the appliance in accordance with the instructions herein. // Before using the appliance for the first time, remove all protective film or plastics. // Never leave the appliance unattended during use. // Before using the appliance, carefully assemble all of its parts. // Only use the appliance indoors and in dry areas. // Only use the appliance with the parts recommended by the manufacturer. // Do not use the appliance if it has been dropped, if it is damaged, if it has been kept outdoors, or if it has been dropped or immersed in a liquid. // Regular cleaning can extend the appliance's useful life. // Make sure your hair, loose parts of your garments, fingers or other parts of the body do not come into contact with the vents or moving parts of the appliance. // The appliance complies with all required standards regarding electricity, and radio interference regulations. // The appliance is not intended to be used by children and persons with impaired physical or mental abilities. This appliance may be used by children aged 8 years and more, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they are supervised during the use of the appliance or if they have been provided relevant instructions regarding the use of the appliance in a safe way, and they understand the hazards involved. Keep children under supervision while they are using the appliance and make sure they do not play with it. // Children should not perform any cleaning or maintenance tasks on the appliance, unless they are older than 8 years, and they do so under supervision. // Switch off the appliance after use.

## DANGER

Do not immerse the main unit/appliance housing or the charging base in water or any other liquid and do not rinse them under running water.

## SPECIAL WARNINGS

Before connecting the appliance or the charging base with the power cord to the power mains, make sure the indicated voltage matches the voltage of the power mains in your home. // Do not use a damaged vacuum cleaner or a damaged charging base (or adapter – depending on your vacuum cleaner model). // If the charging base (or adapter) is damaged, replace it only with an original spare part in order to avoid danger. // A transformer is integrated into the adapter. Removal and replacement of adapter with another one are not allowed as this may lead to a dangerous situation. // Only charge the vacuum cleaner with the supplied adapter and charging base. The adapter may heat up during charging. This is a normal occurrence. (Depending on your model, if it has an adapter.) // Switch off the appliance during charging. // Never use the vacuum cleaner without filters or filtering unit in place. // The exhaust vents may not be blocked during vacuum cleaning. // Only use the appliance for household purposes and indoors. // Keep the suction vents clean and free in order to ensure optimum and unimpeded suction power of the appliance. It is highly recommended to regularly clean the open parts of the suction hose, and to remove dust, hair, or anything else that may block the airflow. // Before cleaning the support or the charging base, unplug it from the power socket. // Never use the vacuum cleaner to clean up embers or filings, cigarette butts, matches, liquids (e.g. water, carpet cleaning foam), or sharp or pointed objects (broken glass etc.). // Keep the suction tube or the open part of the appliance away from your face and body. // Never use the appliance to vacuum construction material (such as fine sand, lime, cement powder, toner dust etc.). This can cause damage to the appliance. // Do not expose the battery to fire or to temperatures above 60°C.

This appliance is marked according to the European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE). This guideline is the frame of a European-wide validity of return and recycling on Waste Electrical and Electronic Equipment.



## PROBLEMS AND SOLUTION

| Problem                             | Possible reason                                                                                                                                        | Solution                                                                                                |
|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| Not working.                        | The battery is dead.<br>The handy VC is not assembled correctly.                                                                                       | Charge.<br>Assemble the handy VC correctly.                                                             |
| Suction power has decreased.        | The dust cup is full.<br>Block in filter.<br>Block in the air inlet tunnel or on the roller of electrical brush.                                       | Pour out the dust.<br>Clean or change filter.<br>Clean the electrical brush.                            |
| The VC is not charging.             | The charger is not connected on socket. The connector of charger is not connected to the hole of base body. The handy VC is not assembled to the body. | Connect the charger on socket. Connect the charger with base body of VC. Assemble the handy VC on body. |
| Use very short time after charging. | Not enough charging time.<br>The battery is aging.                                                                                                     | Charge according to instruction. Change the battery.                                                    |

## ENVIRONMENT

Do not throw away the appliance with the normal household waste at the end of its life. Hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

## GUARANTEE & SERVICE

If you need information or if you have a problem, please contact the Hisense Customer Care Centre in your country (the phone number is in the worldwide guarantee leaflet). If there is no Customer Care Centre in your country, go to your local Hisense dealer or contact the Service department of Hisense domestic appliances.

### NOTE:

The warranty on the battery of vacuum cleaner is 1 year.

**For personal use only!**

# Hisense



***Hisense***