

HOW TO ADD SEA FOAM MOTOR TREATMENT TO CRANKCASE OIL



BENEFITS

When added to gasoline and diesel crankcase oil, Sea Foam Motor Treatment works to help:

- Safely liquefy petroleum residues that restrict flow and lubrication.
- Clean oil control rings, vvt solenoids and actuators.
- Dissolve and clean deposits throughout the crankcase including diesel soot residues.
- Clean and quiet noisy lifters and timing chain tensioners and reduce diesel injector stiction.



INSTRUCTIONS

- First determine the engine's crankcase oil capacity. Most autos and light trucks have 5 or 6 quart systems. Check in your vehicle's owner's manual for the size of your crankcase. One 16 ounce can of Sea Foam Motor Treatment treats up to 16 quarts of oil.

Add one ounce of Sea Foam Motor Treatment for every quart of oil in the crankcase. When ready,

- remove oil filler cap and pour the recommended amount of Sea Foam directly into the engine crankcase. Do not exceed one treatment per oil change interval.

NOTE:

Though Sea Foam can be added at any time between oil change intervals, we recommend adding Sea Foam to an oil crankcase 100 to 300 drive miles before changing oil and filter.

CONCLUSION

Sea Foam Motor Treatment can be used in every type of gasoline or diesel engine. When added to an engine's oil crankcase, Sea Foam Motor Treatment works to clean and liquefy heavier oil deposits, so the residues will drain away when the oil is changed. Sea Foam cleans internal engine parts, prevents sludge and other harmful oil formations.

FOR MORE HELPFUL RESOURCES VISIT: SeaFoamWorks.com

