

Operators Manual

ReadStar TT Torque Tester

Manual 1298-01 Issue 1

Crane Electronics Ltd



Notice

ALL RIGHTS RESERVED. Reproduction of any part of this manual in any form whatsoever, without the prior permission in writing from Crane Electronics Ltd is forbidden.

Copyright © June 2020 by Crane Electronics Ltd.

CONTENTS

Contents	2
CE Marking & Compliance	3
Product Disposal & About this Manual	4
Packing list	5
Spares & Accessories	5
Features & Dimensions	6
Specifications	7
Hardware	8
Technical Features	8
Icons	9
Start Up	9
Fixed Icons	11
Input	12
Powering your ReadStar TT	12
Measurement Screen	13
Deletion	14
Settings	15
AutoPrint Settings	16
Readings List	17
Statistics	18

CE MARKING

Manufacturer: Crane Electronics Ltd
Address: 3 Watling Drive
Sketchley Meadows
Hinckley
Leicestershire
LE10 3EY
Tel: +44 (0)1455 25 14 88

Declares that the ReadStar TT ranges have been assessed and comply with the requirements of the relevant CE Directives.



Changes or modifications to the ReadStar TT not expressly approved by Crane Electronics Ltd could void the user's authority to operate the equipment.

COMPLIANCE

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installations. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

PRODUCT DISPOSAL

Applicable in the EU and other European Countries with separate collection systems



The symbol shown here and, on the product, means that the product is classed as Electrical or Electronics Equipment and should not be disposed with normal commercial waste at the end of its working life.

The Waste of Electrical and Electronics Equipment (WEEE) Directive (2012/19/EU) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increasing landfill.

To enable this product to be disposed of properly i.e. cradle to grave, Crane Electronics is willing to accept the return of your product (at your cost) for recycling or alternatively, for more detailed information about recycling of this product please contact your local authority or the Distributor / Company where you have purchased the product.

Battery disposal to take place in line with the AMENDED BATTERIES DIRECTIVE 2013/56/EU. Batteries must **not** go to landfill. Check with local legislation.

Crane Electronics declares that this product does not contain any of the 191 Substances of Very High Concern (SVHC's) identified in the REACH Regulation in used articles make-up.

In Countries outside the EU:

If you wish to discard this product, please contact your local authorities and ask for the correct way of disposal.

Signed for & on behalf of **Crane Electronics Ltd.**

Name: **B. M. Etter**
Title: **Safety & Environmental Advisor**

Signature of Issuer: *B. M. Etter*

ABOUT THIS MANUAL

This manual covers the ReadStar TT torque testers.

Actual screen shots represented in this manual may differ slightly from those on the actual torque tester unit, depending on the version.

PACKING LIST

The following Items are supplied with the ReadStar TT dependent on model specification purchased.

- 1 x ReadStar TT (with standard rundown adapter)
- 1 x Calibration Certificate (12 months)
- 1 x Quick Start Guide (with QR code link to Operator's Manual)
- 2 x Type 'C' Cell non-rechargeable batteries

All contents are supplied packaged in a box.

Please ensure all items are present and notify Crane Electronics Ltd immediately of any shortages.



SPARES AND ACCESSORIES (with Product Code)

5V PSU Power Adapter	RSXXA-0000-CRPXXX
Standard Rundown Adapter	TAXXA-00NN-CRRAXX*
Premium Joint Kit Adapter	TAXXA-00NN-CRJKXX*
Standard Rundown Adapter Spares	TAXXS-00NN-CRRASX*
Premium Joint Kit Spares	TAXXS-00NN-CRJKSX*

*Where 'NN' appears in the product code, replace with the Nm size required e.g. 01 = 1Nm, 04 = 4Nm, 12 = 12Nm and 30 = 30Nm.

FEATURES AND DIMENSIONS – READSTAR TT



SPECIFICATIONS

Measurement Modes:

Track – Real time torque

Peak – Capture of the highest torque

Pulse – Special measurement algorithm for use with impulse tools, incorporating pulse count

Click – Capture of peak torque before click mechanism operates to limit

Measurement Units:

Torque - Nm, lbft, lbin, Ncm, kgcm, kgm, ozin

Physical Measurements:

Auto Bi-directional torque; pulse count; cycle time duration.

Data Storage:

999 readings in storage mode.

Basic Statistics:

Count, range, mean, min, max, standard deviation.

AutoPrint / Data Output:

Easy selectable output to AutoPrint of all results. Interface to simple PC package that outputs the print data to an Excel spreadsheet.

Cycle Status Indication:

LED HI/OK/LO torque status. User definable limits.

Operating Languages:

English, Czech, French, German, Italian, Hungarian, Spanish, Swedish, Polish, Turkish.

HARDWARE

Construction:

High strength injection moulding. Steel base with mounting bars.

Display:

White OLED screen - 79mm x 21mm

Keypad:

Easy clean keypad. 11 keys including 5 function keys, 5 directional keys and on/off key.

Power:

Universal 5V PSU or USB.

Power Management:

User selectable auto power-off: User definable between 0-200 minutes.

Batteries:

Compatible with both Alkaline and NiMH "C" cells (LR14)

Input/output ports:

Micro USB (2.0) for power and export.

5V DC power port for use with mains power DC PSU.

TECHNICAL FEATURES

Zero Stability:

$<\pm 0.02\%$ FSD/ °C.

Static Accuracy:

$\pm 0.25\%$ FSD.

Operating Environment:

Temperature: -20 to +50 °C.

Humidity 10-75% non-condensing.

Ingress protection rating: IP45.

Torque Measurement

Display up to 5 significant figures. Sample every 20 micro seconds.

Warranty:

12 months parts and labour against faulty workmanship or materials.

ICONS – READSTAR TT

Fixed soft-key Icons:



Measurement
Modes



Delete



Readings



Statistics



Settings

On-screen Icons - Measurement Modes:



Peak



Click



Track



Pulse

START UP

Turning on your ReadStar:

Turn on the ReadStar by pressing the On/Off button situated below the arrowed keypad.



The first screen you will see is as below.



The screen will then change to:



It confirms the serial number of the ReadStar TT you have and its calibration due date. TM is the latest software version of the torque module and KB represents the latest version of the keyboard.

The unit will then enter measure mode, showing the last measurement mode used is automatically displayed.



The screen icons below denote the following:



Measurement reading



Primary measurement mode



Battery status



Number of readings



Measurement unit



Duration in seconds



Direction of rotation/torque



DC power

FIXED ICONS



Measurement Mode - Default mode will be peak. A second press will take you to track, a third press will take you to click, and a fourth press will take you to pulse (shown as icon in secondary parameter position).



Delete - You can delete the last reading or all readings. One press will delete the last reading; two presses will delete all readings.



Reading List – This will show the readings currently held on the torque tester. Using the up and down arrow keys you can scroll through the readings.



Statistics – This will display the following stats from the current readings: count, range, mean, min, max, and standard deviation (sigma).



Settings – Allows you to toggle through various screen settings. See separate screen section of this manual below.

INPUTS



The ReadStar TT has connectivity using the following:

- 1) Micro USB
- 2) 5V DC power supply

POWERING YOUR READSTAR TT



There are three ways in which the unit can be powered:

- 1) Connect Micro USB on the ReadStar TT to USB on a laptop, PC or USB charger.
- 2) Connect the 5V DC port with a DC power supply.
- 3) Insert 2 x Type 'C' Cell (LR14) NiMH or Alkaline batteries.

Please note: Rechargeable batteries cannot be charged on board the ReadStar TT.

THE MEASUREMENT SCREEN



Measurement Screen:



1 Measurement reading.

2 Primary measurement mode.

3 Battery status.

4 Reading count.

5 Unit of measurement.

6 Duration in seconds.

7 Measurement direction.

Pressing the measurement button will take you through the measurement modes.




Screen 2 on the second press Track mode.



Screen 3 on the third press Click mode with peak value displayed.




Screen 4 on the fourth press pulse mode with peak value and cycle duration displayed




A second parameter for pulse count can also be enabled.


DELETION



Readings are taken in order, so the first is 1 the last reading would be 999. One press of the delete icon will allow you to delete the **last** reading only. Press the green OK button to do so.



A second press of the delete button will allow you to delete all readings in the list in one go. Just press the green OK button.



The other time you are forced to delete all readings is when you change the measurement mode mid-way through readings you have already done.



In addition, readings are also deleted when the torque limit specifications are altered.

SETTINGS



Settings can be accessed by pressing the Settings Icon and using the up and down arrow keys and changing the formats by using the right and left arrow keys:

TQ = Torque CLK = Click PUL = Pulse
UL = Upper Spec Limit NOM = Target LL = Lower Spec Limit THR = Threshold


Pressing the fixed Settings key. The first screen you will come to is the torque settings.

It will show CLK THR (Click Threshold) for Click and Pulse for Pulse.

Using the up and down arrows on the keypad you can manoeuvre between the required lines. When the arrow is on the line press the green button. You can then use the Up and Down arrows to change the numbers and the left and right arrows to move left and right. Pressing the green button will save and take you back to the main setting screen. Note. Pressing Settings icon cancels edit.

The units of measurement are the display units (show on screen after).


e.g. Peak Mode



e.g. Threshold



Pushing the up or down arrow key will take you to another screen where you can change the Direction, Frequency, Cycle End Time, 2nd Parameters and Measurement Units. Use the up and down arrows to navigate and the left and right arrows to change.




Direction:  Auto
Clockwise
Anti-clockwise

Frequency Response (Hz): 75, 151, 256, 307, 384, 542, 768, 921, 1024, 1536, 2304, 3072, 4608

Cycle End Time (s): 0.20, 0.5, 1.0, 2.0, 5.0, 10, 20


2nd Param: 0 = Off, 1 = On

Units: Nm, lbft, lbin, Ncm, kgcm, kgm, + others (display valid units for span)



A second press of the settings icon will take you to Setup System Settings.

- Power Off: Set the duration of the length of time before the torque tester turns off. 0 – 200 (0 = Never turn off)
- Date: Set the correct date.
- Time: Set the time.
- Date format: Change how you want the date to be formatted. DD/MM/YYYY, MM/DD/YYYY, YY/MM/DD
- Time format: Set how you want the time displayed. HH:MM:SS, HH:MM




A press of the arrow keys up or down will take you to the above screen where you can make additional settings changes.

- Number format: Period or Comma for decimal place.
- Result FIFO: First in first out can be set which way you want the readings to be deleted. If off (0) then it stops taking readings when it reaches 999. If on (1) then when 999 readings are reached, it starts overwriting the earliest readings, meaning it holds the last 999 readings only.

Language: English, Swedish, Czech, Spanish, Italian, Portuguese, German, Turkish, Polish, Hungarian, French

AUTOPRINT SETTINGS



A third press of the settings icon will take you to the AutoPrint settings.

The AutoPrint settings are as follows:

- Format: Show the AutoPrint format. Display as [xxxx] 1 = Show, 0 = Not Shown
- Date: Show the date of the reading.
- Time: Show the time of the reading.
- Status: HI, LO, OK
- Direction: Right (Clockwise), Left (Anti-clockwise)
- Duration: Reading duration in seconds.
- Spec Limits: USL, Target and LSL.
- Secondary: Show if there are any second parameters.
- Serial No.: Show the serial number of the tool.

Example:

```
16:08:30.449 << [B17F] 096829 17/10/18 16:06:10 1.811Nm LO 0.6 OK Right 1.279 10.00 2.500 3000.0 0.0 Peak
16:08:30.453 << [B17F] 096829 17/10/18 16:06:14 4.285Nm OK 2.9 OK Right 1.848 10.00 2.500 3000.0 0.0 Peak
16:08:30.458 << [B17F] 096829 17/10/18 16:06:18 15.11Nm HI 1.8 OK Right 1.761 10.00 2.500 3000.0 0.0 Peak
16:08:30.462 << [B17F] 096829 17/10/18 16:06:32 2.605Nm OK 7.6 LO Right 4.537 10.00 2.500 3000.0 0.0 Peak
16:08:30.469 << [B17F] 096829 17/10/18 16:06:36 2.443Nm LO 5.4 LO Right 2.094 10.00 2.500 3000.0 0.0 Peak
16:08:30.473 << [B17F] 096829 17/10/18 16:06:42 10.58Nm HI 85.5 LO Right 3.144 10.00 2.500 3000.0 0.0 Peak
```

AutoPrint takes place when each reading cycle end is complete. AutoPrint does not work in Track mode as there is no cycle end and no reading stored.

READINGS LIST



One press of the Readings icon will take you to the first reading screen where you can see all of your current readings. You can navigate through the results by using the up and down arrow keys.

```
001/002 0.649Nm      ↓ ↻
0.06s 11:17:51 07/02/2020
002/002 0.672Nm      ↓ ↻
0.13s 11:17:58 07/02/2020
—⚡
```


A second press will allow you to export your readings to a PC. Press the green button to accept. All readings are exported in AutoPrint format.

```
Export Readings?
—⚡
```


STATISTICS



Pressing the fixed Statistics icon takes you to two screens which display simple statistics relating to the current collected readings data.



The first screen displays X = Mean average n = Sample count and σ = Sigma (Standard deviation).



Pressing the up and down arrow keys takes you to the second screen which displays the current minimum and maximum readings as well as the range between them.