



Installation Instructions

Suits 35mm to 45mm Door Thickness

GAINSBOROUGH
freestyle



External View




Exploded View

Step 1:

Prepare the Door

Fold template where indicated.

- Position template on door edge at desired lock / latch height.
- Firmly hold template and mark latch height and hole positions at desired backset.
- Reverse the template fold and mark the other side of the door.
- Measure the door thickness and mark the centre on the "latch height" marking.
- Drill Ø25mm latch hole. Note: it is important to drill this hole squarely.
- Drill pilot holes. (suggested size Ø3 mm) Then enlarge holes following the installation template instructions.
- Drill Ø10 mm and Ø54 mm holes from both sides of the door.
- Mark and chisel latch faceplate to a recess of 4.0 mm. Use latch as a template.




(If installing the Door Position Sensor, refer to Step 1b on page 3)

Step 2:

Install the Latch

Install latch with the tapered (bevelled) side of the bolt facing towards the door jamb when the door is open.




(If installing the Door Position Sensor, refer to Step 2b on page 3)

Step 3:

Prepare the Internal Furniture

Using the supplied battery cover release tool, push through the hole to release the battery cover to expose the mounting screw holes.


Battery cover release tool



Step 4:

Handing of the Internal Lever

- Rehand the lever (if necessary), by pushing the retaining plate inside the furniture as shown. (Push through the hole on the same side as the lever.)
- Then swing the lever up and over to the other direction.



NOTES:

- Carefully follow these instructions when installing.
- Do not overtighten screws.
- Use of power driver is not recommended for screw installation.
- Fully remove the Gainsborough Freestyle prior to painting the door to avoid damaging the product's finish
- Suitable door thickness is between 35 and 45mm


TRILOCK

Installation Instructions

Step 5:

Handing of the External Furniture


- Rehand the lever (if necessary), by pushing the retaining plate inside the furniture as shown. Push through the hole on the same side as the lever.
- Then swing the lever up and over to the other direction.



Step 6:

Assemble the External Furniture to the Door


Install the External furniture onto the door as shown.



Step 7:

Install the Spindle


Fit the Spindle Spring to the Spindle, and then assemble through the latch into the External Handle.



Step 8:

Connect the Internal Furniture


Connect the main loom to the Internal furniture



Step 9:

Connect the Internal Furniture

Ensure the internal and external drive "D" shaft and socket are aligned




Step 10:

Secure the Internal Furniture

Install the Internal furniture, taking care:

- to align the "D" shaft / socket and the latch spindle
- to ensure the loom is not pinched during assembly. This is very important.**

Fasten the Internal Furniture to the External Furniture using the 4 screws supplied with the Allen Key



(If installing the Door Position Sensor, refer to Step 3b on page 3)

Step 11:


Installation of Batteries

Install the batteries and fit the battery cover.

Use only good quality AA ALKALINE batteries.

Note orientation of the batteries.

Do not mix old and new batteries.



Step 12:

Installation of the Strike



All door seals must be fitted prior to fitting strike plate.

Position the door so that the centrepont of the strike plate can be marked on door frame.

Mark and drill a Ø25mm hole to a depth of 25mm, at a corresponding height to the bolt.

Mark and chisel recesses for strike plate

Fit the strike plate using the 2 screws supplied.




(See Step 4b below for installation of Door Sensor Magnet)

Door Position Sensor Installation - Connected Gainsborough Freestyle only

Step 1b:

Prepare Door

Using the template provided, drill a Ø10mm hole in the side of the door as shown.




Step 2b:

Install Door Position Sensor in Door

Insert Door Position Sensor cable through the Ø10mm hole.

Extend it through the Ø54mm hole.


Firmly press the magnet housing into the door edge until the front face is flush with the door edge.



Step 3b:

Connect Door Position Sensor


Connect Door Position Sensor cable to plug on the Main cable



Step 4b:

Install Door Position Magnet


Drill a Ø10mm hole for the Door Position Magnet and fit magnet as shown.



Setting First User Admin Code


Step 1:

Facing the Internal lockset, locate the Program button above the batteries. Press and hold for 10 sec. After approx. 10 sec., confirmation light will blink.




Step 2:

On the External side, slide cover up to energise Keypad.




Step 3:

Press '*', choose '1' then '*'.




Step 4:

Enter desired 4 digit PIN code then press '*'.



Step 5:


PIN code will repeat.
Press '*' again to accept PIN
Press '%/6' to reject PIN



Gainsborough Freestyle Function - with Keypad

Step 1:


Slide cover up to energise Keypad.



Refer to User Guide for full Gainsborough Freestyle functionality.

Step 2:


To **UNLOCK** - Enter 4 digit PIN code and press '%/6'.



Note: Lockset must be in LOCKED state.

Step 3:


To **PRIVACY LOCK** - Press '%/6' when leaving.



Note: Lockset must be in UNLOCKED state.

Step 4:

To **DEADLOCK** - Enter 4 digit PIN code and press '%/6' when leaving.




Note: Lockset must be in UNLOCKED state.

Gainsborough Freestyle Manual Function

PASSAGE MODE

Outside **UNLOCKED**
Inside **UNLOCKED**




PRIVACY MODE

Outside **LOCKED**
Inside **UNLOCKED**

Press Button to engage Privacy mode.

Unlock by external key, keypad or internal by operating lever.



DEADLOCK MODE

Outside **LOCKED**
Inside **LOCKED**

Note: DEADLOCK can only be set via the Keypad (see above).

Unlock by external key, keypad or internal key.

