



www.jbctools.com

INSTRUCTION MANUAL



MV

Pneumatic Desoldering Module
for DIU

This manual corresponds to the following reference:

MV-A

Packing List

The following items are included:



**Pneumatic Desoldering
Module**1 unit



**Module Cable
connector**1 unit
Ref. 0026830



Suction Filter1 unit
Ref. 0821830




Paper Filter Box1 unit
Ref. 0005966
Ref. contains 50 filters



Cotton Filter Set 1 unit
Ref. 0781046
Ref. contains 10 filters





Escape Filter Kit1 unit
Ref. 0008446



Manual 1 unit
Ref. 0027990



Features and Connections




Module	Stand	Tool	Tips Range	Control Units	
				CDD	DIU
MV	DSS	DS360	C360	●	●
	DRS	DR560	C560		●

Maintenance

Before carrying out maintenance, always unplug the electric and pneumatic connectors.

- Use a damp cloth to keep the casing clean.
- Periodically check all cable and tube connections.
- Keep filters clean to ensure proper solder suction and replace them when necessary.

Important: Do not use sharp pointed objects to open the suction filter.



- Use original JBC spare parts only
- Replace any defective or damaged pieces. Only use original JBC spare parts.
- Repairs should only be performed by a JBC authorized technical service.
- Maintenance must not be carried out by children unless supervised.

Removing Pneumatic Tubing

Push the release ring to remove the pneumatic tubing.



Safety



It is imperative to follow safety guidelines to prevent electric shock, injury, fire or explosion.

- Do not use the units for any purpose other than soldering or rework. Incorrect use may cause fire.
- The power cord must be plugged into approved bases. Be sure that it is properly grounded before use. When unplugging it, hold the plug, not the wire.
- Do not work on electrically live parts.
- The tool should be placed in the stand when not in use in order to activate the sleep mode. The soldering tip or nozzle, the metal part of the tool and the stand may still be hot even when the station is turned off. Handle with care, including when adjusting the stand position.
- Do not leave the appliance unattended when it is on.
- Do not cover the ventilation grills. Heat can cause inflammable products to ignite.
- Avoid flux coming into contact with skin or eyes to prevent irritation.
- Be careful with the fumes produced when soldering.
- Keep your workplace clean and tidy. Wear appropriate protection glasses and gloves when working to avoid personal harm.
- Utmost care must be taken with liquid tin waste which can cause burns.
- This appliance can be used by children over the age of eight and also persons with reduced physical, sensory or mental capabilities or lack of experience provided that they have been given adequate supervision or instruction concerning use of the appliance and understand the hazards involved. Children must not play with the appliance.
- Maintenance must not be carried out by children unless supervised.

Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Specifications

MV

Pneumatic Desoldering Module for DIU

Ref.: **MV-A**

- | | |
|-------------------------------------|---|
| - Net Weight: | 679 g / 1.50 lb |
| - Module Dimensions: | 225 x 145 x 55 mm / 8.86 x 5.71 x 2.17 in |
| - Air Pressure Supply Range: | 4 - 6 Bar |
| - Vacuum at 6 Bar: | 90% / 680 mmHg / 26.8 inHg |
| - Flow Rate: | 15 SLPM |
| - Ambient Operating Temperature: | 10 - 40 °C / 50 - 104 °F |
| - Pedal connection | |
| - Total Package Dimension / Weight: | 280 x 195 x 115 mm / 982 g |
| (L x W x H) | 11.02 x 7.68 x 4.53 in / 2.16 lb |

Complies with CE standards.
ESD safe.

JBC

Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labour.

Warranty does not cover product wear or misuse.

In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage.

In accordance with the European directive 2012/19/EU, electronic equipment at the end of its life must be collected and returned to an authorized recycling facility.



www.jbctools.com