

INVERTER GENERATOR USER'S MANUAL



GM6000XiE | **Portable Inverter Generator** 5250 Running Watts | 6000 Peak Watts



WARNING: SAVE THIS MANUAL FOR FUTURE REFERENCE



This manual contains important information regarding safety. Operation, maintenance and storage of this product. Before use, read carefully and understand all cautions, warnings, instructions and product labels. Failure to do so could result in serious personal injury and/or property damage.

**California
Proposition 65 Warning**

The engine exhaust from this product contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

**California
Proposition 65 Warning**

Certain components in this product and its related accessories contain chemicals known to the state of California to cause cancer, birth defects or other reproductive harm. Wash hands after handling.

DISCLAIMERS:

All information, illustrations and specifications in this manual are based on the latest information available at the time of publishing. The illustrations used in this manual are intended as representative reference views only. Moreover, because of our continuous product improvement policy, we may modify information, illustrations and/or specifications to explain and/or exemplify a product, service or maintenance improvement. We reserve the right to make any change at any time without notice. Some images may vary depending upon which model is shown.

ALL RIGHTS RESERVED:

No part of this publication may be reproduced or used in any form by any means - graphic, electronic or mechanical, including photocopying, recording, taping or information storage and retrieval systems - without the written permission of CHONGQING DINKING POWER MACHINERY CO., LTD

 DANGER



This manual contains important instructions for operating this inverter generator. For your safety and the safety of others, be sure to read this manual thoroughly before operating the generator. Failure to properly follow all instructions and precautions can cause you and others to be seriously hurt or killed.

UNPACKING

 CAUTION



Always have assistance when lifting the generator. The generator is heavy; lifting it could cause bodily harm.



Avoid cutting on or near staples to prevent personal injury.

WHAT COMES IN THE BOX

Spark Plug Socket Wrench (1)
Dual-Purpose Screwdriver (1)
User Manual (1)
Warranty Information (1)
Funnel (1)
Duplex plug (1)
Four-prong plug (1)

Tools required - box cutter or similar device.

1. Carefully cut the packing tape on top of the carton.
2. Remove socket wrench, oil and funnel and save for later.
3. Carefully cut two sides of the carton to remove the generator.

LIMITED WARRANTY

1. DURATION : One (1) year from the date of purchase by the original purchaser (retail customer) on products used solely for consumer applications; if a product is used for business, commercial, or industrial applications, the warranty period will be limited to ninety (90) days from the date of purchase.
2. WHO GIVES THIS WARRANTY (WARRANTOR):
CHONGQING DINKING POWER MACHINERY CO., LTD
3. WHO RECEIVES THIS WARRANTY(PURCHASER):The original purchaser (other than for purposes of resale) of the Genmax's inverter.
4. WHAT PRODUCTS ARE COVERED BY THIS WARRANTY: Any portable generator supplied or manufactured by Warrantor.
5. WHAT IS COVERED UNDER THIS WARRANTY: Substantial defects on material and workmanship which occur within the duration of the warranty period.
6. WHAT IS NOT COVERED UNDER THIS WARRANTY:
 - A. Transportation charges for sending the product to Warrantor or its authorized service representative for warranty service, or for shipping repaired or replacement products back to the customer; these charges must be borne by the customer.
 - B. Damages caused by abuse, accident, shipping, misuse, overloading, modification, and the effects of corrosion, erosion and normal wear and tear.
 - C. Warranty is voided if the customer fails to install, maintain and operate the product in accordance with the instructions and recommendations set forth in the owner's manual(s), or if the product is used as rental equipment.
 - D. Pre-delivery service, i.e. assembly, oil or lubricants, and adjustment.
 - E. Items or service that are normally required to maintain the product, i.e. lubricants and filters.
 - F. Warrantor will not pay for repairs or adjustments to the product, or for any costs or labour, performed without Warrantor's prior authorization.

EXCLUSIONS AND LIMITATIONS : Warrantor makes no other warranty of any kind, express or implied. Implied warranties, including warranties of merchantability and of fitness for a particular purpose, are hereby disclaimed. This warranty service described above is the exclusive remedy under this warranty; liability for incidental and consequential damages is excluded to the extent permitted by law.

7. RESPONSIBILITIES OF PURCHASER UNDER THIS WARRANTY:

- A. The purchaser must provide dated proof of purchase and must notify Warrantor within the warranty period.
- B. Deliver or ship the serviced generator or component to the nearest Warrantor's authorized service representative. Freight costs, if any, must be borne by the purchaser.

8. HAVE QUESTIONS?

Email: warrantiessmallengines@gmail.com Phone: 866-960-2920

WARRANTY CARD

PERSONAL INFORMATION

Name: _____

Street Address: _____

City, State, ZIP: _____

Country: _____

Phone Number: _____

E-Mail: _____

INVERTER INFORMATION

Model Number: _____

Serial Number: _____

Date Purchased: _____

Purchased From: _____

GENMAX®

TABLE OF CONTENTS

LIMITED WARRANTY	2
SAFETY WARNING	4
SAFETY INSTRUCTIONS	5
NAMES OF COMPONENTS	7
INSTALLATION OF WHEELS AND HANDRAILS	8
CONTROL FUNCTIONS	9
PREPARATIONS	10
1.Fuel.....	10
2.Oil.....	10
3.Pre-operation inspection.....	11
STARTING UP THE GENERATOR	12
SHUTTING DOWN THE GENERATOR	13
USING THE GENERATOR	14
1.Service environment of the generator.....	14
2.Generator wiring.....	14
3.Generator grounding.....	15
SERVICE AND MAINTENANCE	16
1.Spark plug inspection.....	17
2.Adjustment of the carburetor.....	18
3.Replacement of oil.....	18
4.Air filter.....	19
5.Fuel filter screen.....	20
STORAGE AND TRANSPORT	21
1.Generator storage.....	21
2.Generator transport.....	22
TROUBLESHOOTING	23
TECHNICAL PARAMETERS	24
CIRCUIT DIAGRAM	25
CHOOSING A GENERATOR	27

SAFETY WARNING



Personal and property safeties of you and others are very vital. Please read the Safety Warning in the User's Manual and the decals of the generator set carefully. The Safety Warning can alert you to those potential hazards that could harm you and others. In front of each Safety Warning, there is one of four words "**DANGER**" "**WARNING**", "**ATTENTION**", and "**CAREFUL**". Details are as follows:

DANGER

Failure to follow the instruction will result in being in peril of your life or extremely serious injury.

WARNING

Failure to follow the instruction will result in being in peril of your life or very serious injury.

CAREFUL

Failure to follow the instruction will result in minor injury.

ATTENTION

Failure to follow the instruction will result in the damage to your generator set and other properties.

CO TECHNICAL WARNING

CO DETECT technology monitors the accumulation of carbon monoxide (CO), a poisonous gas produced by engine exhaust when the generator is running. If CO Sensor detects unsafe elevated levels of CO gas, it automatically shuts off the engine. CO Sensor is not a substitute for an indoor carbon monoxide alarm or for safe operation. DO NOT allow engine exhaust fumes to enter a confined area through windows, doors, vents or other openings. Generators must ALWAYS be used outdoors, far away from occupied buildings with engine exhaust pointed away from people and buildings. Meets the requirements of ANSI/PGMA G300-2018.

NEUTRAL FLOATING


For portable generators where the neutral is floating, the operator's manual shall include the following wording or equivalent:

The portable generator stator winding is isolated from the frame and from the AC receptacle ground pin; and Electrical devices that require a connection between one conductor pin and the grounded receptacle pin may not function properly.




SAFETY INSTRUCTIONS

Before operating the generator, it will help you avoid accidents to read and understand the Manual and familiarize yourself with the safe operation procedures of the generator.




Please do not use indoors



Please do not use in humid environment



Please do not connect it to household appliances directly



Please do not smoke when refueling



Please do not spill when refueling





Please shut down the generator before refueling



SAFETY INSTRUCTIONS

SAFETY LABELS AND DECALS



1




A hot exhaust system can cause serious burns, avoid contact if the engine has been running.

2




Before using the generator, please read the operation manual.
Be careful with the shock hazard.
Be careful, the fuel is flammable, do not add the fuel when the engine is running.

3



Do not use the generator in door or garage, the exhaust contains carbon monoxide, this is a poison you cannot see or smell, and it will kill you in minutes.


4



5

GM6000XiE		Inverter Generator	
Rated Power	5.25kW	Power Factor	1
Rated Voltage	120V/240V	Performance Class	G1
Rated Frequency	60Hz	Number Of Phases	Single
Rated Current	21.9A	Insulation Class	Class F
Rated Speed	3600rpm	Rated ambient temperature	25°C
CHONGQING DINKING POWER MACHINERY CO.,LTD.			

NAMES OF COMPONENTS



INSTALLATION OF WHEELS AND HANDRAILS

Install Support Foot

1. Align the two holes on the support seat with the two holes on the bottom of the frame. Place two bolts through the support seat hole and the frame hole;



2. Fasten the nut to the bolt, tighten with a wrench. Install the other side in the same way.



Install the Wheel

1. Pass the axle through the wheel, connect to the rack;



2. Insert the R pin into the hole in the wheel shaft. Install the other side in the same way.



Install Handrails


1. Bolt the handle to the frame;



2. Fasten the nut to the bolt, tighten with a wrench. Install the other side in the same way.



CONTROL FUNCTIONS



CONTROL PANEL FEATURES GM6000XiE

① 120-Volt, 20-Amp Duplex Outlet (NEMA 5-20R):

The outlet is capable of carrying a maximum of 20 amps.

② **USB Duplex:** 5V DC that come in 1 amps and 2.1 amps.

③ **Reset:** If the inverter is overloaded, the reset breaker will trip. The engine will continue to run, but there will be no output from the inverter. Unplug the devices and reduce the load. Push in the reset breaker to reset it.

④ **Low Idle:** When turned to the ON position, the engine will sense the load needed and run at a slower RPM to save fuel.

⑤ **Ground Terminal:** The ground terminal is used to externally ground the inverter.

⑥ **Low Oil Alarm:** Indicates low oil level.

⑦ **Overload Alarm:** Indicates that the inverter is overloaded.

⑧ **Power Indicator:** Indicates the inverter is ready to be used.

⑨ **120/240-Volt, 30-Amp Outlet (L5-30):** The outlet is capable of carrying a maximum of 30 amps.

⑩ **Circuit Protector:** If the inverter is overloaded, the reset breaker will trip to block current.

⑪ **Hours:** Total time of generator use.

⑫ **CO Alarm:** Flashing red light: dangerous levels of carbon monoxide gas have built up leave immediately until area has aired out. Move generator to well-ventilated area before operation. Flashing yellow light: carbon monoxide sensor malfunction. Sensor needs service.

⑬ **Engine Switch:** Manage battery power and shutdown.

⑭ **Choke Switch:** when cold start, properly close part of the air inlet to improve the engine start performance, after normal operation, the choke should be fully open, otherwise the engine can not run properly because of too thick mixture and cause too much oil consumption.

PREPARATIONS

1 Fuel



DANGER

- Fuel is flammable and toxic, please read the Safety Instruction carefully before refueling;
- Do not fuel too full, otherwise fuel will spill after fuel tank is warmed;
- After refueling, confirm that the fuel tank cap has been tightened.



ATTENTION

- After refueling, dry gasoline residue with a clean and soft cloth in time to avoid damaging plastic enclosure;
- Unleaded gasoline must be used, as leaded gasoline can seriously damage internal parts of the generator;

Remove the tank cap and add gasoline.
Fuel tank capacity: **3.8gal**



2 Oil

No oil is filled into this generator when being delivered. Do not start up the generator without filling sufficient oil.

1. Please place the generator onto a horizontal plane surface;

2. Unscrew oil dipstick, Fill in 0.21gal oil (SAE 10W/30 oil is recommended, of which the grade is API standard Type SE or higher);



Don't go over the scale



3. Tighten the oil dipstick.



3 Pre-use Inspection



WARNING

Even if the generator is not in service, its important component may suddenly fails. Before the generator is started up, if any of following components is unable to work properly, please inspect and repair carefully.

Tip: The condition of the generator shall be inspected before using every time.

Pre-operation inspection

Fuel

- Check fuel level in fuel tank of the generator, and fuel it if necessary.

Oil

- Check oil level of the generator, and fill oil if necessary;
- Check whether there is oil leaking.

Abnormal conditions during operation

- Check operating condition of the generator;
- If there is any need, please do not hesitate to consult your dealer.



STARTING UP THE GENERATOR


1. Remove the load from all output ends;

2. Connect battery line before first use:

1. Unscrew the bolt on the negative electrode of the battery;
2. Install the negative wire through the bolt to the battery;
3. The positive wire is installed in the same way.



3. Turn fuel switch to "ON" position;



4. Press LOW IDLE to "OFF";



5. Pull the choke out;

Tip: There is no need to pull out the damper when the engine is started in warm state.



6. Select Boot Mode:

a. Hand Starting:

1. Press the engine switch to move up the middle position "ON";
2. Pull the starting handle to start the generator.



b. Electric Start: Press the engine switch upward to the Start position "Start" for 2-3 s.



- 7.** After starting push the choke in;




- 8.** Plug in after started.




SHUTTING DOWN THE GENERATOR

- 1.** Unplug the power cord;

- 2.** Press main switch to "OFF" position;



- 3.** Turn fuel switch to "OFF" position.



USING THE GENERATOR

1 Service environment of the generator

- Applicable temperature: $-5^{\circ}\text{C} \sim 40^{\circ}\text{C}$;
- Applicable humidity: below 95%;
- Applicable altitude: regions below 1,500 m (It shall be used by reducing power in regions above 1,000 m).

Standard atmospheric condition


- Ambient temperature T_r : 298k (25°C)
- Relative air humidity Φ_r : 30%
- Absolute atmospheric pressure P_r : 100kPa

When actual environmental condition is inconsistent with the condition of output power of the generator set:

- Every 5°C of increase in ambient temperature will reduce the power of generator by about 2%.
- Every 30% of increase in relative humidity of air will reduce the power of generator by about 1.5%.
- Every 300 m rising of ASL will reduce the power the generator by about 4.5%.

2 Generator wiring

- When the generator is connected to household power source as a backup power supply, the connection shall be carried out by a professional electrician or a person familiar with electricity.
- After connecting the load to the generator, check carefully whether electrical connection is safe and reliable. Improper electrical connection may cause generator damage, burning or fire.
- Avoid connecting this generator to commercial power outlet.
- When extending the cable, be sure not to exceed its length.
 - ① 60m cross-section area is 1.5mm^2
 - ② 100m cross-section area is 2.5mm^2
- The appearance of extension cable shall be protected by a layer of tough and elastic rubber cover (IEC25) or other substitutes.



USING THE GENERATOR

Connection of AC power



WARNING

All electrical equipment shall be disconnected before inserting the plug.




ATTENTION

- Make sure that all electrical equipment, including wires and plugs, are in good condition before connecting to the generator;
- Make sure that all loads driven by the generator are within rated load range;
- Make sure that load current is within rated current range of rated socket.

Tip: Make sure that the generator set is grounded, and if electrical equipment requires grounding, the generator set must be grounded.

- ① Start up the engine;
- ② Turn energy-saving switch to "ON";
- ③ Insert the plug into AC outlet;
- ④ Make sure that AC indicator is lit up;
- ⑤ Switch on electrical equipment.

Tip: Before increasing engine speed, energy-saving switch must be switched to "OFF". If the generator set supplies power to multi loads or electrical equipment, start from large to small according to the size of each electrical equipment.



3 Generator grounding

In order to prevent any damage to the generator caused by electric shock or improper electrical application, it is recommended that the generator is grounded with good conductor with insulating sheath.

- ① Please use grounding wire with sufficient electrical energy capacity;
- ② Connect one end of grounding wire reliable to grounding bolt on control panel of the generator set;
- ③ Insert grounding body (iron rod with a diameter of 5 ~ 10mm) 200mm below into the earth and lead it out with conductor;
- ④ Connect the other end of the grounding wire reliable to the led wire of grounding body.



SERVICE AND MAINTENANCE

Good maintenance and service is the best guarantee for safe, economical and zero-failure operation. It also contributes to environmental protection.

In order to keep the generator in good condition, you must inspect and maintain it regularly. The maintenance schedule is as follows:

Maintenance cycle		Each	First in 1 month or 20 hours	Then every three months or every 50 hours	100 hours per year or use
Item					
Engine oil	Check-fill	√			
	Replace		√	√	
Gearbox gear Oil (if any)	Check oil	√			
	Replace		√	√	
Air cleaner element	Inspection	√			
	Clean		√		
	Replace			√	
Settling cup (if any)	Clean				√
Spark plug	Clean-adjust				√*
Spark eliminator	Clean			√	
Idle speed (if any)**	Check-adjust				√
Valve clearance**	Check-adjust				√
Fuel tank and fuel filter***	Clean				√
Fuel line	Inspection	Every two years (Please replace if necessary)			
Cylinder head, piston	Remove carbon deposit**	Displacement < 225cc, every 125 hours; displacement capacity ≥ 225cc, every 250 hours.			
* These items shall be replaced if necessary; ** These items shall be maintained by the dealer authorized by the Company, unless the user has proper tools and maintenance ability.					

ATTENTION

- If it often works under high temperature or high load, oil shall be changed every 25 hours;
- If it often works in dusty or harsh environment, air cleaner element shall be cleaned every 10 hours. If necessary, the air cleaner element shall be replaced every 25 hours;
- It shall be maintained on spot-inspection cycle and time, whichever is earlier;
- If maintenance cycle time has elapsed, perform the maintenance as soon as possible as per the table above.



WARNING

Please shut down the engine first before performing any maintenance. The engine shall be placed in a horizontal position. In order to prevent the engine from starting up, separate spark plug cap shall be separated from spark plug.

Do not use it indoors or use it in a tunnel, cave or other places ventilated poorly. Make sure that work area is well ventilated. Exhaust gas from the engine contains toxic gases, carbon oxides, and the inhalation can cause shock, loss of consciousness, and even death.


1 Spark plug inspection

Spark plug is an important part of the generator, which must be inspected regularly.

1. Remove the high voltage assembly;



2. Insert the screwdriver into the sleeve, to screw it counterclockwise, and then remove the spark plug;




3. Check whether there is discoloration, and remove carbon deposits. Check whether there is little pale to moderate brown on ceramic cores around center electrode of the spark plug;



4. Check the model of spark plug and clearance.

Standard spark: BPR6ES

Spark plug gap: 0.7-0.8mm



Tip: The spark plug clearance is required to be measured by line thickness gauge, which shall be adjusted if necessary.



SERVICE AND MAINTENANCE

5. Install the spark plugs in reverse order of removal.

Spark cold torque: 22.5 ± 2.5 N.m



Tip: If there is no torque wrench when installing the spark plug, a better estimation method is to screw it 1/4-1/2 turns by force after screwing it in place, but the spark plug shall be screwed to specified torque as soon as possible.

2 *Adjustment of the carburetor*

The carburetor is an important components of the engine. The adjustment shall be carried out by a dealer with professional knowledge, professional data and equipment, to ensure that the adjustment is proper.

3 *Replacement of oil*



WARNING

Do not drain the oil immediately after turning off the generator. Oil temperature is very high, when operating, take care to avoid scalding.

1. Put the generator on a horizontal surface, start the generator, run it for a few minutes to increase its temperature, and then turn off the engine;

2. Unscrew oil dipstick;



3. Place the container and tilt the machine to drain the oil;




SERVICE AND MAINTENANCE

4. Refill oil to a proper level, tighten oil dipstick, cover external cover plate and tighten the knob.

Recommended oil: SAE S10W/30

Oil grade: API standard Model SJ or higher

Volume: 0.21gal



4 Air filter

Dirty air cleaner may prevent air from flowing into the carburetor. In order to prevent failure of the carburetor, please maintain air cleaner regularly. If being used in a dusty environment, it shall be maintained frequently.

1. Remove screws, to remove cover plate of air cleaner ;



2. Clean foam cleaner element with cleaning solvent and blow it dry, Put a few drops of oil on the filter element;



ATTENTION


Be sure not to twist the foam cleaner element forcibly to avoid damage.



3. Put foam cleaner element into air cleaner;
Tip: Make sure that the surface of foam cleaner element is in close contact with air cleaner, and there shall be no gap leaking air. Be sure not to start the engine before air cleaner is assembled, because it will generate excessive toxic gas and wear the cylinder;



4. Reassemble empty air cleaner cap back to original position, and tighten screws.



SERVICE AND MAINTENANCE

5 Fuel filter screen



WARNING

Be sure not to open fuel tank of the generator in a place where smoking or with flame.

1. Remove fuel tank cap and fuel tank filter screen.
2. Clean fuel tank filter screen with gasoline.
3. Wipe filter screen dry, and put it back into fuel tank.
4. Reassemble fuel tank cap.



ATTENTION

Be sure to screw fuel tank cap tight.



STORAGE AND TRANSPORT

1 Generator storage

If it is stored long-term, in order to prevent aging, you shall take some storage measures.

1. Follow the shutdown steps to shut down the generator.


2. Open fuel tank cap, to take out fuel filter screen.
Pump all fuel in fuel tank into special fuel tank,
and then reassemble fuel tank cap back.



3. Start up the engine to burn off fuel in the carburetor, and then shut it down.

Tip: Do not connect any electrical equipment. Running time of the engine depends on remaining fuel in the fuel tank.

4. Locate the carburetor to drain the remaining gasoline and place a suitable container to capture the emitted fuel.



5. Loosen the carburetor drain screws until you see fuel draining from the carburetor.



6. Allow fuel to drain into the container and tighten the drain screws on the carburetor.



7. Unscrew oil dipstick, and drain oil in the crankcase off. Fill new oil to upper oil limit, and then assemble oil dipstick.




STORAGE AND TRANSPORT

8. Gently pull startup handle until you feel resistance, allowing both inlet valve and exhaust valve to be closed.



9. Disconnect the battery cable.



10. Place the generator set in a clean and dry area.

2 Generator transport

- When the generator set is transported, it shall be ensured that there is no fuel spilling;
- Do not fill excessive fuel into fuel tank;
- Do not run the generator, and avoid direct sunlight;
- Do not transport the generator set on rough road for long time.



TROUBLESHOOTING

Problem	Possible Causes	Probable Solutions
Engine will not start	FUEL RELATED: - No fuel in tank or fuel valve closed. - Choke not in START position, cold engine. - Gasoline with more than 10% ethanol used. (E15, E20, E85, etc.) - Low quality or deteriorated, old gasoline. - Carburetor not primed. - Dirty fuel passageways. - Carburetor needle stuck. Fuel can be smelled in the air. - Too much fuel in chamber. This can be caused by the carburetor needle sticking. - Clogged Fuel Filter.	FUEL RELATED: - Fill fuel tank with fresh 87+ octane stabilizer-treated unleaded gasoline and open fuel valve. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.). - Move Choke to START position. - Clean out ethanol rich gasoline from fuel system. Replace components damaged by ethanol. Use fresh 87+ octane stabilizer-treated unleaded gasoline only. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.). - Use fresh 87+ octane stabilizer-treated unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.). - Pull on Starter Handle to prime. - Clean out passageways using fuel additive. Heavy deposits may require further cleaning. Gently tap side of carburetor float chamber with screwdriver handle. - Turn Choke to RUN position. Remove spark plug and pull the start handle several times to air out the chamber. Reinstall spark plug and set Choke to START position. - Replace Fuel Filter.
	IGNITION (SPARK) RELATED: - Power Switch at OFF position. - Spark plug cap not connected securely. - Spark plug electrode wet or dirty. - Incorrect spark plug gap. - Spark plug cap broken. - Circuit breaker tripped (electric start models only). - Incorrect spark timing or faulty ignition system.	IGNITION (SPARK) RELATED: - Turn Power Switch to ON. - Connect spark plug cap properly. - Clean spark plug. - Correct spark plug gap. - Replace spark plug cap. - Reset circuit breaker. Check wiring and starter motor if breaker continues to trip. - Have qualified technician diagnose/repair ignition system.
	COMPRESSION RELATED: - Cylinder not lubricated. Problem after long storage periods. - Loose or broken spark plug. (Hissing noise will occur when trying to start.) - Loose cylinder head or damaged head gasket. (Hissing noise will occur when trying to start.) - Engine valves or tappets mis-adjusted or stuck.	COMPRESSION RELATED: - Pour tablespoon of oil into spark plug hole. Crank engine a few times and try to start again. - Tighten spark plug. If that does not work, replace spark plug. If problem persists, may have head gasket problem, see #3. - Tighten head. If that does not remedy problem, replace head gasket. - Have qualified technician adjust/repair valves and tappets.
	ENGINE OIL RELATED: - Low engine oil. - Engine mounted on slope, triggering low oil shutdown.	ENGINE OIL RELATED: - Fill engine oil to proper level. Check engine oil before EVERY use. - Operate engine on level surface. Check engine oil level.
	SPARK ARRESTOR RELATED: Spark Arrestor clogged with soot.	SPARK ARRESTOR RELATED: Clean and replace Spark Arrestor.



Follow all safety precautions whenever diagnosing or servicing the generator or engine.



TROUBLESHOOTING

Problem	Possible Causes	Probable Solutions
Engine misfires	1. Spark plug cap loose. 2. Incorrect spark plug gap or damaged spark plug. 3. Defective spark plug cap. 4. Old or low quality gasoline. 5. Incorrect compression.	1. Check cap and wire connections. 2. Re-gap or replace spark plug. 3. Replace spark plug cap. 4. Use only fresh 87+ octane stabilizer-treated unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.). 5. Diagnose and repair compression. (Use Engine will not start: COMPRESSION RELATED section.)
Engine stops suddenly	1. Carbon Monoxide level high. Red light on Carbon Monoxide Sensor illuminates. 2. CO Sensor Alarm flashes yellow continually shortly after starting. 3. CO Sensor Alarm flashes yellow continually after longer period of operation. 4. Low oil shutdown. 5. Fuel tank empty or full of impure or low quality gasoline. 6. Defective fuel tank cap creating vacuum, preventing proper fuel flow. 7. Faulty magneto. 8. Disconnected or improperly connected spark plug cap.	1. Leave area immediately and allow area to ventilate thoroughly. Only operate generator outside. 2. Carbon monoxide sensor malfunction. Sensor needs service. Do not use the Generator until the sensor is working properly. 3. Make sure to operate generator within rated ambient temperature; maintain minimum 5 ft. clearance from all sides. 4. Fill engine oil to proper level. Check engine oil before EVERY use. 5. Fill fuel tank with fresh 87+ octane stabilizer treated unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.). 6. Test/replace fuel tank cap. 7. Have qualified technician service magneto. 8. Secure spark plug cap.
Engine stops when under heavy load	1. Dirty air filter 2. Engine running cold.	1. Clean element. 2. Allow engine to warm up prior to operating equipment.
Engine knocks	1. Old or low quality gasoline. 2. Engine overloaded. 3. Incorrect spark timing, deposit buildup, worn engine, or other mechanical problems.	1. Fill fuel tank with fresh 87+ octane stabilizer-treated unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.). 2. Do not exceed equipment's load rating. 3. Have qualified technician diagnose and service engine.
Engine backfires	1. Impure or low quality gasoline. 2. Engine too cold. 3. Intake valve stuck or overheated engine. 4. Incorrect timing.	1. Fill fuel tank with fresh 87+ octane stabilizer-treated unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.). 2. Use cold weather fuel and oil additives to prevent backfiring. 3. Have qualified technician diagnose and service engine. 4. Check engine timing.
Attached device doesn't have power	1. Device not plugged in properly. 2. Circuit Breaker tripped. 3. Product needs service.	1. Turn off and unplug the device, then plug it back in again and turn on. 2. Turn off and unplug device, reset Circuit Breaker, plug in device and turn on. 3. Have product repaired.
Attached device begins to operate abnormally	1. Problem with device. 2. Rated load capacity exceeded.	1. Immediately unplug device. Have device repaired by a qualified technician, or replace device. 2. Lower the number of items plugged into the generator to stay within the rated capacity, or use a more powerful generator.



Follow all safety precautions whenever diagnosing or servicing the generator or engine.




TECHNICAL PARAMETERS

Item	GM6000XiE
Rated Power (kW)	5.25
Max. Power (kW)	6.0
Engine Model	180F/P-2
Stroke x Bore (mm)	80x62
Engine Type	4-stroke
Displacement (cc)	312
Gas Distribution Mode	OHV
Cooling Mode	Forced cooling wind
Rated Speed (RPM)	3600
Starting Method	Recoil start
Fuel Tank Volume (gal)	3.8
Fuel Type and Grade	Vehicle-use unleaded gasoline
Lubricating Oil Capacity (gal)	0.21
Lubricating Oil Model	SAE 10W/30
Noise dB (at 7m)(25% load)	70
Rated Voltage (V)	120/240
Rated Frequency (Hz)	60
Rated Power Factor	1
Phase Number	Single phase
Run Time @ 25% (h)	13
Overall Dimension (in.)	22.2x18.1x17.7
Net Weight (lb.)	106.9

CIRCUIT DIAGRAM

GM6000XiE SCHEMATICS



QUICK REFERENCE WATTAGE

Power Rating	Tool or Appliance	Running Watts	Starting Watts
5500 - 12,000 Running Watts	Blender	300	650
	Coffee Maker	1500	
	Drill	600	900
	Fan	200	
	Furnace 1/4 hp	600	1000
	Game console	150	
	Hand sander	600	1200
	Hedge trimmer	450	1200
	Lamp	100	
	Laptop	800	
	LED/LCD TV	150	
	Microwave	1000	
	Modem/router	20	
	Paint sprayer	600	600
	Radio	100	
	Slow cooker	200	200
	String trimmer	350	875
	Sump Pump 1/3 hp	800	1300
	Work light	1000	
	Belt sander	1200	2400
2800 - 3800 Running Watts	Chainsaw	1200	2400
	Circular saw	1200	2000
	Edger	950	2400
	Electric grill	1650	
	Lawn mower	1200	2400
	Pressure washer	1200	2400
	Refrigerator	700	2200
	Washing machine	1150	2250
	Well pump	1000	2100
	Window AC 13k BTU	1800	2800
	Air compressor 1 hp	1600	4500
	Central AC 3 ton	5400	7200
	Electric Dryer	5400	6750
	Heat Pump 3 ton	3400	6500
	Water heater	4000	

†Chart for reference only. Check your device for ACTUAL wattage requirements.

HOW TO CALCULATE

Running Watts needed:

Total Running Watts of ALL items to be powered by the generator.

Starting Watts needed:

Add highest SINGLE Starting Watt to Total Running Watts needed above.

EXAMPLE

1 Calculate Running Watts:

Furnace	600
Lamp	100
Microwave	1000
Refrigerator	700

Total Running Watts 2400

2 Calculate Starting Watts:

Total Running Wattage	2400
Refrigerator	2200

Total Starting Watts 4600





In production management, based on orderly, efficient, scientific principles. trying to do as better as possible in product design, development, production, inspection,etc. to make our production can keep orderly . And will continue to make improvement to make sure that keep the competitiveness.

Welcome friends at home and abroad to visit and guide, work together to create brilliant.

GENMAX[®]

Caojie Industrial Park,Hechuan District,Chongqing

Phone 866-960-2920

E-mail warrantiessmallengines@gmail.com

Http://www.genmaxpower.com/



6800.526.GEM.02.00 V1

