


Smart Robot Vacuum Cleaner

Instruction Manual

(V16 / SC-860SV)



Contents

1. Safety information	3-5
1.1 Warnings	3
1.2 Use restrictions	3
1.3 Power precautions	4
1.4 Precautions	5
2. Accessories List	6
3. Product	7-8
3.1 Robot	7
3.2 Charging base	8
3.3 Dust bin	8
3.4 Water tank(optional)	8
4. Operating	9-10
4.1 Remote control	9
4.3 Preparation before use	9
4.4 Power On / Off / Sleep mode	10
5. Function description	11-13
5.1 Auto cleaning	11
5.2 Random cleaning	11
5.3 Recharge	12
5.4 Spot cleaning	13
5.5 Edge cleaning	13
5.6 Mopping	13
5.7 Virtual wall	13
6. Maintenance	14-16
6.1 Main brush cleaning	14
6.2 Side brush cleaning	15
6.3 Universal wheel cleaning	15
6.4 Dust bin cleaning	16
6.5 Filter cleaning	17
7. Water tank and mop	17-18
8. Troubleshooting & Parameters	19



● Warnings

- Please read all safety instructions carefully before operating your robot.
- Please keep the instruction manual for future reference.
- Please pay attention to all warnings in your device, including battery, charging base and instruction manual.
- Please follow the instruction manual for all operations.

● Use restrictions

- ▲ Please use this product strictly in accordance with the instruction manual.
Any loss or damage caused by improper use shall be borne by the user.
- ※ Only for home floor environment cleaning.
Do not use this device in outdoors (open balcony), suspended environment (top of furniture; duplex floor), commercial or industrial environment.
- ※ Uncleanable items
Before using, please tidy up the fragile objects and sharp objects (such as nails, broken glass, etc.) scattered on the ground, curtain wires, temporarily erected wires, vases and so on. Otherwise, it is easy to damage or winding the main engine, which will lead to the failure of normal cleaning, or even lead to short circuit of the wires and endanger personal safety.
- ※ Do not clean flammable materials and liquids
It is forbidden to clean the ground with sticky liquids materials (glue, pet droppings, etc.) and flammable materials (tobacco butts, matches, etc.).
- ※ Use restrictions
Do not use this product in a bathroom, where it is damp or dripping, or it may damage the device and cause electric shock, fire and other damage.
- ※ Do not use other brands' accessories.
Do not use other brands' accessories, please use only the adapter and charging base that are delivered to charge the device.
- ※ No standing / stepping on
Do not sit or stand on this device, small children should be supervised when the robot is operating.



Safety information

※ Do not use corrosive liquid wipe products

Do not use water to wash or corrode the liquid to wipe any position of the product, in order to avoid damage to the internal electronic components and appearance of the product.

※ Do not use wet cloth / wet hand to wipe the charging base

Do not wipe or clean the charging base with a wet cloth or wet hands.

※ Do not disassemble and repair by yourself

If there is a problem with the product, please contact the after-sales service personnel in time, do not disassemble the device or the charging base.

※ Battery disposal

Do not dispose discarded batteries, incinerate batteries, or place them in any liquid. Batteries should be disposed of by a professional recycling agency.

※ Storage instructions

If you won't use the product for a long time, please turn off the main device and put it in a cool and dry place when fully charged, and charge it at least once every three months to prevent the battery from being over-discharged and cause the device stop working.

※ Transportation

If you need to transport the product, please make sure that the main device is turned off and it is recommended to use the original packaging.

● Power precautions

▲ Use adapters and sockets in accordance with the following instructions to avoid fire, electric shock or damage :

- Do not over twist or bend the adapter power cord, otherwise the core may be exposed or broken, in order to avoid leakage or electric shock and other personal safety accidents.
- Please use only the original adapters provided, do not use the adapters of other brands.
- Do not use the adapter provided with this device for other devices.
- When disconnecting the adapter from the charging base, hold the plug and pull it out, don't pull the cable directly.




If there is a problem with the product, please contact the after-sales service personnel!




Safety information

● Precautions


- ▲ Due to the different household environment, the robot may miss some area during a cleaning process. In order to achieve the best cleaning effect, it is recommended to use it daily and remove some unfriendly environmental obstacles for the device.




- ※ Wires that are scattered on the ground or power cords of various household appliances, and wires that are temporarily erected maybe entangled at any time, it may cause short-circuiting of the wires, endangering personal safety, etc., must be removed before cleaning.




- ※ Please hide the tassel side of the carpet or directly put the product on the carpet to clean it. The rolled burrs, piles, etc. will wrap around the main device then affect the best cleaning effect.




- ※ If the height of the bottom of the furniture is less than 8 cm, it can jam the product. When cleaning, please raise the furniture.



- ※ A virtual wall is required at the edge of the floor to ensure safe operation of the product.




- ※ Place the furniture and appliances in the house neatly, avoid product jamming during the cleaning process.




- ※ Please do not stand in the aisle or threshold to avoid product miss cleaning some part of the area.

Accessories List


● Accessories List



1) Robot



2) Charging base




3) Adapter



4) Remote control




5) Side brush x4




6) Filter



7) Instruction manual




8) Cleaning brush




9) AAA battery x2



10) Virtual wall (Optional)




11) Water tank (Optional)





12) Mop x2 (Optional)



Robot




Blue : standby / normal
Red : fault prompt
Yellow : low battery
Yellow/Blue flashes: charging status




Please do not paste or cover the anti drop sensor;
check and clean it frequently to avoid dust and dirt affecting normal operation!


● Charging base



● Dust bin




● Water tank(Optional)



Operating

● Remote control



1. Power button
2. Arrow buttons
3. Edge cleaning
4. Suction mode
5. Auto recharge
6. Mute
7. Auto cleaning
8. Spot cleaning
9. Random cleaning


● Suction mode




Silence / Standard / Super

● Preparation before use

▲ After you receive this product, please complete the following steps before use.




1 Remove the protection sheet.




2 Install the side brushes for the robot.





- 3** Place the charging base against the wall, reserve a space of more than 1 meter in radius;



- 4** Fully charge the robot.




1. The charging base is recommended to be placed on the open floor of a room with a larger area and usually the most need to be cleaned.
2. Before start cleaning, please remove all kinds of wires on the floor to avoid damage or other accidents caused by winding the robot during the cleaning process.
3. take the wire into the slot or hang on the wall to avoid winding the device or causing circuit accidents.

● Power ON/ OFF/ Sleep mode

○ Power ON/ OFF

- ※ Push the power switch to "1", Power on;
- ※ Push the power switch to "0", Power off;



○ Sleep mode


- ※ When the robot is power on and not doing cleaning, After 3 minutes, it will automatically shut down and sleep, saving power.
- ※ In sleep mode, operate the remote control "U" twice to wake up the machine.



Function description

● Automatic cleaning


- ※ Press the “  button on the robot or remote control to start automatic cleaning;
- ※ Robot uses a preset cleaning process, and the path is neat and orderly, get higher efficiency cleaning.



Tips : It is recommended that the robot start the cleaning while it's on the charging base. By this way, the robot will mark the charging base position, when the cleaning task is completed or when return to charging base, the robot can quickly return to the charging base.

● Random cleaning

- ※ Press the “  button on the remote control to start Random cleaning;
- ※ Random cleaning uses a random way to steering and cleaning method.




Tips : Because the carpet scene will affect the accuracy of the host positioning and recording device, it may cause abnormal path planning and affect the cleaning coverage, it is highly recommended to use random mode to clean the carpet scenes.

● Recharge


○ Auto recharge

- ※ When the cleaning finished, robot will automatically return to recharge
- ※ Whenever the battery is lower then 20%, robot will automatically return to charge ;
- ※ When the robot start at the charging base, When it needed to be charge, robot can quickly return to recharge.



○ Manually recharge

- ※ Press the button “” on the remote or robot, start to go back to recharge.
- ※ When the robot start at a random place, and it's not near the charging base, the robot will follow the edge to find the path back to recharge.




1. Please try to keep the operation environment neat and tidy, because a complex environment may cause a reduction in the success rate of the robot's recharge.
2. Do not place the charging base to direct sunlight, also do not block the charging base to affect auto recharging.



Function description


◎ Spot cleaning

- ※ Press “  button on the robot or remote control to start spot cleaning; use spiral (1.2 m) spot cleaning method.




◎ Edge cleaning

- ※ Press the button “  to start edge cleaning; Cleaning trash along the edge accurately and steadily.




◎ Water tank(optional accessory)

- ※ With water tank,robot can mopping the floor;
- ※ Install the water tank then press “  button to sweeping and mopping together;



◎ Virtual wall(optional accessory)

- ※ This device supports the magnetic virtual wall function, and you can use a virtual wall to isolate areas that you do not want the device get into. (Such as bathroom with wet floor, stairs or fragile items)



Note :

1. Please refer to page P13 for installation and maintenance of the water tank.
2. When using the wet mop function, due to marble or plank ground environment, there may be abnormal situations such as in- situ slippage.


Warning :

Please stick or fix the magnetic strip to the ground, lifting or loosening may affect the function of the virtual wall,even cause other security incidents!


● Main brush cleaning

※ It is recommended to clean once a week, replace every 6-12 months


- ▲ The main brush is the main component of the cleaning parts, it can not only roll up the garbage, but also clean the dust on the floor. Regularly clean the rolling brush can keep the cleaning ability of the device.




1. Pull up the buckle



2. Pull up the main brush



3. Clean up the stains and tangled hair on the brush




4. Replace the rolling brush and fasten the buckle

Maintenance


● Side brush cleaning

※ It is recommended to clean up every 1-2 weeks

- ▲ The side brush mainly collects garbage and sweeps the corners, which can widen the cleaning range, but it is easy to wrap the hair and cause the side brush to work abnormally. The side brush should be cleaned regularly.



1. Turn over the main device, use a cleaning tool to wipe the bristles and clean the wrapped hair.




2. If the root of the brush is wrapped by the hair, it cannot be removed. Please remove the edge brush before cleaning it.


● Universal wheel cleaning

※ It is recommended to clean up every 2~3 weeks

- ▲ The universal wheel is an important part of controlling the direction of the main device. If it is not cleaned regularly, it will affect the movement and steering of the robot.




1. Use a rag to wipe dirt off the universal wheel.




2. If the hair wrapped around the wheel and cannot be removed, use a flat-blade screwdriver to lift the universal wheel and clean it.

Dust bin / Filter cleaning

- ※ It is recommended to clean the dust box before each cleaning.
- ※ Filter It is recommended replace every 3-6 months.
- ▲ The dust bin is made of high- strength transparent resin, which is environmentally- friendly. Please check the dust bin before cleaning every time, and clean the dust bin in time to ensure the cleaning effectiveness.
- ▲ The device use HEPA filter, the filtration effect on particles larger than $0.3\ \mu\text{m}$, after long time using the device, a lot of dust will stick on the filter, which will affect the cleaning effectiveness.




Press the buckle, then pull out the dustbin ;




Take out the filter assembly from the side of the dustbin;




Pour dust into the trash can;



Pinch the cloth strip on the filter to remove the filter;



Tap the filter on the edge of the trash can to clean the dust;




Put the filter back into the dustbin, then put the dustbin into the cleaner and fix it well;



The filter should be cleaned regularly to avoid the filter blocking which will affect the cleaning effectiveness.


Water tank and mop

● Install water tank and mop




1 Power off

Power off the main device first




2 Wet the mop

Soak the mop, then squeezed excess water.




3 Paste the mop

Paste the dry mop on the water tank, fasten the elastic band, and smooth the mop with your hand.



4 Fill the tank with water

Open the water tank plug, slowly inject water and close the soft rubber plug



5 Install the water tank

Put the water tank flat on the ground, hold the host to make the tail close to the water tank, can be adsorbed tightly together;

Warning


- Please remove the water tank before start charging.
- When using wet mop, please inject water and clean the mop after cleaning.
- When using a wet mop, be careful to prevent water from flowing into the main device, causing damage or other accidents.

Note:


1. The robot and the water tank are attached by magnets. When the robot is working without water tank, the magnet at the bottom of the robot can pick up iron scraps from the ground, small metal objects such as screws and needles, keep the kids and pets safer at home.
2. Please clean the adsorbed on the magnet before start cleaning, maintaining the robot or before installing the water tank.
3. Do not use the wet mop on the wooden floor and carpet to avoid damage to the wooden floor or carpet.

Water tank and mop


Maintenance of water tank and mop




- 1** Turn off the power, lift the main engine, turn down and take out the water tank;




- 2** Take off the mop




- 3** Clean the mop with water



- 4** Pour out the remaining water in the tank



- 5** Wipe the water on the tank



- 6** Dry the mop and water tank for next use

※ To ensure the continuous and effective cleaning ability of the device, please remove the water tank and clean up the mop regularly.

Troubleshooting & Accessories List

Troubleshooting

▲ Troubleshoot the robot when the following abnormalities occurs.

Problems		likely cause and solution for reference
1	Can not power on	The power switch of the robot is not turned on, please turn it on first; Maybe battery is too low, please charge the robot first.
2	Abnormal noise when the device is cleaning	There maybe something stuck in the brush, please clean the brush ;
3	Red light + Du twice	The dust box test may not be detected. Please check if the dust box is installed correctly.
4	Red light + Du triple	The anti-drop sensor may be blocked or left floating, please move to a new location to start
5	Red light + Du Quatic	The bumper may get stuck, please clean it then restart;
6	Blink Red + Du twice	The side brush may get stuck, please clean it then restart;
7	Blink Red + Du Triple	The main brush may get stuck, please clean it then restart;
8	Blink Red + Du Quatic	The driving wheel may get stuck, please clean it then restart;
9	Blink Yellow + Du Triple	Battery low, please charge the robot;

Parameters

Robot	
Working voltage (V)	14.8V
Rated power (W)	30W
Adapter	
Rated input voltage (V)	100 - 240V ~ 50/60Hz
Rated output voltage (V)	DC 19V 1.2A
Charging base	
Rated output Voltage(V)	DC 19V
Rated output Current(A)	1.2A

※ Due to the continuous optimization of the product, the company reserves the right of changing the technical or design of the product, the final interpretation right belongs to the company.

