

RXRL-LCD

1. Frequency Range

From 940 to 960 MHz (in RXRL-LCD.940 variant for US and Canadian market).
Frequency programmability from software, with 5 kHz steps

2. Power Instructions

- 1) Switch on the receiver by putting the selector on the position “I” (on) the switch situated on the panel, and switch it on thanks to the switch situated on the front panel.
When turned on, the LCD display shows the “Main Menu” with the graphic representation of the instantaneous modulation and the instantaneous reading of the received signal levels:



Menu 1

The vertical bars near the title “Mod” indicate the progress of the modulation in real time; the hachured bar indicates the maximum 75 kHz nominal modulation level (100%).

- 2) In order to change the instantaneous reading of the received signal set, select with the push-button  the line which corresponds to the power and keep the **ENTER** button pressed until you enter the modify mode.



Menu 1

The bottom line gives the instantaneous reading of the received signal level on analog scale, while the bar indicates the squelch level set. In order to increase the level, keep the  button pressed, in order to reduce it press the  button. Once you reach the desired level, press **ENTER** to confirm and exit the default menu. Note that the set value is stored anyway, so if you press **ESC** or if you leave the timeout time without pressing a button, the power will remain to the last set level. In case the RF signal is lower than the squelch threshold set, the receiver outputs are placed in MUTE and BNC interlock is closed.

3. Tuning Instructions

- 1) Power on the receiver and ensure that the **ON** light turns on.


When turned on, the LCD display shows the “Main Menu” with the graphic representation of the instantaneous modulation and the instantaneous reading of the received signal levels (Menu 1):



Menu 1

- 3) When the display is off, touching any key will turn on backlighting.

When the display is on, pressing the **ESC** button from the default menu (menu 1) calls up the selection screen (menu 2), which gives access to all other menus:




Menu 2

Select “Set Menu”, then press **ENTER** to confirm.

- 2) Set a new frequency value and then press the **ENTER** button to confirm your selection; the receiver unlocks from current frequency (the **LOCK** LED turns off) and will lock to the new operating frequency (**LOCK** turns back on again).

If you press **ESC** or let the preset time time out, the previous frequency setting is retained.



Menu 3

4. User Manual

User manual and technical annex are attached in the main folder.

R.V.R. Elettronica s.r.l.
Via del Fonditore, 2/2c - 40138 Bologna-Italy
P.Iva - Vat no. IT 02124450376
Tel. +39 051 6010506 - Fax +39 051 6011104
Certified - UNI EN ISO 9001
Valentino Biavati
CEO / President