

This is a legacy product document supported by Resideo. It is no longer manufactured



C7189A Wall Mount Temperature Sensor

INSTALLATION INSTRUCTIONS

APPLICATION

The C7189 Wall Mount Temperature Sensor provides the input required by the PC8900 Perfect Climate® Comfort Center with the W8900 Remote Module to sense temperature in indoor air spaces.

SPECIFICATIONS

Operating Ambient Temperature Range:

40 to 95°F (4.4°C to 35°C)

Humidity Setting Range:

None

Operating Relative Humidity:

5% to 95% noncondensing

Finish:

White

Dimensions in Inches (millimeters):

2 3/4 (70) width x 4 5/8 (117) height x 1 1/16 (27) depth

Accessories:

202689A Mounting Plate Assembly used to cover marks left on the wall by the old thermostat

INSTALLATION

When Installing this Product...

- 1 Read these instructions carefully. Failure to follow them could damage the product or cause a hazardous condition.
- 2 Check the ratings given in the instructions and on the product to make sure the product is suitable for your application.

- 3 Installer must be a trained, experienced service technician.
- 4 After installation is complete, check out product operation as provided in these instructions.



CAUTION

Disconnect power supply before connecting wiring to prevent electrical shock or equipment damage.

Location and Mounting

Locate the C7189 Wall Mount Temperature Sensor where the setting will not be subjected to tampering.

- 1 Choose a location for the sensor on an inside wall about 5 ft (1.5 m) above the floor. A horizontally mounted standard 2 x 4 in. (51 x 102 mm) junction box can also be used at the selected location for the C7189.
- 2 Be sure that the wire distance between the C7189 and the W8900 does not exceed 200 feet.
- 3 Make sure that there is good air circulation at average temperature at the chosen location. Avoid the following locations because they can introduce errors in sensor measurements. See Fig. 1:
 - Hot areas caused by:
 - Concealed pipes or ducts.
 - Drafts from fireplaces or other heat sources.
 - Convection or radiant heat from the sun or electrical equipment.
 - Cold areas caused by:
 - Concealed pipes or ducts.
 - Drafts from windows and doors.
 - Unheated areas on the other side of the wall location.
 - Dead air areas:
 - Behind doors, furniture and curtains.
 - In corners and alcoves.
- 4 Mark the area on the wall where the C7189 Sensor or junction box will be mounted.



- 5 Run cable to a hole at the selected wall location. Pull approximately 3 inches of wire through the opening. Color-coded, 18 gauge thermostat wire is recommended.

NOTE: If the old thermostat has left marks on the wall that are not covered by the C7189, order part no. 202689A Mounting Plate Accessory to mount between the wall and the C7189.



RECYCLING NOTICE

If this control is replacing a control that contains mercury in a sealed tube, do not place your old control in the trash.

Contact your local waste management authority for instructions regarding recycling and the proper disposal of any control containing mercury in a sealed tube.

If you have questions, call Honeywell Inc. at 1-800-468-1502, Monday through Friday, 7:00am to 5:30pm.

Wiring



CAUTION

Keep wiring at least one foot away from large inductive loads such as motors, line starters, lightning ballasts, and large power distribution panels. Failure to follow these wiring practices can introduce electrical interference (noise), which can cause erratic system operation. Use shielded cable to reduce interference when rerouting is not possible. Ground the shielded cable to the GND terminal on the W8900.

Important

Erratic temperature readings from a sensor can occur as a result of any of the wiring practices described below. These practices must be avoided to assure proper operation. Use shielded cable to reduce interference if rerouting of sensor wiring is not possible.

- Do not route temperature sensor wiring with building power wiring, next to control contactors or near light dimming circuits, electric motors or welding equipment.
- Avoid poor wiring connections.
- Avoid intermittent or missing building earth ground.




CAUTION

Disconnect power supply before connecting to wiring to prevent electrical shock or equipment damage.

Wiring must comply with applicable codes, ordinances and regulations.

- Wire the C7189 Sensor to the W8900 Remote Module terminals S1 and S. For an example of general wiring of the C7189, see Fig. 2.
- Push excess wire back into the hole. Plug the hole using nonhardening caulk, putty or insulation to prevent drafts from affecting performance.
- Remove C7189 cover.
- Mount the C7189 to the wall or junction box using the screws and anchors provided.
- Level the C7189 for appearance only. Device will function properly even when not level.
- Install C7189 cover.



M4476

Fig. 1. Typical Location for C7189 Sensor.




Fig. 2. Wiring Diagram for the C7189 Sensor to the W8900 Remote Module.

OPERATION

The C7189 Wall Mount Temperature Sensor converts room temperature to a resistance that the controller can interpret. The C7189 has a negative temperature coefficient (NTC), which means that the resistance decreases


as the temperature increases. Fig. 3 shows how sensor resistance decreases by 19 ohms per degree Fahrenheit.

The C7189 can be used to control as one remote sensor, as a temperature averaging network with the PC8900, or with multiple C7189 Sensors connected as shown in Fig. 2.

CHECKOUT

Allow the C7189 Wall Mount Temperature Sensor to soak in the air moving through the room for a minimum of five minutes before taking a resistance measurement.

With an accurate thermometer ($\pm 1^{\circ}\text{F}$ [0.5°C]), measure the temperature at the sensor location, allowing time for the thermometer to stabilize before reading. Remove one wire from one of the C7189 wiring terminals. Use an ohmmeter to measure the resistance across the sensor. Then verify sensor accuracy with the temperature/resistance curve of Fig. 3.



CALIBRATION

The C7189 Remote Sensor is calibrated at the factory and cannot be recalibrated in the field.

ROOM TEMPERATURE		OHMS OF RESISTANCE
°F	°C	
46	7.8	2131 to 2094
48	8.9	2094 to 2057
50	10.0	2057 to 2019
52	11.1	2019 to 1982
54	12.2	1982 to 1945
56	13.3	1945 to 1908
58	14.4	1908 to 1871
60	15.6	1871 to 1833
62	16.7	1833 to 1796
64	17.8	1796 to 1759
66	18.9	1759 to 1722
68	20.0	1722 to 1685
70	21.1	1685 to 1647
72	22.2	1647 to 1610
74	23.3	1610 to 1573
76	24.4	1573 to 1536
78	25.6	1536 to 1499
80	26.7	1499 to 1461
82	27.8	1461 to 1424
84	28.9	1424 to 1387
86	30.0	1387 to 1350
88	31.1	1350 to 1313
90	32.2	1313 to 1275
92	33.3	1275 to 1238
94	34.4	1238 to 1201
96	35.6	1201 to 1164
98	36.7	1164 to 1127
100	37.8	1127 to 1089

M6357

Fig. 3. C7189 Sensor Resistance vs. Temperature Performance Characteristics.

Honeywell

Home and Building Control
Honeywell Inc.
1985 Douglas Drive
Golden Valley, MN 55422

Home and Building Control
Honeywell Limited-Honeywell Limitée
740 Ellesmere Road
Scarborough, Ontario
M1P 2V9

Helping You Control Your World

QUALITY IS KEY