




RAYCHEM

SSR Modules certified for hazardous area Zone 2

Installation Instruction for 32 Amp SSR and 63 Amp SSR Modules



APPROVALS / CERTIFICATION

CSANe 20ATEX3280X CSAE 21UKEX3630X
Ex II 2G Ex ec IIC T4 Gc



IECEX CSA 20.0010X
Ex ec IIC T4 Gc



Class I, Div 2, Groups A,B,C,D;
CSA22CA80090563X
EX ec IIC T4 Gc
Class I, Zone 2; AEx ec IIC T4 Gc
TYPE 4X

DESCRIPTION

The nVent RAYCHEM Solid-state relay (SSR) assembly is suitable for ATEX / IECEx / UKEx Zone 2.

Control input: 4-32 VDC supplied by an external device (typically a controller).

Enclosure Type: Type 4X, IP66

Ingress Protection: IP66

Ambient Operating Temperature Range: -40°C to $+60^{\circ}\text{C}$ *

*for 32A rated modules max. ambient temperature is $+40^{\circ}\text{C}$ at 32A and $+60^{\circ}\text{C}$ at 16A

*for 63A rated modules max. ambient temperature is $+40^{\circ}\text{C}$ at 63A and $+60^{\circ}\text{C}$ at 32A

TOOLS REQUIRED

- Drill, drill bits
- Diagonal cutters
- Wire strippers
- $\frac{3}{4}$ in. NPT knockout punch
- Channel lock pliers

PARTS

Part	Quantity	
	32 Amp SSR	63 Amp SSR
Lock Ring (A)	1	2
Sealing Gasket (B)	1	2
Heat Sink/SSR assembly (C)	1	1

VERSIONS AND RATINGS OF THE SSRs:

List of items	Description
SS3-EX	Standard 32A 277 Vac module, 6 mm ² cable
SS3Z-EX	Standard 32A 277 Vac module, 6 mm ² cable, Low Smoke Zero Halogen
SS3L-EX	Standard 32A 277 Vac module, 10 mm ² cable
SS3LZ-EX	Standard 32A 277 Vac module, 10 mm ² cable, Low Smoke Zero Halogen
SS3R-EX	Standard 32A 277 Vac, high in-rush module, 6 mm ² cable
SS3RZ-EX	Standard 32A 277 Vac, high in-rush module, 6 mm ² cable, Low Smoke Zero Halogen
SS3RL-EX	Standard 32A 277 Vac, high in-rush module, 10 mm ² cable
SS3RLZ-EX	Standard 32A 277 Vac, high in-rush module, 10 mm ² cable, Low Smoke Zero Halogen
SSH3-EX	High voltage 32A 690 Vac module, 6 mm ² cable
SSH3Z-EX	High voltage 32A 690 Vac module, 6 mm ² cable Low Smoke Zero Halogen
SSH3L-EX	High voltage 32A 690 Vac module, 10 mm ² cable
SSH3LZ-EX	High voltage 32A 690 Vac module, 10 mm ² cable Low Smoke Zero Halogen
SSH6L-EX	High voltage, 63A 690 Vac module, 10 mm ²
SSH6LZ-EX	High voltage, 63A 690 Vac module, 10 mm ² Low Smoke Zero Halogen



WARNING:

The purchaser should make the manufacturer aware of any External effects or Aggressive substances that the equipment may be exposed to.

Fire Hazard: The contents of the component kit must be installed correctly to ensure proper operation and to prevent unsafe conditions. Be sure to read and understand these important warnings and carefully follow all the installation instructions.

Be sure all personnel involved in installation, servicing, and programming are qualified and familiar with electrical equipment, their ratings and proper practices and codes. Multiple voltages and signal levels may be present during the installation, operation, and servicing of this product. Do not power the product until the safety provisions outlined in the controller manual have been observed.

Many wiring configurations will use more than one power source, and all must be de-energized prior to performing any maintenance on a controller circuit.

IMPORTANT:

- Maintain proper spacing between SSR assemblies
- Tighten the lock ring to maintain the weatherproof seal, but not so much as to strip the threads or crack the hub. Apply 8.13 Nm when tightening the locknut.
- Ensure the ground wire is installed in the grounding bar.
- Strip all wires the proper length for the terminals being used.
- Wire the SSR assemblies following the included diagrams.
- Misuse and/or false installation will impair the protection provided by the equipment.

CONDITIONS OF SAFE USE

The nVent RAYCHEM Solid-state relay (SSR) assembly is suitable for ATEX / IECEx / UKEx Zone 2. The equipment shall only be used in an area of at least pollution degree 2, as defined in EN/IEC 60664-1.

1. This equipment has a non-conducting enclosure and may generate an ignition-capable level of electrostatic charge under certain extreme conditions. The user shall take the necessary precautions to minimize the risk from electrostatic discharge. For example: control of the environmental humidity of the installation to minimize the generation of static electricity; protection from direct airflow that could cause a transfer of charge to the surface of the equipment; suitable electrical bonding and earth provisions; cleaning of the equipment only with a damp cloth
2. The equipment shall be protected from exposure to UV light
3. The equipment shall be connected in compliance with IEC 60079-14 to an enclosure providing and maintaining a degree of protection of at least IP54 according to IEC 60079-0 and IEC 60079-7 requirements. Field wiring shall be terminated in this enclosure using appropriate connection methods in accordance with IEC 60097-7
4. For the installation in North America, the equipment shall be connected to an enclosure which shall provide and maintain a degree of protection of at least IP54 according to CSA/UL 60079-0 requirements and TYPE 4X. The "flying leads" supplied for field wiring shall be terminated in this enclosure using appropriate connection methods in accordance with CSA/UL 60079-7
5. The equipotential bonding of the equipment relies upon the factory installed cables which must be connected in accordance with the user instructions
6. Install per local electrical code
7. For the installation in North America, the equipment shall be connected to a controller which has been evaluated to UL 508/CSA 14 or equivalent

INITIAL INSPECTION

Inspect the packaging for damage. If the packaging or cushioning material is damaged it should be kept until the contents of the shipment have been verified for completeness and the equipment has been checked mechanically and electrically. Procedures for configuring and operating the heat trace controller are given in the manual of the controller. If the shipment is incomplete, there is mechanical damage or a defect, or the switch does not pass the electrical performance tests, notify the nearest nVent representative. If the packaging is damaged, or the cushioning material shows signs of stress, notify the carrier as well as your nVent representative. Keep the shipping materials for the carrier's inspection.

 **WARNING: Many wiring configurations will use more than one power source, and all must be de-energized prior to performing any maintenance on a controller circuit.**


 **AVERTISSEMENT: De nombreuses configurations de câblage utilisent plus d'une source d'alimentation, et l'ensemble de celles-ci doivent être mises hors tension avant d'effectuer toute opération de maintenance sur un circuit de contrôleur.**



- This device is OPEN type equipment that must be used with a suitable end-use system enclosure, the interior of which is accessible only through the use of a tool. This enclosure must provide ingress protection to the level of IP54 or greater, and be compliant with the requirements of CAN/CSA C22.2 No. 60079-0 or be certified as having protection method of Ex ec, Ex dc, or greater. The suitability of the enclosure is subject to investigation by the local Authority Having Jurisdiction at the time of installation.
- Wiring to or from this device, which enters or leaves the system enclosure, must utilize wiring methods suitable for Class I, Division 2 and Zone 2 Hazardous Locations, as appropriate for the installation. :


Mounting Procedures

1. Follow this mounting hole pattern to maintain the spacing required for proper heat dissipation; also note the minimum mounting height from the top of the enclosure.



2. To mount the SSR at the outside of the panel drill a hole with the dimensions as marked on the drawing. Make sure that the notch is at the bottom of the hole drilled.



If you are adding a multi pole circuit, you must place all on the same side of the enclosure (due to wire length).



3. Install the heat sink assembly C as shown. Make sure the gasket B is between the enclosure and the switch, and the boss on the plastic hub fits in the notch at the bottom of the knockout hole.

After the SSR assembly is positioned in the hole, carefully feed the lock ring A over the wires, and thread onto the hub finger tight.

Using channel lock pliers, tighten the ring enough to maintain a weatherproof seal, but not so tight as to crack the plastic hub. About ¼ turn past finger tight should be adequate.



POWER CONNECTIONS

One SSR Application

The SSR module has two control wires (14-16 AWG), 2 black wires (6 mm² / 10 mm²) and one yellow/green wire (6 mm² / 10 mm²) connected to it. Connect the wiring as follows:

1. Connect the yellow/green earth wire to the earth bar in the panel
2. Connect the two black wires to the L1 incoming and L1 outgoing terminals in the panel
3. Connect the attached male control wire to loose control wire (is included in package) and terminate these into the SSR output terminals of the controller. BE AWARE: Yellow wire is +V, blue wire is -V

Remark: It is allowed to shorten all cables to length. See **Figure A** for more information.

Two pole SSR Application

A two pole SSR application will be controlled via one control signal coming from the controller. As such, the control cable shall be connected in parallel. Due to limitation in length of the control cables both SSRs need to be placed above or next to each other. The SSR module wires consist of the following: two control wires (14-16 AWG), 2 black power wires (6 mm² / 10 mm²) and one yellow/green earth wire (6 mm² / 10 mm²). Connect all wiring as follows:

1. Connect the yellow/green earth wires to the earth bar in the panel
2. Connect the two black wires of the first SSR to the L1 incoming and L1 outgoing terminals in the panel
3. Connect the two black wires of the second SSR to the L2/N incoming and L2/N outgoing terminals of that same circuit in the panel

4. Connect the attached male control wire to loose control wire (is included in package) and terminate these into the SSR output terminals of the controller. BE AWARE: Yellow wire is +V, blue wire is -V
5. Connect the female control connector of the first SSR to the male connector of the second SSR.

Remark: It is allowed to shorten all cables to length. See **Figure B** for more information.

Three pole Switch Application

The three SSR assembly application follows the same instructions as for the two SSR application, with the addition of one more SSR assembly. After the first two SSR's are wired (as per Figure B), add the third one the same way. Make sure to plug the two mating connectors together (from SSR 2 & 3) to daisy chain the control signals to the last SSR assembly. The wire sizes are equal as described in the one pole and two pole switch application (control wires 14-16 AWG, black power wires 6 mm² / 10 mm² and yellow/green earth wire 6 mm² / 10 mm²).

Note: Always be sure that all terminals are adequately tightened according to the terminal manufacturer's specification. A loose terminal can cause arcing and damage to the terminal or incorrect operation of the controller.

Note: Make sure that power terminals are re-tightened several days after installation. Stranded wire will tend to compress when initially installed, therefore the terminals should be checked for tightness several times after the system is installed to ensure that a good connection is maintained. Be certain to use the proper size screwdriver for the terminal blocks to minimize the chance of damage to the terminals.

INITIAL POWER UP

Note: Ensure the SSR is rated for the connected load before applying power to the controller. If the total load is not known, disconnect load prior to applying power to the controller. The load should only be connected once controller has been suitably programmed for safe and correct operation.

CAUTION: DO NOT DISCONNECT WHILE CIRCUIT IS LIVE UNLESS AREA IS KNOWN TO BE NON-HAZARDOUS.

AVERTISSEMENT: RISQUE D'EXPLOSION. NE PAS DEBRANCHER TANT QUE LE CIRCUIT EST SOUS TENSION, A MOINS QU'IL NE S'AGISSE D'UN EMPLACEMENT NON DANGEREUX.






Figure A: Wiring connection single SSR unit




Figure B: Wiring connection double SSR unit





Contact your nVent representative for service and a Return Authorization number if required

North America

nVent
899 Broadway
Redwood City, CA 94063
United States
Tel +1 800 545 6258
Fax +1 800 527 5703
thermal.info@nVent.com

Europe, Middle East, Africa

nVent
Romeinse straat 14
3001 Leuven
Belgium
Tel +32 16 213 511
Fax +32 16 213 604
thermal.info@nVent.com

Asia Pacific

Tel +86 21 2412 1688
Fax +86 21 5426 3167
cn.thermal.info@nVent.com

Latin America

Tel +1 713 868 4800
Fax +1 713 868 2333
thermal.info@nVent.com



Our powerful portfolio of brands:

CADDY ERICO HOFFMAN RAYCHEM SCHROFF TRACER

©2022 nVent. All nVent marks and logos are owned or licensed by nVent Services GmbH or its affiliates. All other trademarks are the property of their respective owners.
nVent reserves the right to change specifications without notice.

RAYCHEM-IM-EU1707-ATEXIECEXZN2SSRMod-EN-2207

nVent.com/RAYCHEM | 8

