



Instruction Manual

The IRB-4X thru beam photoeye is an external entrapment protection device type B1, non-contact sensor for use with automatic gates and doors. The photoeye provides a signal to the gate or door operator that the beam is or is not obstructed. The IRB-4X operates up to 115 feet in a weather-proof NEMA 4X housing. A red alignment indicator on the receiver provides status information at a glance, making set-up and alignment easy.

Cautions and Warnings



This product is an accessory or part of a system. Install the IRB-4X according to instructions from the gate or door operator manufacturer. Comply with all applicable codes and safety regulations.

The IRB-4X is not UL compliant. This photoeye will not work with gate or door operators that require monitored safety devices.

Specifications


Operating Range	Up to 115 ft. (35 m)
Power	12-24 VDC/AC
Current Draw of Transmitter	37 mA
Current Draw of Receiver	23 mA standby, 17 mA detect
Surge Protection	Thermal fuse
Relay Output Configuration	Form C contacts (NO, COM, NC)
Relay Contact Rating	1 A at 24 VDC / 120 VAC
Operating Temperature	-40° to 170°F (-40° to 77°C)
Dimensions (L x W x H)	2.3" (57 mm) x 2.6" (65 mm) x 3.7" (94 mm)
Environmental Rating	NEMA 4X

Ordering Information

- IRB-4X KIT Thru beam photoeye kit, includes transmitter, receiver, protective hoods, and sunshield
- IRB-HD-SET Gold anodized aluminum protective hoods
- IRB-SH-SET Gray powder-coated steel protective hoods




Board Diagram



Installation

1. Knock out the perforated hole on the transmitter and receiver housing that will be used to wire through. Be careful not to damage the electronic circuit board when knocking out the hole.
2. Connect 12-24 VDC/AC power to the "Power Input" terminals on the transmitter (marked "TX") and receiver (marked "RX"). The power input terminals are not polarity sensitive.
3. Install the optional sunshield on the receiver as shown to the right in case of solar interference or cross talk.
4. Connect the Common (COM) to the control input terminal per the operator manufacturer.
5. Connect either the Normally Open (NO) or Normally Closed (NC) as needed to the control input terminal per the operator manufacturer.
6. Adjust the sensitivity potentiometer as needed by turning counter clockwise to increase gain. Use the minimum sensitivity setting needed to achieve reliable detection.



7. Make sure the covers are attached and closed tight using all four plastic screws provided. The wiring to the enclosure must enter via UL listed watertight fitting such as a strain relief or watertight conduit connector.

8. Verify that the IRB-4X transmitter and receiver are aligned and apply power.

LED Indicators	
Green transmitter LED on	Power
Green receiver LED on	Power
Red receiver LED on	Beam blocked or not aligned

9. Place an obstruction (ex. hand) between the IRB-4X transmitter and receiver. The red LED on the receiver will turn on. Check the operator control board and verify that the safety input is recognized by the operator. Test the beam with an obstruction between the transmitter and receiver at multiple distances to confirm proper operation.

10. Remove the obstruction and red LED will turn off.

TIP:

- If IRB-4X is aligned but not detecting an obstruction, consider slowly reducing the sensitivity (clockwise) on the receiver until the obstruction is detected. This may be applicable for installations with a detection zone of less than 20 ft.
- On some variable frequency drives and noisy installations, it may be necessary to connect the bottom right mounting hole labeled "Earth Ground" to a wire connected to earth ground. **Do not connect unless necessary.**

Troubleshooting

Symptom	Possible Cause	Solution
Does not detect obstruction	Sensitivity is too high	Decrease sensitivity potentiometer clockwise.
	Signal is reflecting off another surface	Check area for highly reflective surfaces.
Receiver red LED on continuously, indicating an obstruction when one is not present	Sensitivity is too low	Increase sensitivity potentiometer counter - clockwise.
	Transmitter does not have power	Check power source of transmitter.
	Receiver does not "see" transmitter	Make sure transmitter and receiver are aligned.
Receiver activates but does not transmit signal to operator	Faulty connection between receiver and operator control input	Verify all wires and terminal connections.
Output relay chatters constantly between open and close	Interference	See step 10 under Installation and check if any reflective surfaces could be sending a signal into the receiver sensor.

Warranty

EMX Industries, Inc. products have a warranty against defects in materials and workmanship for a period of two years from date of sale to our customer.

