

 MILAGROW *iMap Max Pro*
Self Cleaning, Wet & Dry **Robotic** Vacuum Cleaner

User Manual

▲  Please read this manual carefully before using this product and keep it properly.



1. Safety Instruction

1.1 Usage Notice


Please follow these basic safety precautions before using the product:

- *Read all the instructions in the manual carefully and follow the instructions to use the product.
- *Keep the manuals in a safe place so that you can check them later.
- *If you need to transfer the product to a third party, please attach the manuals along with the product.
- *Any operation that does not conform to instructions of the manual may result in serious personal injury or damage to the product itself.


1.2 About Product Safety Precautions



- ⚠ This product can only be used with the power cable and wash base delivered. Failure to do so may result in damage to the product, electric shock, or fire caused by high voltage.
- ⚠ If the machine, wash base and accessories of this product are found to be damaged, please do not use this product and contact our customer service department.



- ⚠ Please unplug the power before maintenance.
- ⚠ Do not touch the power plug or product when your hands are wet, or this may result in electric shock.
- ⚠ If the power cable is damaged, it must be replaced to avoid danger.




- ⚠ Do not allow clothing or any part of your body (hair, fingers, etc.) to get caught in the middle brush or wheel of the machine, the mopping board leverage area, or the wash base scraper area, or this may result in personal injury.



- ⚠ Do not place the product near fire or near flammable, explosive, or corrosive materials.
- ⚠ If the manuals is missing, please contact your local dealer or call the customer service hotline for an electronic version manuals.

⚠ Precautions



This product can only be used indoors.




Do not use to vacuum sharp objects, such as glass sheets, nails, etc., in case to avoid damage to the product.




Do not use the product in a damp or flammable, explosive, corrosive environment.



Please avoid using the product in a suspended environment without a protective fence, in case to prevent the machine from in case accidentally falling and causing personal injury.



Please unplug the power adapter when the machine is left unused for a long time.



Please turn o the power when the machine will not be used for a long time, in case to avoid damage to the battery. Please use manufacturer's original battery.

1.3 About Child Safety



Children under the age of 8 are not allowed to operate this product. Persons with physical, sensory, intellectual disabilities or lack of relevant experience and knowledge cannot clean or repair the product without any care or instructions or being unfamiliar with the hazard. Children are not allowed to play the packaging bags, or it may cause suocation.

1.4 About Battery



1. This product is limited to the manufacturer's baery.
2. The battery must be removed when the machine is discarded.
3. If you need to replace the battery, please contact our customer service department. If you replace the battery with the wrong model, it may cause a safety accident.
4. If the battery leaks, be careful not to let the liquid stick to the skin or clothing. If so, please wipe it with a dry cloth immediately and send it to the recycling site or designated maintenance point.
5. Please dispose of the old battery of the product properly. The battery contains hazardous substances that are harmful to the environment. Please follow local environmental regulations and place it at the designated recycling site.

1.5 Ground Material for Product Cleaning

The product is designed for :



Wooden floor




Ceramic tile




Short-hair carpet

2.Packing Composition


2.1 Product and Accessories




Machine




Wash Base



Power Cable



Manuals



Side Brush



Middle Brush



Mopping Fabric



Non-Disposable
Dust Bag




Measuring Cup




Knife & Brush

2.2 Product View


Upper view of the machine




Boom view of the machine



View of the wash base




3. Installation



1. Please place the wash base on a flat floor against the wall. Before placing the wash base, please clean dust and other debris on the ground in the placing area. Press firmly on the wash base to make it attached to the ground and connect the power cable. To connect the power cable to power port of the wash base after plugging the same in power.


Note: The wash base should not be placed on the carpet. It is recommended to place it in a fixed position. Do not manually move the wash base during the cleaning process. Otherwise, the machine will not be able to find and return to the wash base.



1. Place the wash base on a flat floor against the wall. There should be no obstacle in the area of 1 meter in front of the base and 0.5 meter in both left and right sides, which may prevent the machine from returning to the wash base.
2. Connect the power cable to the wash base. Please bundle up cable which may entangle machine during its work.

4. Usage Instruction

4.1 Manual Operating



Note: When using the new mop for the first time, please wet the mop completely by hand.

Note: It is recommended to clean this box once a week to prevent water leakage.

Standby

Press and hold the power button for 3 seconds until the light belt is on, the machine enters the standby status.

Shut Down

Press and hold the power button for 3 seconds to shutdown normally, or press and hold the power button for 15 seconds to forced shutdown.

Cleaning on specific point

Press and hold the function button for 3 seconds to enter cleaning on specific point mode in-situ.

Automatic Charging

When the machine is in standby status, press the function button once to enter charging mode.

Automatic Cleaning

When the machine is in standby state, press the power button once and the machine will start to clean automatically.

Forced Power Cut

Stab the reset hole for 3 seconds to cut power.


Tips:

The product is self-routed during its work . If it is moved manually, the machine will reset route and re-clean the cleaned area. To ensure work Efficiency, please do not move the machine.


This product may have a short stay during work, trying to traversing uncovered area or to reset route. Please wait patiently. How often it stops or how long it stays depends on complexity of actual home environment.

4.2 Charging

4.2.1 Charging Manually



1. Charging by using the wash base: Connect the power cable to the wash base firstly, and place the machine on the wash base for charging (the light is orange during charging).



2. Charging by using APP

Firstly connect the machine to the app, then tap "back to charge" button.


The machine will automatically find the wash base for charging within valid range.

Notes:

1. If the machine stops working and stay away from the wash base for more than 10 minutes, it will automatically enter sleep mode.
2. When the battery is lower than 5%, the machine will automatically shut down.



4.2.2 Charging Automatically



Automatic charging:

When the battery is lower than 15%, the machine will automatically return for charging during its work and continue working after the battery is charged to 80%.

4.3 APP Guidance

Overview

APP is an application developed based on Android or iOS to control added devices.

This document mainly guides fresh user to operate the APP, elaborate operation steps and attentions.

APP installation

Device system requirements: Android 6.0/iOS 10+ or above. By scanning the QR code below or searching for "Venii" in Android app market or Apple Store to download and install the APP.

APP file name: Venii

When installation is completed in due course, you can find the corresponding indicator icon in application list.



Android/iOS compatible download code.

Connecting WiFi


1. To connect WiFi 2.4G ONLY in your home.
2. Additional seings requirement for Xiaomi or Huawei brand cell phone after connecting WiFi successfully.

Xiaomi brand: Seings → WLAN Advanced seings → turn o WLAN assistant


Huawei brand: Seings → Wireless & networks → WLAN → seings on the upper right corner → WLAN+ → turn o WLAN+



4.3.1 Add Device



Follow instructions to login.




Tap "Add Venii".




Power on the machine and wait until it is initiated.



Press and hold START and FUNCTION button at the same time for 3 seconds after the machine is powered on. The network is self-matching when you hear "Network is reset".



Please input the password of WiFi your cell phone has connected before tapping "Next".



Android

Choose WiFi named "VENII_N1_XXX".

Note to Xiaomi brand cell phone user:

Limited by Xiaomi cell phone system, permission is needed in adding device. Please follow additional instructions below:

Alternative 1: Tap "Allow Once" when dialogue box pops up in the first time, and ignore subsequent popups.


Alternative 2: System settings - Permissions - APP permissions - Venii, to allow WiFi permission.






iOS

Tap "To connect" to connect cell phone's WiFi with device.




iOS


Cut back to Venii App page after connecting WiFi named "VENII_N1_XXX" successfully.




Wait until the seing is completed.



You may name the machine after connecting successfully.




The device will show on device management page once it is added.



More thoughtful seings can be found on main page, and you can check status of the current device.

4.3.2 Main Function




Start cleaning

Enter cleaning page, tap "Start Cleaning" to make the machine clean. You may select vacuuming power and cleaning mode manually.




Clean where you point

To clean where you point, the machine will move to the designated point before cleaning an area of 1.5m*1.5m with the point as center.



Return for washing fabric

Tap "Clean fabric" during work, the machine will return to wash mopping fabric.




Return for charging

Tap "Charge" during work, the machine will return to charge.



Area setting

Tap specific area to enter settings on such area, upon which, the machine will work in line with the settings when entering into such area.



Scheduled cleaning

To add scheduled cleaning in settings on cleaning page, and set cleaning time and more detailed settings following page indication.

5. Product Maintenance

Scan QR code to enter Milagrow official website .

Check tutorial videos or download an electronic manuals.

Learn how to maintain the product.



6. Technical Parameter

Parameter of the machine		Parameter of the wash base	
Working voltage	14.4V---	Output voltage	20V ---
Rated power	55W	Output current	1800mA ---
Battery type	Lithium battery	Input voltage	100V-240V ~ 50/60HZ
Charging time	About 4-5 hours	Working temperature range	0℃-40℃
Working time	90-120 minutes	Working humidity range	≤90RH
Working temperature range	0℃-40℃	Weight	3.5kg
Working humidity range	≤90RH	Size	Φ350mm 360mm 225mm
Noise	60dB		
Weight	3.5kg		
Size	Φ350mm 350mm 150mm		

7. Content of Hazardous Substances in the Product

Part name	Hazardous Substance					
	Plumbum (Pb)	Hydrargyrum (Hg)	Cadmium (Cd)	Hexavalent chromium (CrVI)	Polybrominated biphenyls PBB	Polybrominated diphenyl ether PBDE
Outer casing component	○	○	○	○	○	○
Internal plastic parts	○	○	○	○	○	○
Metal parts	×	○	○	○	○	○
Electrical components and control components	×	○	×	○	○	○
Rechargeable Battery	○	○	○	○	○	○

This form is prepared in accordance with the provisions of SJ/11364

○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in GB/T26572.

×: Indicates that the content of the hazardous substance in at least one of the uniform materials of the part exceeds the limit requirement specified in GB/T26572.

(All parts marked "×" in the table are in compliance with the EU ROHS Directive, or the hazardous substances cannot be replaced due to global technological development limits).



The rechargeable battery used with the product has an environmentally friendly use period of 5 years.



Warranty Card

Username		
Address		
Telephone number		
Postal code		
Product model		
Purchase date		
Invoice number		
Warranty date		
Date	Repairman	Repair records

Product Warranty Description:

1. There isn't man-made damage and the packaging, products and all accessories (including gifts) are complete, the user can apply for refund or replacement within 7 days from the date of purchase. We supply free maintenance within 1 year from purchase date without man-made damage.
2. Users can learn about technical solutions through the product instruction or after-sales service hotline: +91-9953476189
3. When the user has performance failure during normal use, our company provides free maintenance service. In addition, if the national applicable laws and regulations clearly stipulate, our company will comply with relevant laws and regulations.

*We provide filter element valve for free during the warranty period, and recommend to replace it once every 3 months.

4. Paid repair services will be implemented in the following cases:

- 1 Cannot provide valid warranty certificate, such as purchase certificate or product warranty card, the model in the certificate does not match the product, or maliciously damage the warranty card content and product information.

- 2 Damage caused by improper use, maintenance or storage by the user, or dismantle or repair by the person without authorization from our company.

- 3 Damage caused by natural disasters or irresistible factors.

- 4 Failure to use, maintain and adjust according to the requirements of the product manual; for example, faulty operation, entering liquid, improper insertion, scratching, transporting, bumping, use of non-standard adapters, etc.

- 5 Other product failures and damages caused by problems other than the design, manufacture and quality of the product itself.

5. The warranty card is an important certificate for the user to enjoy the warranty service. The user should keep it in a safe place. If it is lost, please call the company's after-sales service hotline to reapply.

6. After the user enjoys the warranty service, our company will record and update the warranty card held by the user. The original is kept by the user, and our company hold the copy which is consistent with the original.

Tips:

Should you have any functional or quality issues during your use of this product, or any comments or suggestions on this product, please contact customer service hotline: +91-9953476189. We are happy to service you at best.

