

Software Manual

Control Panel for Hybrid Units

Models: MU421-P
MU422-P
BW4-P
BW7-P
BF8-P



Software Manual

1. Description	3
2. DISPLAY LAYOUT	4
3. MODES	5
3.1 Power On	5
3.2 Standby	5
3.3 Run Mode	6
3.3.1 Single Booster with high and low pressure	6
3.4 Power Off	7
3.5 Error Mode	7
4. CONTENT OF MAIN- AND SUBMENUS	8
5. OVERVIEW OF MAIN- AND SUB-MENUS	9
5.1 Content of the Info menu	10
5.2 Content of the Errors menu – CAUSE & REMEDY	11
5.2.1 Error List	11
5.3 Content of the Setup sub menu Settings	13
5.4 Content of Setup menu	14
5.4.1 Submenu Language & Units	16
5.4.2 Submenu Supply tank	16
5.4.3 Submenu Communication	17
5.4.4 Submenu Settings	17
5.4.5 Submenu Installation	17
5.4.6 Submenu Reset	17
5.5 Content of Readings	18
6. UPGRADE FIRMWARE	19
6.1 Upgrade display using USB Cable	19
6.2 Upgrade display using IrDA Cable	21
6.3 Upgrade Inverter	23



1. Description

This software manual describes the operation of the control panel of the advanced Single Booster unit (SB and SBHL).


The advanced SB unit is operated via the control panel (see below illustration).

1. OFF
Button (1) switches OFF the unit.
2. ON/STANDBY
Button (2) switches ON the unit.
3. ERROR
Error light indicator (3).
4. NAVIGATION BUTTONS
The four "arrow" navigation buttons (4) are used for navigation in the display menu. Pressing the "OK" button activates the menu and confirms any activity displayed.
5. DISPLAY


2. Display layout

(1)

Example:



(2)



(1)

When switched on the display will show an arrow symbol in the top right corner equivalent to the active navigation buttons on the control board.

The arrows illustrate that it is possible to scroll up and down between the menus. Scrolling to the right makes it possible to enter a value. Set the value scrolling up (+) or down (-) to set the value higher or lower accordingly. Confirm by pressing ok.

(2)


A letter combination for easy reference in connection with service work will appear in the top right corner of the display.



3. Modes

3.1 Power On

The very first time the unit is switched on, we recommend setting date and time in the Setup menu. If date and time is not set, date and time will count from the pre-set



3.2 Standby

The start up display will look as the one below.



Display for SB model with High- and Low pressure - Select either HP or LP using arrows up & down.



3.3 Run Mode


3.3.1 Single Booster with high and low pressure

The following screen displays will appear when the unit is in Run Mode.

Screen display for High pressure unit in Run Mode.
Scroll down to return to STANDARD pressure.

Screen display STANDARD pressure.
Scroll up to choose HP and scroll down to choose LP.


Screen display for Low Pressure unit in Run Mode.
Scroll up to return to STANDARD pressure.



remain in HIGH or LOW pressure Run Mode until otherwise is selected.

5. Overview of Main- and Sub-menus

3.4 Power Off



When the unit is off the display will only show a small dot in the top right corner.

In Off mode it is possible to access all menus without the pump running by pressing the OK button on the panel.

Dot is equivalent to the OK confirm button on the panel.

3.5 Error/Warning



In case of an error, “ERROR” will appear on the display screen.

Press the OFF button to switch of unit.

If the error remains when the unit is switched ON again, please Press right arrow to see current error.

In case of a warning, “WARNING” will appear on the display screen. When a warning is detected the machine will either stop or run with limited performance until the cause of the warning has been improved (eg. inlet pressure).





To see further error/warning list and possible cause and remedy go to section 5.2.

4. Content of Main- and Submenus

The control panel contains the below main menu screen displays.

Scroll between the menus using the navigation buttons.

Each main menu contains submenus which will be described subsequently.






This display view is only ment as an example, SW ID and CT ID shows the current SW version.



<u>1. Info (A)</u> 1 Σ Counters total (AA) 2 Σ Counters trip (AB) 3 Service center(AD) 4 Machine info (AE) ↓ <u>2. Errors (B)</u> <u>3. Setup (C) (default password 6802)</u> <u>1 Password (CA)</u> <u>2 Settings (E)</u> Post run time (ED) Dry run level (EE) Standard pressure (ER) High pressure (EA) Low pressure (EB) Startup method (EY) Pressure start level(EX) Startup delay (EW) Quick Start level (EC) Auto off delay (EZ) Accelleration time (EU) Date & Time (EP) Service text (EJ) Inverter power (EO) Backlight intensity (EI) Display contrast (EV) User password (EL) Standard settings (EK) <u>3 Languages & units (F)</u> Language (FA) Units (FB) <u>4 Supply Tank (H)</u> Tank control OFF (HA) LLA Detect Delay (HB) <u>5 Communication (I)</u> Firmware Upgrade by cable (IC) Firmware Upgrade by infrared (ID) <u>6. I/O Settings (J)</u> Output 1 (JA) Output 2 (JB) Input (JC) <u>7. Installation (K)</u> Install password (KA) <u>8 Resets (D)</u> Reset trip counters(DA)	<u>4. Readings (R)</u> Pump state (RA) Outlet pres. (RB) Water temp (RC) Supply pressure (RD) Flow Status (RF)
---	---

5.1 Content of the Info menu



Please note that the Info menu is only for display – all data must be typed in via the setup menu!




Displays accumulated consumption of power and operation hours.



Displays accumulated consumption of power and operation hours. To reset the trip counter go to the setup menu.



Displays name and tel. no. of service technician.



Displays Software version and Pump size, machine configuration and inverter software version.

5.2 Content of the Errors menu – CAUSE & REMEDY

Example of Error log screen display:

All error occurrences will be stamped with date and time.

E indicates Error number. P indicates Pump number.

E0\P1	BA	↕	E0\P1	BA	↕
2006-01-01	12:00		2006-01-01	12:00	
C1 Inverter			C1 Inverter		
Error			Error		

The error log stores up to 1000 occurrences. When max. memory is reached, the errors will be deleted according to "First in" First out" principle.

5.2.1 Error List

Error	Cause	Remedy
C1 Inverter Error	1. Frequency inverter in error state	1. Switch off the power on the service switch. Wait 180 sec. Switch on the unit again. If error still occurs, please contact your local service technician.
C2 Low Supply Pressure	1. Insufficient water supply	1. Secure sufficient water supply pressure. 2. Check inlet filter for impurities/rinse filter 3. Contact your local service technician.
C3 High Water Temp.	1. Water pump top temperature is above 80° 2. Water consumption is too low (pump column has been overheated)	1. Lower the inlet water temp. (max 70°C) 2. Secure sufficient water consumption 3. Contact your local service technician.
C4 High Motor Temp.	1. Insufficient cooling of motor 2. The ambient temperature is above 40°	1. Secure that all air channels are open and not blocked by impurities 2. Lower ambient temperature
C5 High Supply Temp.	1. Water inlet temperature is above 70°	1. Lower the water temp. (max 70°C) 2. Contact your local service technician.
C6 Low Sensor Supply Voltage	1. Voltage supply for sensors too low	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C7 No Response Error	1. No communication between display and control board	1. Contact your local service technician.
C8 Low Tank Level	1. Insufficient water supply 2. Water supply valve not open	1. Contact your local service technician.
C9 High Tank Level	1. Water supply valve not closed	1. Contact your local service technician.
C11 Warning Cri. Inlet press.	1. Insufficient water supply 2. Booster will return to standby mode after 20 sec. If this error occurs 3 times within 20 min. Error C2 occurs.	1. Contact your local service technician.
C13 Warning Low inlet press.	1. Insufficient water supply. The machine will keep on working as always, but the maximum speed of the pump will be reduced until sufficient inlet pressure is present.	1. Contact your local service technician.
C14 Warning leakage start	1. Booster start condition changed to flow, due to leakage in pipe	1. Check for leakage in pipe system. 2. Press "off" button 3. If error reoccurs, contact your local service technician.
C20 Low Sensor Signal P-Pump-top	1. Pressure signal from pumptop sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C21 Low Sensor Signal T-Pump-top	1. Temperature signal from pumptop, sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.

C22 Low Sensor Signal P-Inlet	1. Pressure signal form inlet sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C23 Low Sensor Signal T-Inlet	1. Temperature signal from inlet sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C24 Low Sensor Signal block	1. Signal from block sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C25 Low Sensor Signal flow	1. Signal from flow sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C30 High Sensor Signal P-Pump- top	1. Pressure signal from pumptop sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C31 High Sensor Signal T-Pump- top	1. Temperature signal from pumptop sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C32 High Sensor Signal P-Inlet	1. Pressure signal from inlet sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C33 High Sensor Signal T-Inlet	1. Temperature signal from inlet sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C34 High Sensor Signal block	1. Signal from block sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C35 High Sensor Signal flow	1. Signal from flow sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C40 Sensor Load Pumptop Sensor	1. Supply voltage for pumptop sensor too low. 2. Pumptop sensor using too much current	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C41 Sensor Load Inlet sensor	1. Supply voltage for inlet sensor too low 2. Inlet sensor using too much current	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C42 Sensor Load Block sensor	1. Supply voltage for block sensor too low 2. Block sensor using too much current	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C43 Sensor Load Flow sensor	1. Supply voltage for flow sensor too low 2. Flow sensor using too much current	1. Press "off" button 2. If error reoccurs, contact your local service technician.
C45 Inverter Module temp.	1. Water consumption too high 2. Ambient temperature too high"	1. Lower the load for inverter 2. Lower the ambient temperature"
C46 Inverter Board temp."	1. Water consumption too high 2. Ambient temperature too high 3. Load at Board high"	1. Lower the load for inverter 2. Lower the ambient temperature 3. lower the load at board"



EZ 

Autooff
Delay:OFF

EZA 

Set auto off
Delay: OFF

EU 

Accelleration
Ramp: 3 sec

EUA 

Set Acc.
Ramp: 3 sec

EP 

Date & time
2006-01-01 12:00



Set date & time
2006-01-01 12:00

Set date and time

SERVICE EJ 

Enter TEXT HERE

SERVICE EJA 

Enter TEXT HERE

Enter name and tel. no of Your local service technician.

EO 

Inverter
power: 11000W

EOA 

Inverter
power: 11000W

Set rated power of frequency inverter

EI 

Backlight
intensity: 75 %

EIA 

Backlight
intensity: 75 %

Set the backlight intensity.

EV 

Display
Contrast:8

EVA 

Set display
Contrast: 8

EL 

User
Password: 6802

ELA 

Password
6802

Create new user password (default 6802).

EK 

Standard
settings


EKA 

Reset?

Reset to standard factory settings.

5.3 Content of the Setup sub menu Settings

The Setup Main menu contains the below submenus, which will be described subsequently.





5.4 Content of Setup menu

CA 

Password
0000

E 

S Settings

ED 

Post run
Time: 20 sec.

EDA 

Post run
Time: 20 sec.

Password Note: Default user password is 6802. Enter the settings menu to change the default password. To avoid unintended access to the system the your local service technician. can insert a blocking preventing access to the password controlled menus.

Set Post run time.

EE 

Dry run
level: 0.5 bar

EEA 

Dry run
level: 0.5 bar

Set dry run level.

ER 

Standard
pressure: 25 bar

ERA 

Standard
pressure: 25 bar

Set standard pressure.

EA 

High
pressure: 25 bar

EAA 

High
pressure: 25 bar

Set high pressure.

EB 

Low
pressure: 12 bar

EBA 

Low
pressure: 12 bar

Set low pressure.

EY 

Startup
Method: Pressure

EYA 

Set Startup
Method: Pressure

EX 

Pressure Start
Level: 8 bar

EXA 

Set Pres. Start
Level: 8 bar

EW 

Startup
Delay: 10 sec

EWA 

Set Startup
Delay: 10 sec.

EC 

Quick start
level: Off

ECA 

Quick start
level: Off

Set Quick start level.

5.4.1 Submenu Language & Units

6. Upgrade Firmware


Upgrading from software 5.02 or higher.

6.1 Upgrade display using USB Cable


1. Connect USB cable (Item No. 110007887) to PC USB port (Remove other USB cables connected to PC)
2. Connect Display cable to USB cable
3. In the menu go to, Setup->"password"->Communication-> Firmware upgrade by cable->Confirm Firmware upgrade and press "OK"
4. Display should now be looking like this:

Upgrade Ready
Power Cycle and
Start PC App.


5. Disconnect display from usb cable and connect it again (Power cycle)
6. Make sure the Green "ON" led and the red "OFF" led at the display is both on, display is blank
7. Startup PC program FWU200.exe (can be downloaded from Nilfisk Food website)
8. Window should be looking like this




9. Press "Browse" button




10. Select the file you will use for upgrade. Software File can be downloaded from Nilfisk Food website. The name of the file should end with ".hex". Ex V4.14_SB_DISP.hex
11. When the file is located press "Open" in browser window
12. The file name will now be written in file text line




13. Press UPGRADE button in FWU 200 tool



14. After a short while the FWU tool should start upgrading, the upgrade button should turn Yellow and change to "RUNNING"



15. The progress bar "Program" must go to the end before the upgrade is complete (less than 1 minute)
16. When the upgrade is complete the FWU tool should be looking like this, Button turns Green and text changes to "DONE/NEW"



17. Now the display is upgraded
18. To verify software version in display, in the menu go to, Info->Machine info
19. Here you will find display software version and control software version. SW ID "Display software", HW ID "type of device", CT ID Controller board software(if display is not connected to a control board, control software will be 0/300)

6.2 Upgrade display using IrDA Cable


1. Connect power to equipment
2. In the menu go to, Setup->"password"->Communication-> Firmware upgrade by Infrared->Confirm Firmware upgrade and press "OK"
3. Display should now be looking like this:

Upgrade Ready
Power Cycle and
Start PC App.


4. Turn Off equipment and turn it on again (Power cycle)
5. Make sure the All three led's are on (Green "ON", red "ERROR" and red "OFF") and the display is blank
6. Connect Irda module (Item No. 110001558) to PC USB port
7. Place Irda module on display module like this




8. Startup PC program FWU200.exe (can be downloaded from Nilfisk Food website)
9. Window should be looking like this




10. Press "Browse" button




11. Select the file you will use for upgrade. Software File can be downloaded from Nilfisk Food website. The name of the file should end with ".hex". Ex V4.14_SB_DISP.hex
12. When the file is located press "Open" in browser window
13. The file name will now be written in file text line




14. Press UPGRADE button in FWU 200 tool



15. After a short while the FWU tool should start upgrading, the upgrade button should turn Yellow and change to "RUNNING"




16. The progress bar "Program" must go to the end before the upgrade is complete (less than 1 minute)
17. When the upgrade is complete the FWU tool should be looking like this, Button turns Green and text changes to "DONE/NEW"




18. Now the display is upgraded
19. To verify software version in display, in the menu go to, Info->Machine info
20. Here you will find display software version and control software version. SW ID "Display software", HW ID "type of device", CT ID Controller board software(if display is not connected to a control board, control software will be 0/300)

6.3 Upgrade Inverter


1. Power off unit using service switch (wait for unit to discharge approximately 5 min.)
2. Open Inverter box
3. Disconnect the Display cable connected to either of the two modbus terminals



4. Connect the usb cable (110007946) to either one of the modbus connectors
5. Connect usb cable to PC
6. Power on inverter by using service switch (AWARE OF HIGH VOLTAGE IN INVERTER!)
7. Start up Firmware upgrade program (Can be downloaded from Nilfisk FOOD web)



8. Click browse to select upgrade file *.hex (Can be downloaded from Nilfisk FOOD web)
9. Click in Serial port up/down to select the com port for USB cable, if com port is not showing press "refresh" button
10. If necessary change inverter ID to match Inverter ID, Default is 1
11. Press Upload Firmware, and wait for progress bar to reach the end and turn green
12. The progress bar will start moving



13. Power off unit using service switch (wait for unit to discharge approximately 5 min.)
14. Disconnect the usb cable from inverter
15. Connect the display to modbus connector again
16. Mount the lid of the inverterbox
17. Turn unit back on.





No.: 110007941B 06/2021 Printed in Denmark