

D-Link Network Assistant (DNA) User Manual



Version: 4.0.0



Table of Contents

1	Introduction	01
	Audience	01
	Other Documentation	01
	Conventions	01
	Notes, Notices, and Cautions	01
2	Product Introduction	02
3	Installation	03
4	Interface Overview	07
5	Toolbar	08
	Workspace Management	10
	Ignore List	12
6	Batch Settings	14
7	Inventory List	17
	Device Settings	18
8	DNA App	21
	Download & Install	21
	Device List	21
	Supported Devices	22

1 Introduction

The manual is organized by the menu layout in the D-Link Network Assistant (DNA). See the Interface Overview section for more information.

Audience

This reference manual is intended for network administrators and other IT professionals responsible for managing network devices using DNA. Alternative management interfaces, such as the Web User Interface (Web UI) and Command Line Interface (CLI) may also be available for your devices but are not documented in this manual. This manual is written in a way that assumes that you already have a basic knowledge of modern networking principles.

Other Documentation

The documents below are a further source of information in regards to configuring and troubleshooting DNA. All documents are available from the D-Link website. Other documents related to DNA are:

- Quick Installation Guide

Conventions

Convention	Description
Boldface Font	Indicates a button, a toolbar icon, menu, or menu item. For example: Open the File menu and choose Cancel. Used for emphasis. May also indicate system messages or prompts appearing on screen. For example: You have mail. Bold font is also used to represent filenames, program names and commands. For example: use the copy command.
Initial capital letter	Indicates a window name. Names of keys on the keyboard have initial capitals. For example: Click Enter.
Menu Name > Menu Option	Indicates the menu structure. Device > Port > Port Properties means the Port Properties menu option under the Port menu option that is located under the Device menu.
Blue Courier Font	This convention is used to represent an example of a screen console display including example entries of CLI command input with the corresponding output.

Table 1-1—Conventions

Notes, Notices, and Cautions

Below are examples of the three types of indicators used in this manual. When administering your device using the information in this document, you should pay special attention to these indicators. Each example below provides an explanatory remark regarding each type of indicator.

	NOTE: A note indicates important information that helps you make better use of your device.
	NOTICE: A notice indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.
	CAUTION: A caution indicates a potential for property damage, personal injury, or death.

2 Product Introduction

The D-Link Network Assistant (DNA) is a Windows standalone application (referred to in this manual as a PC tool run in a Windows browser) which simplifies the first-time setup of D-Link business networking devices. The tool is free and available on any device that is able to be executed in Windows web browser. It is compatible with any supported devices running the D-Link Discovery Protocol (DDP) v2 and v5, and will automatically scan the D-Link business networking devices for new or existing devices.

The DNA tool makes first-time setup of D-Link Switches, Access Points (APs), D-Link Business Network Controllers, and D-Link Business Security Routers simple. When a D-Link Business Access Points(APs) has been detected, it is added to the inventory, so it can be managed along with existing D-Link Business Network Device.

It enables you to set IP addresses, change usernames and passwords, and configure SNMP information so that devices can be managed with an existing Network Management System (NMS).

DNA allows you to set up new devices quickly and easily. Devices can be organized into workspaces, so that they can be managed based on physical or organizational requirements. First-time setup of devices is greatly simplified, significantly reducing the time it takes to integrate a new device with the network and lowering administration and maintenance costs.

3 Installation

Follow these instructions to download and install the DNA tool.

1. Go to <https://www.dlink.com/en/business/tools/d-link-network-assistant> and click Free Download. On the next page, click Download to download the DNA installer file to your local hard drive.




Figure 3-1—




Figure 3-2—

2. Run the DNA installer file and follow the on-screen instructions to complete installation.



Figure 3-3—




Figure 3-4—




Figure 3-5—

Once installed, run the DNA application and click Launch a Browser to Manage the Network. This will launch your default web browser and open the DNA interface window. To use DNA in a different browser, enter `http://localhost:[listening port]` into the address bar.




Figure 3-6—




Figure 3-7—

4 Interface Overview

This provides an overview of the different areas of the interface.



Figure 4-1—Interface Overview

Field	Description
AREA 1	This is the main toolbar located at the top of the screen.
AREA 2	This is the batch settings menu which is always displayed in the workspace.
AREA 3	This is the main workspace which contains device information and the device inventory.

Table 4-1—Interface Overview

	NOTE: Ensure that there is IP connectivity to the devices that you wish to manage from your management PC or device before continuing with the instructions.
---	---

5 Toolbar

This is the DNA toolbar, which contains features that are present in all workspaces.
The toolbar is always displayed in the workspace:




Figure 5-1—Toolbar

Field	Description																		
	The workspace management menu allows workspaces to be created, deleted, and renamed, and also allows global settings to be set.																		
	The search feature. This is used for searching the workspace for specific device states.<table><tr><th>Field</th><th>Description</th></tr><tr><td>Search...</td><td>Enter device properties to search the workspace for.</td></tr><tr><td></td><td>Click this to begin the search.</td></tr><tr><td></td><td>Click this to get a list of pre-set device states to search for.<table><tr><th>Field</th><th>Description</th></tr><tr><td>IP Conflict(s)</td><td>Search for devices in the workspace with IP conflicts.</td></tr><tr><td>SNMP off</td><td>Search for devices in the workspace with SNMP off.</td></tr><tr><td>New firmware available</td><td>Search for devices in the workspace with new firmware available.</td></tr><tr><td>Unauthenticated</td><td>Search for unauthenticated devices in the workspace.</td></tr></table></td></tr></table>	Field	Description	Search...	Enter device properties to search the workspace for.		Click this to begin the search.		Click this to get a list of pre-set device states to search for. <table><tr><th>Field</th><th>Description</th></tr><tr><td>IP Conflict(s)</td><td>Search for devices in the workspace with IP conflicts.</td></tr><tr><td>SNMP off</td><td>Search for devices in the workspace with SNMP off.</td></tr><tr><td>New firmware available</td><td>Search for devices in the workspace with new firmware available.</td></tr><tr><td>Unauthenticated</td><td>Search for unauthenticated devices in the workspace.</td></tr></table>	Field	Description	IP Conflict(s)	Search for devices in the workspace with IP conflicts.	SNMP off	Search for devices in the workspace with SNMP off.	New firmware available	Search for devices in the workspace with new firmware available.	Unauthenticated	Search for unauthenticated devices in the workspace.
Field	Description																		
Search...	Enter device properties to search the workspace for.																		
	Click this to begin the search.																		
	Click this to get a list of pre-set device states to search for. <table><tr><th>Field</th><th>Description</th></tr><tr><td>IP Conflict(s)</td><td>Search for devices in the workspace with IP conflicts.</td></tr><tr><td>SNMP off</td><td>Search for devices in the workspace with SNMP off.</td></tr><tr><td>New firmware available</td><td>Search for devices in the workspace with new firmware available.</td></tr><tr><td>Unauthenticated</td><td>Search for unauthenticated devices in the workspace.</td></tr></table>	Field	Description	IP Conflict(s)	Search for devices in the workspace with IP conflicts.	SNMP off	Search for devices in the workspace with SNMP off.	New firmware available	Search for devices in the workspace with new firmware available.	Unauthenticated	Search for unauthenticated devices in the workspace.								
Field	Description																		
IP Conflict(s)	Search for devices in the workspace with IP conflicts.																		
SNMP off	Search for devices in the workspace with SNMP off.																		
New firmware available	Search for devices in the workspace with new firmware available.																		
Unauthenticated	Search for unauthenticated devices in the workspace.																		

Field	Description														
	The Layer 3 discovery function <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Range type</td><td>Click the drop-down menu to select IP Range or Subnet. In the IP fields, enter the starting and ending addresses to define the search pool.</td></tr> <tr> <td></td><td>Remove a defined range.</td></tr> <tr> <td></td><td>Add a defined range.</td></tr> </table> Click Save to confirm the discovery range and initiate a search of Layer 3 devices within the defined pool.	Field	Description	Range type	Click the drop-down menu to select IP Range or Subnet. In the IP fields, enter the starting and ending addresses to define the search pool.		Remove a defined range.		Add a defined range.						
Field	Description														
Range type	Click the drop-down menu to select IP Range or Subnet. In the IP fields, enter the starting and ending addresses to define the search pool.														
	Remove a defined range.														
	Add a defined range.														
	The ignore list. This is for devices which have been removed from the workspace. There must be devices present in the ignore list for this icon to be available. See the Ignore List section for more information.														
	The export feature. This is used to export the inventory in Comma Separated Value (CSV) format.														
	The feedback menu. This is used to send problem reports, questions or bugs to the software manufacturers. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Feedback type</td><td>Select the feedback type. This can be: Problem, Request, Question, Bug, Complaint, Others.</td></tr> <tr> <td>Your name</td><td>Enter your name. This is a required field.</td></tr> <tr> <td>Email address</td><td>Enter your email address. This is a required field.</td></tr> <tr> <td>Subject</td><td>Enter the subject of your message. This is a required field.</td></tr> <tr> <td>Description</td><td>Enter your message. This is a minimum of 10 words and a maximum of 2000. This is a required field.</td></tr> <tr> <td>Add attachment</td><td>Click Add attachment to add an attachment to the message. This can be up to 10 files, with a total combined file size of 10 MB.</td></tr> </table>	Field	Description	Feedback type	Select the feedback type. This can be: Problem, Request, Question, Bug, Complaint, Others.	Your name	Enter your name. This is a required field.	Email address	Enter your email address. This is a required field.	Subject	Enter the subject of your message. This is a required field.	Description	Enter your message. This is a minimum of 10 words and a maximum of 2000. This is a required field.	Add attachment	Click Add attachment to add an attachment to the message. This can be up to 10 files, with a total combined file size of 10 MB.
Field	Description														
Feedback type	Select the feedback type. This can be: Problem, Request, Question, Bug, Complaint, Others.														
Your name	Enter your name. This is a required field.														
Email address	Enter your email address. This is a required field.														
Subject	Enter the subject of your message. This is a required field.														
Description	Enter your message. This is a minimum of 10 words and a maximum of 2000. This is a required field.														
Add attachment	Click Add attachment to add an attachment to the message. This can be up to 10 files, with a total combined file size of 10 MB.														
	The introduction screen. This is shown when you log-in to DNA for the first time.														

Field	Description						
	The credential information for the workspace. This is used to manage the stored credentials. See the table below for more information: <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td></td><td>Clear the stored credentials for all devices in the workspace. Clicking this will display a clear credentials window, which will ask you to confirm clearing the default credentials and device credentials. Click Yes, clear them to clear the credentials and Cancel to return to the previous page.</td></tr> <tr> <td></td><td>Set the default credentials to be used with all workspaces. Clicking this will display a default workspace credentials window, which will allow you to set default workspace credentials, or specify not to set any credentials. Tick the Don't set box not to use any credentials, or enter in default device credentials in the Username and Password boxes. Click Save to save the changes and Cancel to return to the previous page.</td></tr> </table>	Field	Description		Clear the stored credentials for all devices in the workspace. Clicking this will display a clear credentials window, which will ask you to confirm clearing the default credentials and device credentials. Click Yes, clear them to clear the credentials and Cancel to return to the previous page.		Set the default credentials to be used with all workspaces. Clicking this will display a default workspace credentials window, which will allow you to set default workspace credentials, or specify not to set any credentials. Tick the Don't set box not to use any credentials, or enter in default device credentials in the Username and Password boxes. Click Save to save the changes and Cancel to return to the previous page.
Field	Description						
	Clear the stored credentials for all devices in the workspace. Clicking this will display a clear credentials window, which will ask you to confirm clearing the default credentials and device credentials. Click Yes, clear them to clear the credentials and Cancel to return to the previous page.						
	Set the default credentials to be used with all workspaces. Clicking this will display a default workspace credentials window, which will allow you to set default workspace credentials, or specify not to set any credentials. Tick the Don't set box not to use any credentials, or enter in default device credentials in the Username and Password boxes. Click Save to save the changes and Cancel to return to the previous page.						

Table 5-1—Toolbar

Workspace Management

This is a sub menu which is displayed when the menu button is pressed in the top left hand corner of the DNA interface.

It can be viewed by pressing the menu button in the top left hand corner of the interface:




Figure 5-2—Workspace Management

The following fields are available:

Field	Description
	This is used to search for workspaces. The results are shown in the area below.

Field	Description																
Workspace	The search feature. This is used for searching the workspace for specific device states.																
	<table><tr><th>Field</th><th>Description</th></tr><tr><td>Search...</td><td>Enter device properties to search the workspace for.</td></tr><tr><td></td><td>This area shows the search results and workspaces available when no search has been entered.</td></tr><tr><td></td><td><table><tr><th>Field</th><th>Description</th></tr><tr><td></td><td>Rename the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Rename Workspace window which can be used to rename the workspace. Click Rename this Workspace to rename the workspace or Cancel to return to the previous page.</td></tr><tr><td></td><td>Delete the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Delete Workspace window which can be used to delete the workspace. Select the workspace and click Yes, delete this Workspace to delete the workspace, or Cancel to return to the previous page.</td></tr><tr><td></td><td>NOTE: This icon is only displayed when there is more than 1 workspace in the list.</td></tr></table></td></tr></table>	Field	Description	Search...	Enter device properties to search the workspace for.		This area shows the search results and workspaces available when no search has been entered.		<table><tr><th>Field</th><th>Description</th></tr><tr><td></td><td>Rename the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Rename Workspace window which can be used to rename the workspace. Click Rename this Workspace to rename the workspace or Cancel to return to the previous page.</td></tr><tr><td></td><td>Delete the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Delete Workspace window which can be used to delete the workspace. Select the workspace and click Yes, delete this Workspace to delete the workspace, or Cancel to return to the previous page.</td></tr><tr><td></td><td>NOTE: This icon is only displayed when there is more than 1 workspace in the list.</td></tr></table>	Field	Description		Rename the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Rename Workspace window which can be used to rename the workspace. Click Rename this Workspace to rename the workspace or Cancel to return to the previous page.		Delete the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Delete Workspace window which can be used to delete the workspace. Select the workspace and click Yes, delete this Workspace to delete the workspace, or Cancel to return to the previous page.		NOTE: This icon is only displayed when there is more than 1 workspace in the list.
	Field	Description															
	Search...	Enter device properties to search the workspace for.															
		This area shows the search results and workspaces available when no search has been entered.															
	<table><tr><th>Field</th><th>Description</th></tr><tr><td></td><td>Rename the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Rename Workspace window which can be used to rename the workspace. Click Rename this Workspace to rename the workspace or Cancel to return to the previous page.</td></tr><tr><td></td><td>Delete the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Delete Workspace window which can be used to delete the workspace. Select the workspace and click Yes, delete this Workspace to delete the workspace, or Cancel to return to the previous page.</td></tr><tr><td></td><td>NOTE: This icon is only displayed when there is more than 1 workspace in the list.</td></tr></table>	Field	Description		Rename the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Rename Workspace window which can be used to rename the workspace. Click Rename this Workspace to rename the workspace or Cancel to return to the previous page.		Delete the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Delete Workspace window which can be used to delete the workspace. Select the workspace and click Yes, delete this Workspace to delete the workspace, or Cancel to return to the previous page.		NOTE: This icon is only displayed when there is more than 1 workspace in the list.								
Field	Description																
	Rename the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Rename Workspace window which can be used to rename the workspace. Click Rename this Workspace to rename the workspace or Cancel to return to the previous page.																
	Delete the workspace by clicking this button. This is only displayed when hovering over the button with the mouse. This will open a Delete Workspace window which can be used to delete the workspace. Select the workspace and click Yes, delete this Workspace to delete the workspace, or Cancel to return to the previous page.																
	NOTE: This icon is only displayed when there is more than 1 workspace in the list.																
	This is used to change the language of DNA. Currently supported languages are EN (English), 简 (Simplified Chinese), 繁 (Traditional Chinese).																

Field	Description										
	This is the list of devices that DNA supports. Clicking this will open the Supported Devices window. The device model, minimum hardware version and minimum firmware version are displayed. Devices are also grouped into categories such as Smart Switches and Security Service Routers (DSRs).										
	These are the global settings for DNA. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Country</td><td>Choose the country that DNA is being used in. This is used to determine the firmware which is available. This is a required field.</td></tr> <tr> <td>Backup file path</td><td>Enter the backup path for device backups using the DNA backup function. This is a required field.</td></tr> <tr> <td>Auto-discover devices when launching DNA</td><td>Enable this to automatically scan for devices when launching DNA. The default is enabled.</td></tr> <tr> <td>Clear credentials of all workspaces when closing DNA</td><td>Enable this to clear all stored credentials when exiting DNA. The default is disabled.</td></tr> </table> Click Save to save the settings or Cancel to return to the previous page.	Field	Description	Country	Choose the country that DNA is being used in. This is used to determine the firmware which is available. This is a required field.	Backup file path	Enter the backup path for device backups using the DNA backup function. This is a required field.	Auto-discover devices when launching DNA	Enable this to automatically scan for devices when launching DNA. The default is enabled.	Clear credentials of all workspaces when closing DNA	Enable this to clear all stored credentials when exiting DNA. The default is disabled.
Field	Description										
Country	Choose the country that DNA is being used in. This is used to determine the firmware which is available. This is a required field.										
Backup file path	Enter the backup path for device backups using the DNA backup function. This is a required field.										
Auto-discover devices when launching DNA	Enable this to automatically scan for devices when launching DNA. The default is enabled.										
Clear credentials of all workspaces when closing DNA	Enable this to clear all stored credentials when exiting DNA. The default is disabled.										
	This is used to create a new workspace. Click this button to display a Create a new Workspace window. Enter a Name for the workspace and click Create Workspace to create the workspace or Cancel to return to the previous page. The maximum number of characters that can be entered is 32.										

Table 5-1—Workspace Management

Ignore List

This is the list of devices which have been removed from the inventory list in the workspace. They are still present in DNA but will not be re-added to the workspace when the network is scanned for devices and are not managed through the workspace.

Use the ignore list icon in the toolbar to access the ignore list:

Ignore list (Online / Offline: 1/0)											
											
☐	Type / Status	Auth.	System Name	IP Address	MAC	Model	SNMP	FW Ver.	SN	System Time	IP Mode
☐			dap2610	192.168.1.166	c4-e9-0a-21-50-d0	DAP-2610	-	v2.01	-	1970/01/11 12:10:58	Static
										rev A1G	DDP V5.5

Figure 5-3—Ignore List

The following fields are available:

Field	Description																				
	Click to return to the previous menu.																				
	Select a device in the list and click this to return the device to the inventory list or workspace.																				
	Select a device in the list and click this to remove the device from the ignore list. This will cause the device to reappear in each workspace when the network is scanned for devices.																				
	Enter device properties to search the ignore list for here. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Search...</td><td>Enter device properties to search the workspace for.</td></tr> <tr> <td></td><td>Press this to begin the search.</td></tr> <tr> <td></td><td>Press this to get a list of pre-set device states to search for.</td></tr> <tr> <td><table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>IP Conflict(s)</td><td>Search for devices in the workspace with IP conflicts.</td></tr> <tr> <td>SNMP off</td><td>Search for devices in the workspace with SNMP off.</td></tr> <tr> <td>New firmware available</td><td>Search for devices in the workspace with new firmware available.</td></tr> <tr> <td>Unauthenticated</td><td>Search for unauthenticated devices in the workspace.</td></tr> </table></td><td></td></tr> </table>	Field	Description	Search...	Enter device properties to search the workspace for.		Press this to begin the search.		Press this to get a list of pre-set device states to search for.	<table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>IP Conflict(s)</td><td>Search for devices in the workspace with IP conflicts.</td></tr> <tr> <td>SNMP off</td><td>Search for devices in the workspace with SNMP off.</td></tr> <tr> <td>New firmware available</td><td>Search for devices in the workspace with new firmware available.</td></tr> <tr> <td>Unauthenticated</td><td>Search for unauthenticated devices in the workspace.</td></tr> </table>	Field	Description	IP Conflict(s)	Search for devices in the workspace with IP conflicts.	SNMP off	Search for devices in the workspace with SNMP off.	New firmware available	Search for devices in the workspace with new firmware available.	Unauthenticated	Search for unauthenticated devices in the workspace.	
Field	Description																				
Search...	Enter device properties to search the workspace for.																				
	Press this to begin the search.																				
	Press this to get a list of pre-set device states to search for.																				
<table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>IP Conflict(s)</td><td>Search for devices in the workspace with IP conflicts.</td></tr> <tr> <td>SNMP off</td><td>Search for devices in the workspace with SNMP off.</td></tr> <tr> <td>New firmware available</td><td>Search for devices in the workspace with new firmware available.</td></tr> <tr> <td>Unauthenticated</td><td>Search for unauthenticated devices in the workspace.</td></tr> </table>	Field	Description	IP Conflict(s)	Search for devices in the workspace with IP conflicts.	SNMP off	Search for devices in the workspace with SNMP off.	New firmware available	Search for devices in the workspace with new firmware available.	Unauthenticated	Search for unauthenticated devices in the workspace.											
Field	Description																				
IP Conflict(s)	Search for devices in the workspace with IP conflicts.																				
SNMP off	Search for devices in the workspace with SNMP off.																				
New firmware available	Search for devices in the workspace with new firmware available.																				
Unauthenticated	Search for unauthenticated devices in the workspace.																				
	Press this to refresh the ignore list.																				
	Press this to export the ignore list in Comma Separated Value (CSV) format.																				
Select	Select either an individual device by ticking the check box next to the device, or choose all devices by ticking the check box at the top of the column.																				
Type/Status	This is the device type and status. An icon will be displayed for the device type (Smart Switches, DSRs etc.) and the color of the icon will change, depending on device availability.																				
Auth.	This indicates whether or not the device can be authenticated. If the device can be authenticated, the icon will be amber. If the device cannot be authenticated, the icon color will be gray. A warning will appear if the device is using the default device username and password.																				
System Name	This is the hostname set on the device.																				
IP Address	This is the management IP address of the device.																				
MAC	This is the MAC address of the device.																				
Modelo	This is the model number the device.																				
SNMP	This shows whether Simple Network Management Protocol (SNMP) is enabled on the device. This cannot be changed from the ignore list.																				
FW Ver.	This is the firmware version the device.																				
SN	This is the serial number of the device.																				
System Time	This is the system time on the device.																				
IP Mode	This is the IP mode of the device. If the switch is set to acquire an address automatically, this will be set to DHCP. If it has a Static IP address, this will be set to Static.																				
HW Ver.	This is the hardware version of the device.																				
Protocol Ver.	This shows the D-Link Discovery Protocol (DDP) version of the device.																				

Table 5-1—Ignore List

6 Batch Settings

These can be used to simultaneously apply settings to multiple devices.



NOTE: This menu is only available when two or more devices have been selected in the workspace.

The batch settings are always displayed in the workspace:




Figure 6-1—Batch Settings

Field	Description														
	Re-scan the network for devices and refresh the inventory list in the workspace.														
	Enter shared authentication information. This only appears if all devices cannot be authenticated with DNA. <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Username</td><td>Enter the username to authenticate the selected devices.</td></tr> <tr> <td>Password</td><td>Enter the password to authenticate the selected devices.</td></tr> </tbody> </table> Click Save to save the settings or Cancel to return to the previous page.	Field	Description	Username	Enter the username to authenticate the selected devices.	Password	Enter the password to authenticate the selected devices.								
Field	Description														
Username	Enter the username to authenticate the selected devices.														
Password	Enter the password to authenticate the selected devices.														
	Configure settings for automatic IP assignment, such as enabling DHCP mode and automatically assigning static IPs for selected devices. <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Enable DHCP mode</td><td>Enable DHCP for the selected devices.</td></tr> <tr> <td>Auto assign static IPs</td><td> Assign static IPs automatically to the selected devices. <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Start from IP</td><td>Enter the start IP to use for the range.</td></tr> <tr> <td>Subnet mask</td><td>Enter the subnet mask to use for the automatically assigned IPs.</td></tr> <tr> <td>Default gateway</td><td>Enter the default gateway for the selected devices.</td></tr> </tbody> </table> Click Apply to apply the settings or Cancel to return to the previous page. </td></tr> </tbody> </table> Click Apply to apply the settings or Cancel to return to the previous page.	Field	Description	Enable DHCP mode	Enable DHCP for the selected devices.	Auto assign static IPs	Assign static IPs automatically to the selected devices. <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Start from IP</td><td>Enter the start IP to use for the range.</td></tr> <tr> <td>Subnet mask</td><td>Enter the subnet mask to use for the automatically assigned IPs.</td></tr> <tr> <td>Default gateway</td><td>Enter the default gateway for the selected devices.</td></tr> </tbody> </table> Click Apply to apply the settings or Cancel to return to the previous page.	Field	Description	Start from IP	Enter the start IP to use for the range.	Subnet mask	Enter the subnet mask to use for the automatically assigned IPs.	Default gateway	Enter the default gateway for the selected devices.
Field	Description														
Enable DHCP mode	Enable DHCP for the selected devices.														
Auto assign static IPs	Assign static IPs automatically to the selected devices. <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Start from IP</td><td>Enter the start IP to use for the range.</td></tr> <tr> <td>Subnet mask</td><td>Enter the subnet mask to use for the automatically assigned IPs.</td></tr> <tr> <td>Default gateway</td><td>Enter the default gateway for the selected devices.</td></tr> </tbody> </table> Click Apply to apply the settings or Cancel to return to the previous page.	Field	Description	Start from IP	Enter the start IP to use for the range.	Subnet mask	Enter the subnet mask to use for the automatically assigned IPs.	Default gateway	Enter the default gateway for the selected devices.						
Field	Description														
Start from IP	Enter the start IP to use for the range.														
Subnet mask	Enter the subnet mask to use for the automatically assigned IPs.														
Default gateway	Enter the default gateway for the selected devices.														

Field	Description																
SNMP	Enable or disable SNMP on the selected devices, including adding and removing community strings.																
	<table><tr><th>Field</th><th>Description</th></tr><tr><td>Set SNMP Status for all selected devices</td><td>Enable or disable SNMP for selected devices. Move the slider to the right to enable SNMP and move it to the left to disable SNMP.</td></tr><tr><td>Edit community</td><td>Tick this to add or remove community strings to or from the selected devices.<table><tr><th>Field</th><th>Description</th></tr><tr><td></td><td>Add a community string.</td></tr><tr><td>Community type</td><td>Select read-only or read-write as the community string type.</td></tr><tr><td>Community name</td><td>Enter the name of the community string. The maximum number of characters that can be entered is 32.</td></tr><tr><td></td><td>Remove the community string.</td></tr></table></td></tr></table>	Field	Description	Set SNMP Status for all selected devices	Enable or disable SNMP for selected devices. Move the slider to the right to enable SNMP and move it to the left to disable SNMP.	Edit community	Tick this to add or remove community strings to or from the selected devices. <table><tr><th>Field</th><th>Description</th></tr><tr><td></td><td>Add a community string.</td></tr><tr><td>Community type</td><td>Select read-only or read-write as the community string type.</td></tr><tr><td>Community name</td><td>Enter the name of the community string. The maximum number of characters that can be entered is 32.</td></tr><tr><td></td><td>Remove the community string.</td></tr></table>	Field	Description		Add a community string.	Community type	Select read-only or read-write as the community string type.	Community name	Enter the name of the community string. The maximum number of characters that can be entered is 32.		Remove the community string.
	Field	Description															
	Set SNMP Status for all selected devices	Enable or disable SNMP for selected devices. Move the slider to the right to enable SNMP and move it to the left to disable SNMP.															
	Edit community	Tick this to add or remove community strings to or from the selected devices. <table><tr><th>Field</th><th>Description</th></tr><tr><td></td><td>Add a community string.</td></tr><tr><td>Community type</td><td>Select read-only or read-write as the community string type.</td></tr><tr><td>Community name</td><td>Enter the name of the community string. The maximum number of characters that can be entered is 32.</td></tr><tr><td></td><td>Remove the community string.</td></tr></table>	Field	Description		Add a community string.	Community type	Select read-only or read-write as the community string type.	Community name	Enter the name of the community string. The maximum number of characters that can be entered is 32.		Remove the community string.					
	Field	Description															
	Add a community string.																
Community type	Select read-only or read-write as the community string type.																
Community name	Enter the name of the community string. The maximum number of characters that can be entered is 32.																
	Remove the community string.																
Click Apply to apply the settings or Cancel to return to the previous page.																	
	Set the time zone for selected devices, including configuring a network time source using Network Time Protocol (NTP) or Simple Network Time Protocol (SNTP).																
	<table><tr><th>Field</th><th>Description</th></tr><tr><td>Time zone</td><td>Choose a time zone to clock synchronize the device to the selected zone.</td></tr><tr><td>Method</td><td>This is the method that is used to set the system clock.<table><tr><th>Field</th><th>Description</th></tr><tr><td>Device time</td><td>Manually set the time on the device. This can be set using the Date and Time fields.</td></tr><tr><td>Use NTP / SNTP server</td><td>Select the IP format of the server and enter the IP address of the network time source for clock synchronization.</td></tr></table></td></tr></table>	Field	Description	Time zone	Choose a time zone to clock synchronize the device to the selected zone.	Method	This is the method that is used to set the system clock. <table><tr><th>Field</th><th>Description</th></tr><tr><td>Device time</td><td>Manually set the time on the device. This can be set using the Date and Time fields.</td></tr><tr><td>Use NTP / SNTP server</td><td>Select the IP format of the server and enter the IP address of the network time source for clock synchronization.</td></tr></table>	Field	Description	Device time	Manually set the time on the device. This can be set using the Date and Time fields.	Use NTP / SNTP server	Select the IP format of the server and enter the IP address of the network time source for clock synchronization.				
	Field	Description															
	Time zone	Choose a time zone to clock synchronize the device to the selected zone.															
	Method	This is the method that is used to set the system clock. <table><tr><th>Field</th><th>Description</th></tr><tr><td>Device time</td><td>Manually set the time on the device. This can be set using the Date and Time fields.</td></tr><tr><td>Use NTP / SNTP server</td><td>Select the IP format of the server and enter the IP address of the network time source for clock synchronization.</td></tr></table>	Field	Description	Device time	Manually set the time on the device. This can be set using the Date and Time fields.	Use NTP / SNTP server	Select the IP format of the server and enter the IP address of the network time source for clock synchronization.									
	Field	Description															
Device time	Manually set the time on the device. This can be set using the Date and Time fields.																
Use NTP / SNTP server	Select the IP format of the server and enter the IP address of the network time source for clock synchronization.																
Click Apply to apply the settings or Cancel to return to the previous page.																	
	Change the password for selected devices.																
	<table><tr><td></td><td>NOTE: This will change the password for the currently authenticated username on the device.</td></tr></table>		NOTE: This will change the password for the currently authenticated username on the device.														
		NOTE: This will change the password for the currently authenticated username on the device.															
	<table><tr><th>Field</th><th>Description</th></tr><tr><td>New password</td><td>Enter the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the entered password.</td></tr><tr><td>Repeat password</td><td>Confirm the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the entered password.</td></tr></table>	Field	Description	New password	Enter the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the entered password.	Repeat password	Confirm the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the entered password.										
Field	Description																
New password	Enter the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the entered password.																
Repeat password	Confirm the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the entered password.																
Click Apply to apply the settings or Cancel to return to the previous page..																	
	Import network profile																

Field	Description										
	Upgrade the firmware for all selected devices.  NOTE: The selected devices must be using unique IP addresses on the local network and be identical hardware types. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Model of selected devices</td><td>This displays the model number of the selected devices.</td></tr> </table> Drag and drop a firmware file to the Drag & drop area to upload it to the selected devices, or click Browse to select a file on the local file system.	Field	Description	Model of selected devices	This displays the model number of the selected devices.						
Field	Description										
Model of selected devices	This displays the model number of the selected devices.										
	Back up configuration for all selected devices. The Filename field shows the format that will be used for the filename. Click Backup now to begin the backup or Cancel to return to the previous page.										
	Reboot selected devices. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>The network will be offline for 60 seconds</td><td>Tick this to confirm that you are aware that the network will be offline for 60 seconds as the device reboots.</td></tr> </table> Click Yes, reboot these devices or Cancel to return to the previous page.	Field	Description	The network will be offline for 60 seconds	Tick this to confirm that you are aware that the network will be offline for 60 seconds as the device reboots.						
Field	Description										
The network will be offline for 60 seconds	Tick this to confirm that you are aware that the network will be offline for 60 seconds as the device reboots.										
	Reset all selected devices to default settings. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>All configurations will be lost</td><td>Tick this to confirm that you are aware that all configuration will be lost when the device is reset.</td></tr> <tr> <td>The system will reboot and be unavailable for roughly 90 seconds</td><td>Tick this to confirm that you are aware that the system will reboot and be unavailable for roughly 90 seconds while the device is being reset.</td></tr> <tr> <td>The network will be disconnected shortly</td><td>Tick this to confirm that you are aware that the network will be disconnected shortly after the device is reset.</td></tr> <tr> <td>Keep the IP configuration for these devices</td><td>Move the slider to the right to keep the IP configuration for the device. Move it to the left to include the device IP address in the deleted configurations when the device is reset.</td></tr> </table> Click Yes, reset these devices to reset the configuration on these devices to the factory default, or Cancel to return to the previous page.	Field	Description	All configurations will be lost	Tick this to confirm that you are aware that all configuration will be lost when the device is reset.	The system will reboot and be unavailable for roughly 90 seconds	Tick this to confirm that you are aware that the system will reboot and be unavailable for roughly 90 seconds while the device is being reset.	The network will be disconnected shortly	Tick this to confirm that you are aware that the network will be disconnected shortly after the device is reset.	Keep the IP configuration for these devices	Move the slider to the right to keep the IP configuration for the device. Move it to the left to include the device IP address in the deleted configurations when the device is reset.
Field	Description										
All configurations will be lost	Tick this to confirm that you are aware that all configuration will be lost when the device is reset.										
The system will reboot and be unavailable for roughly 90 seconds	Tick this to confirm that you are aware that the system will reboot and be unavailable for roughly 90 seconds while the device is being reset.										
The network will be disconnected shortly	Tick this to confirm that you are aware that the network will be disconnected shortly after the device is reset.										
Keep the IP configuration for these devices	Move the slider to the right to keep the IP configuration for the device. Move it to the left to include the device IP address in the deleted configurations when the device is reset.										
	Remove all selected devices from the inventory list. Click Yes, remove devices to remove the devices from the inventory list, or Cancel to return to the previous page.										

Table 6-1—Batch Settings

	NOTE: The authentication information in DNA needs to be correct in order to apply batch settings to a device. If DNA cannot authenticate with a device, then it will not be possible to batch manage devices.
---	---

7 Inventory List

This is the main window of the DNA interface, where a list of devices is displayed. From here you can manage your network devices and view the general overview of all devices in the workspace.

The inventory list is displayed after a workspace is selected:

Ignore list (Online / Offline: 1/0)												
												
												
☐ Type / Status	Auth.	System Name	IP Address	MAC	Model	SNMP	FW Ver.	SN	System Time	IP Mode	HW Ver.	Protocol Ver.
☐ 		dap2610	192.168.1.166	c4-e9-0a-21-50-d0	DAP-2610	-	v2.01	-	1970/01/11 12:10:58	Static	rev A1G	DDP V5.5

Figure 7-1—Inventory List Window

The following fields are available:

Field	Description
Select	device, or select all devices by ticking the check box at the top of the column.
Type/Status	This is the device type and status. An icon will be displayed for the device type (Smart Switches, DSRs etc.) and the color of the icon will change, depending on device availability.
Auth.	This shows whether or not the device can be authenticated. If the device can be authenticated, the icon will be amber. If the device cannot be authenticated, the icon color will be gray. A warning will appear if the device is using the default device username and password.
System Name	This is the hostname set on the device.
IP Address	This is the management IP address of the device.
MAC	This is the MAC address of the device.
Model	This is the model number the device.
SNMP	This shows whether SNMP is enabled on the device. Move the slider to the right to enable SNMP and move it to the left to disable SNMP.
FW Ver.	This is the firmware version the device.
SN	This is the serial number of the device.
System Time	This is the system time on the device.
IP Mode	This shows the IP mode of the device. If the switch is set to acquire an address automatically, this will be set to DHCP. If it has a Static IP address, this will be set to Static.
HW Ver.	This is the hardware version of the device.
Protocol Ver.	This shows the D-Link Discovery Protocol (DDP) version of the device.

Table 7-1—Inventory List

Device Settings

These are the settings that apply to individual devices, and are the same settings that appear in the batch settings menu.

They can be viewed by hovering over the individual device entry in the workspace:




Figure 7-2—Device Settings

The following fields are available:

Field	Description															
IP	Change IP settings, such as statically assigning an IP address to the device, or configuring it for DHCP.															
	<table><tr><th>Field</th><th>Description</th></tr><tr><td rowspan="4">Static</td><td>Assign a static IP address to the device.</td></tr><tr><td><table><tr><th>Field</th><th>Description</th></tr><tr><td>IP address</td><td>Enter the start IP to assign to the device.</td></tr><tr><td>Subnet mask</td><td>Enter the subnet mask for the device.</td></tr><tr><td>Default gateway</td><td>Enter the default gateway for the device.</td></tr></table></td></tr><tr><td>DHCP</td><td>Enable DHCP on the device.</td></tr></table>	Field	Description	Static	Assign a static IP address to the device.	<table><tr><th>Field</th><th>Description</th></tr><tr><td>IP address</td><td>Enter the start IP to assign to the device.</td></tr><tr><td>Subnet mask</td><td>Enter the subnet mask for the device.</td></tr><tr><td>Default gateway</td><td>Enter the default gateway for the device.</td></tr></table>	Field	Description	IP address	Enter the start IP to assign to the device.	Subnet mask	Enter the subnet mask for the device.	Default gateway	Enter the default gateway for the device.	DHCP	Enable DHCP on the device.
	Field	Description														
	Static	Assign a static IP address to the device.														
		<table><tr><th>Field</th><th>Description</th></tr><tr><td>IP address</td><td>Enter the start IP to assign to the device.</td></tr><tr><td>Subnet mask</td><td>Enter the subnet mask for the device.</td></tr><tr><td>Default gateway</td><td>Enter the default gateway for the device.</td></tr></table>	Field		Description	IP address	Enter the start IP to assign to the device.	Subnet mask	Enter the subnet mask for the device.	Default gateway	Enter the default gateway for the device.					
		Field	Description													
		IP address	Enter the start IP to assign to the device.													
	Subnet mask	Enter the subnet mask for the device.														
	Default gateway	Enter the default gateway for the device.														
	DHCP	Enable DHCP on the device.														
Click Apply to apply the settings or Cancel to return to the previous page.																
SNMP	Enable or disable SNMP on the device, including adding and removing community strings.															
	<table><tr><th>Field</th><th>Description</th></tr><tr><td>SNMP Status</td><td>Enable or disable SNMP on the device. Move the slider to the right to enable SNMP and move it to the left to disable SNMP.</td></tr><tr><td> + </td><td>Add a community string.</td></tr><tr><td>Community type</td><td>Select read-only or read-write as the community string type.</td></tr><tr><td>Community name</td><td>Enter the name of the community string. The maximum number of characters that can be entered is 32.</td></tr><tr><td> </td><td>Remove the community string.</td></tr></table>	Field	Description	SNMP Status	Enable or disable SNMP on the device. Move the slider to the right to enable SNMP and move it to the left to disable SNMP.	+	Add a community string.	Community type	Select read-only or read-write as the community string type.	Community name	Enter the name of the community string. The maximum number of characters that can be entered is 32.		Remove the community string.			
	Field	Description														
	SNMP Status	Enable or disable SNMP on the device. Move the slider to the right to enable SNMP and move it to the left to disable SNMP.														
	+	Add a community string.														
	Community type	Select read-only or read-write as the community string type.														
	Community name	Enter the name of the community string. The maximum number of characters that can be entered is 32.														
	Remove the community string.															
Click Apply to apply the settings or Cancel to return to the previous page.																

Field	Description								
	Set the time zone for the device, including configuring a network time source using Network Time Protocol (NTP) or Simple Network Time Protocol (SNTP). <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Time zone</td><td>Choose the local time zone from the list.</td></tr> <tr> <td>Device time</td><td>Use the time set locally on the device. This can be set using the Date and Time fields.</td></tr> <tr> <td>Use NTP / SNTP server</td><td>Use a network time source for clock synchronization. Choose Domain Name to enter a DNS name and IPv4 to enter an IP address.</td></tr> </tbody> </table> Click Apply to apply the settings or Cancel to return to the previous page.	Field	Description	Time zone	Choose the local time zone from the list.	Device time	Use the time set locally on the device. This can be set using the Date and Time fields.	Use NTP / SNTP server	Use a network time source for clock synchronization. Choose Domain Name to enter a DNS name and IPv4 to enter an IP address.
Field	Description								
Time zone	Choose the local time zone from the list.								
Device time	Use the time set locally on the device. This can be set using the Date and Time fields.								
Use NTP / SNTP server	Use a network time source for clock synchronization. Choose Domain Name to enter a DNS name and IPv4 to enter an IP address.								
	Change the password for selected devices. <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>New password</td><td>Enter the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the string.</td></tr> <tr> <td>Repeat password</td><td>Confirm the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the string.</td></tr> </tbody> </table> Click Apply to apply the settings or Cancel to return to the previous page.	Field	Description	New password	Enter the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the string.	Repeat password	Confirm the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the string.		
Field	Description								
New password	Enter the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the string.								
Repeat password	Confirm the new password to be used with the device. The Show/Hide characters button () can be used to show or hide the string.								
	Change the system name for the device. <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>System Name</td><td>Enter the hostname for the device.</td></tr> </tbody> </table> Click Apply to apply the settings or Cancel to return to the previous page.	Field	Description	System Name	Enter the hostname for the device.				
Field	Description								
System Name	Enter the hostname for the device.								
	Import network a pre-configured network profile into the device. Click Apply to apply the settings or Cancel to return to the previous page.								
	Upgrade the firmware on the device. <table border="1"> <thead> <tr> <th>Field</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Current firmware version</td><td>This displays the current firmware on the device.</td></tr> <tr> <td>Update firmware using a local file</td><td> Drag and drop a firmware file here to upload it to the device, or click Browse to select a file on the local filesystem. Click  to remove the file item from the listed menu. </td></tr> </tbody> </table> Click Upgrade Now to start the upgrade or Cancel to return to the previous page.	Field	Description	Current firmware version	This displays the current firmware on the device.	Update firmware using a local file	Drag and drop a firmware file here to upload it to the device, or click Browse to select a file on the local filesystem. Click  to remove the file item from the listed menu.		
Field	Description								
Current firmware version	This displays the current firmware on the device.								
Update firmware using a local file	Drag and drop a firmware file here to upload it to the device, or click Browse to select a file on the local filesystem. Click  to remove the file item from the listed menu.								

Field	Description																
	Back up or restore the device configuration. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Backup</td><td> <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Filename</td><td>This shows the file name that will be used for the saved configuration file.</td></tr> </table> Click Backup now to begin the backup or Cancel to return to the previous page. </td></tr> <tr> <td>Restore</td><td> Restore the device configuration. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Restore from a previous backup file</td><td>An existing backup must be available. A list of the stored backups is displayed at the bottom of the page. Click Restore to restore a particular file, or press Delete to delete it.</td></tr> <tr> <td>Restore using a local file</td><td> Drag and drop a configuration file here to upload it to the device, or click browse to select a file on the local filesystem. Click  to remove the file item from the listed menu. </td></tr> </table> </td></tr> </table> Click Restore Now to start the upgrade process or Cancel to return to the previous page.	Field	Description	Backup	<table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Filename</td><td>This shows the file name that will be used for the saved configuration file.</td></tr> </table> Click Backup now to begin the backup or Cancel to return to the previous page.	Field	Description	Filename	This shows the file name that will be used for the saved configuration file.	Restore	Restore the device configuration. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Restore from a previous backup file</td><td>An existing backup must be available. A list of the stored backups is displayed at the bottom of the page. Click Restore to restore a particular file, or press Delete to delete it.</td></tr> <tr> <td>Restore using a local file</td><td> Drag and drop a configuration file here to upload it to the device, or click browse to select a file on the local filesystem. Click  to remove the file item from the listed menu. </td></tr> </table>	Field	Description	Restore from a previous backup file	An existing backup must be available. A list of the stored backups is displayed at the bottom of the page. Click Restore to restore a particular file, or press Delete to delete it.	Restore using a local file	Drag and drop a configuration file here to upload it to the device, or click browse to select a file on the local filesystem. Click  to remove the file item from the listed menu.
Field	Description																
Backup	<table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Filename</td><td>This shows the file name that will be used for the saved configuration file.</td></tr> </table> Click Backup now to begin the backup or Cancel to return to the previous page.	Field	Description	Filename	This shows the file name that will be used for the saved configuration file.												
Field	Description																
Filename	This shows the file name that will be used for the saved configuration file.																
Restore	Restore the device configuration. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>Restore from a previous backup file</td><td>An existing backup must be available. A list of the stored backups is displayed at the bottom of the page. Click Restore to restore a particular file, or press Delete to delete it.</td></tr> <tr> <td>Restore using a local file</td><td> Drag and drop a configuration file here to upload it to the device, or click browse to select a file on the local filesystem. Click  to remove the file item from the listed menu. </td></tr> </table>	Field	Description	Restore from a previous backup file	An existing backup must be available. A list of the stored backups is displayed at the bottom of the page. Click Restore to restore a particular file, or press Delete to delete it.	Restore using a local file	Drag and drop a configuration file here to upload it to the device, or click browse to select a file on the local filesystem. Click  to remove the file item from the listed menu.										
Field	Description																
Restore from a previous backup file	An existing backup must be available. A list of the stored backups is displayed at the bottom of the page. Click Restore to restore a particular file, or press Delete to delete it.																
Restore using a local file	Drag and drop a configuration file here to upload it to the device, or click browse to select a file on the local filesystem. Click  to remove the file item from the listed menu.																
	The More button. Click this to display additional device settings.																
	Reboot the device. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>The network will be offline for 60 seconds</td><td>Tick this to confirm that you are aware that the network will be offline for 60 seconds as the device reboots.</td></tr> </table> Click Yes, reboot this device or Cancel to return to the previous page.	Field	Description	The network will be offline for 60 seconds	Tick this to confirm that you are aware that the network will be offline for 60 seconds as the device reboots.												
Field	Description																
The network will be offline for 60 seconds	Tick this to confirm that you are aware that the network will be offline for 60 seconds as the device reboots.																
	Reset the device to the default settings. <table> <tr> <th>Field</th><th>Description</th></tr> <tr> <td>All configuration will be lost</td><td>Tick this to confirm that you are aware that all configuration will be lost when the device is reset.</td></tr> <tr> <td>The system reboots, and be unavailable for roughly 90 seconds</td><td>Tick this to confirm that you are aware that the system will reboot and be unavailable for roughly 90 seconds when the device is reset.</td></tr> <tr> <td>The network will be disconnected shortly</td><td>Tick this to confirm that you are aware that the network will be disconnected shortly after the device is reset.</td></tr> <tr> <td>Keep the IP configuration for this device</td><td>Move the slider to the right to keep the IP configuration for the device. Move it left to include the device IP address in the configuration that will be lost when the device is reset.</td></tr> </table> Click Yes, reset these devices to reset the configuration on the device to the factory default, or Cancel to return to the previous page.	Field	Description	All configuration will be lost	Tick this to confirm that you are aware that all configuration will be lost when the device is reset.	The system reboots, and be unavailable for roughly 90 seconds	Tick this to confirm that you are aware that the system will reboot and be unavailable for roughly 90 seconds when the device is reset.	The network will be disconnected shortly	Tick this to confirm that you are aware that the network will be disconnected shortly after the device is reset.	Keep the IP configuration for this device	Move the slider to the right to keep the IP configuration for the device. Move it left to include the device IP address in the configuration that will be lost when the device is reset.						
Field	Description																
All configuration will be lost	Tick this to confirm that you are aware that all configuration will be lost when the device is reset.																
The system reboots, and be unavailable for roughly 90 seconds	Tick this to confirm that you are aware that the system will reboot and be unavailable for roughly 90 seconds when the device is reset.																
The network will be disconnected shortly	Tick this to confirm that you are aware that the network will be disconnected shortly after the device is reset.																
Keep the IP configuration for this device	Move the slider to the right to keep the IP configuration for the device. Move it left to include the device IP address in the configuration that will be lost when the device is reset.																
	The device journey. This displays the history of changes to the device. Select the From and To date to show a device history for particular dates.																
	Remove the selected device from the inventory list. Click Yes, remove devices to remove the devices from the inventory list, or Cancel to return to the previous page.																

Table 7-1—Device Settings

8 DNA App


The DNA, D-Link Network Assistant app makes the initial setup and ongoing management of your D-Link business networking devices as easy as it should be.

Key Features

- DNA Guides you through initial setup and deployment of new D-Link devices
- DNA Intuitive interface that makes individual device set up easy to understand
- DNA Simultaneously configure multiple D-Link Network devices for greater productivity
- DNA organize D-Link devices into categories with Workspaces for an overall tidier overview of your network
- DNA Support for all your D-Link devices, including access points, routers, switches and WLAN controllers

Download & Install

Get the free DNA app on the App Store or on Google Play. Search for D-Link Network Assistant, then download and install onto your mobile device.



Device List

View and manage a list of devices in your DNA inventory. If this is your first time using DNA, your device will scan for compatible devices in your network.

You can change the settings by clicking the settings button in the top right. From there you can change the search settings to include L3 wireless configurations. Enter an IP range for the L3 configuration.

Cancel
Configuration Discovery
Done

Discover L2/L3 Wireless Configuration

L2


On

L3

On

✓ From to ✗

⊕ Add an IP range





NOTE: Be sure your mobile device is connected to the same Wi-Fi network as your devices are.

Supported Devices

From the Supported Devices menu, view a full list of supported Access Points and Switches. Service Routers and Controllers that are compatible and can be managed with D-Link Network Assistant.

Tap the different drop down menus to see a full list of devices along with their required hardware version and minimum firmware.

Alternatively, search for a specific model using the search function in the top right of your screen.

Supported Devices	
Access Point ▲	
DWL-6620APS FW v4.7.2.5	HW A1 DDP v2 0.24
DWL-7620AP FW v4.7.2.5	HW A1 DDP v2 0.24
DWL-8620AP FW v4.7.2.5	HW A1 DDP v2 0.24
DAP-2682 FW v1.0.0	HW A1 DDP v5 0.00.033
DAP-2720 FW v1.0.0	HW A1 DDP v5 0.00.033
Switch ▼	
Service Router ▼	
Controller ▼	