


Requirement

- SMS-200 V0.3.0 above or SMS-1000SQ Eunhasu V0.3.0 above
- Wifi dongle
 - RTL8812AU chipset

Simple Instruction

Connect Wifi USB dongle into USB port. To setup Wifi feature on Eunhasu, the wired LAN should be connected.



Click 'Wifi' tab in System config page.



System config

Names Background **Wifi**

To change Hostname and workgroup name, replace input box content what you want to change and click 'Save & Reboot system' button.

Host name eunhasu
Enter Host name

Workgroup workgroup
Enter Workgroup name

Save & Reboot system Cancel

System information
Eunhasu Web interface version: V0.3.0
IP address: 11.11.0.6
MAC address: 00:e0:91:20:96:3b
Tag ID: 923727c

Eunhasu information
About
Change Log

Click 'Wifi Router' button to show Wireless Access Point and it will take a few minutes to be detected the AP.

System config

Names Background **Wifi**

Set wifi configurations. If you could not see any 'Wifi Router', please reload page.

On Wifi Router SSID Password Connect


Remove Wifi Information

Cancel


System information
Eunhasu Web interface version: V0.3.0
IP address: 11.11.0.6
MAC address: 00:e0:91:20:96:3b
Tag ID: 923727c

Eunhasu information
About
Change Log

Select AP what you want.




Enter a password or secret if required.




Wait till the progress will be done.






After connecting successfully, you can see IP address like the screen shot below.



If you need remove Wifi connection information, Click 'Remove Wifi Information' button will remove all stored information include the name and password.






- Eunhasu version $\geq$ V0.3.0 required.
- There might be connection error if you use wired and wireless network at the same time.
- Network speed could be degraded depends on wireless network status.
- After wireless connected, use IP address to connect

Reference

Video clip



Device IDs in driver

- 0x050D, 0x1106 : Belkin - sercomm
- 0x050D, 0x1109 : Belkin F9L1109 - SerComm
- 0x2001, 0x330E : D-Link - ALPHA
- 0x7392, 0xA822 : Edimax - Edimax
- 0x0DF6, 0x0074 : Sitecom - Edimax
- 0x04BB, 0x0952 : I-O DATA - Edimax
- 0x0789, 0x016E : Logitech - Edimax
- 0x0409, 0x0408 : NEC -
- 0x0B05, 0x17D2 : ASUS - Edimax
- 0x0E66, 0x0022 : HAWKING - Edimax
- 0x0586, 0x3426 : ZyXEL -
- 0x2001, 0x3313 : D-Link - ALPHA
- 0x1058, 0x0632 : WD - Cybertan*/
- 0x13B1, 0x003F : Linksys WUSB6300
- 0x1740, 0x0100 : EnGenius - EnGenius
- 0x2019, 0xAB30 : Planex - Abocom
- 0x07B8, 0x8812 : Abocom - Abocom
- 0x2001, 0x3315 : D-Link - Cameo
- 0x2001, 0x3316 : D-Link - Cameo
- 0x20F4, 0x805B : TRENDnet - Cameo
- 0x2357, 0x0101 : TP-Link - Archer T4U
- 0x2357, 0x0103 : TP-Link - T4UH
- 0x2357, 0x010D : TP-Link - Archer T4U AC1300
- 0x2357, 0x010F : TP-Link - Archer T4UHP
- 0x148F, 0x9097 : Amped Wireless ACA1

Last Updated: 2020/04/20 01:36

From:

<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:

https://www.docs.sotm-audio.com/doku.php?id=en:how_to_use_wifi_in_eunhasu

Last update: **2020/04/20 01:36**

