




USER'S MANUAL

Charcoal Smoker



THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.





Remark:

H: Screw $\Phi 3 \times 8$
 J/G: Screw $\Phi 6 \times 14$
 L/I: Screw $\Phi 5 \times 10$

A		B			6X		4pcs
	1X		1X				
C		D			2X	 M6	6pcs
	1X		2X				
E		F		 $\Phi 6 \times 14$	12pcs	 M5	7pcs
	2X		1X				
G		H		 $\Phi 5 \times 10$	7pcs	 M3	8pcs
	3X		2X				
I		J		 $\Phi 3 \times 8$	8pcs		
	1X		3X				
W		L					
	1X		6X				

FIRST TIME USE

For the first use, we strongly recommend that you keep it burning for over 30 mins without food load.

USEFUL HINTS AND PRECAUTIONARY MEASURES

This smoker can only be used outdoor.

Always install this product on a solid surface away from inflammable and metal materials.

Do not use the smoker when windy .

Use the smoker only after it is completely assembled and all parts are firmly in place.

Never move the smoker before the fire is completely extinguished and the smoker is cooled off completely.

Keep children and pets at a safe distance when using.

Never use liquid fuel to light or stir up the fire.

Protect yourselves against the fire and steam when opening lid or access doors when the smoker is in use.

INSTRUCTIONS FOR USE

LIGHTING

Remove lid, upper layer body, cooking grates and drip pan.

Make sure charcoal grate sits inside the charcoal pan, and the charcoal pan is securely rested on all 3 legs.

Open door to the lower layer body. If possible, face open door to the wind to enhance fire starting and air circulation within the smoker.

Place charcoal or wood(not pine wood) into a pyramid shape, in the center of the charcoal grate.

Start the fire while leaving lid, upper layer body and drip pan off.

Allow charcoal /wood to burn for about 25 minutes. The coals should be lightly coated in gray ash before starting to cook.

Spread coals/wood evenly over the charcoal grate to obtain even fire. Close door on the lower layer body.

KEEP THE SMOKING GOING

Place drip pan securely on the 3 support brackets of the lower layer body.

You can fill this pan with little bit of water.

Place a cooking grate directly on top of the drip pan. Place food on the cooking grate in a single layer with spaces between each piece. This allows smoke and heat to circulate evenly all around the food.



Place upper layer body on top of the lower layer body. Keep door closed.

Position the other cooking grate on the support brackets of the upper layer body, and make sure the rim of the cooking grate is resting firmly on the support brackets. Place food on the cooking grate.

Place lid on the smoker and start cooking.

COOKING TIPS

During the smoking process, don't lift the lid to check food.

Opened lid allows heat to escape, making additional cooking time necessary.

When removing lid during cooking, lift it towards the side instead of straight up.

Lifting lid straight up creates an air flow within the smoker, which will suck up ashes onto the food.

REGULATING THE FIRE

It's absolutely necessary to keep a consistent, even and low heat environment of +/-158°F inside your smoker. You should just be able to touch the outside of the smoker in area of the dish without burning your hand.

If the fire is too hot, place lid on smoker and close lid air vent. You can also add in some wet wood chips on the fire. This will lower the temperature and also build up a smoldering smoke for enhanced flavor.

If the fire is too low, enlarge lid air vent and access door to the lower layer body to let air in and build up the fire.

ADDING WATER DURING COOKING

Pour water slowly with a funnel or container with a spout through the access door of upper layer body.

ADDING CHARCOAL/WOOD DURING COOKING

Slowly remove lid from smoker, and carefully open access door to the lower layer body with barbecue mitts.

Use a long tong to add charcoal or wood, avoiding to stir-up ashes and sparks.

Close door and place lid back on the smoker once the charcoal or wood is burning strong again.

EXTINGUISHING FIRE

Place lid on the smoker.

Simply close all air vents and doors to extinguish fire. Also try covering coals with sand. Never use water.



EN

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

DE

Mit Ihrer inspirierenden Bewertung wird COSTWAY konsistenter sein, um Ihnen EIN SCHÖNES EINKAUFSERLEBNIS, GUTE PRODUKTE und EFFIZIENTEN SERVICE zu bieten!

FR

Avec votre évaluation inspirante, COSTWAY continuera à fournir une EXPÉRIENCE D'ACHAT PRATIQUE, des PRODUITS DE QUALITÉ et un SERVICE EFFICACE !

ES

Con su calificación inspiradora, COSTWAY será más consistente para ofrecerle EXPERIENCIA DE COMPRA FÁCIL, BUENOS PRODUCTOS y SERVICIO EFICIENTE.

IT

Con la tua valutazione incoraggiante, COSTWAY sarà più coerente per offrirti ESPERIENZA DI ACQUISTO FACILE, BUONI PRODOTTI e SERVIZIO EFFICIENTE!

PL

Dzięki twojej opinii COSTWAY będzie mógł oferować jeszcze WYGODNIEJSZE ZAKUPY, LEPSZE PRODUKTY i SPRAWNIEJSZĄ OBSŁUGĘ KLIENTA.

US office: Fontana

UK office: Ipswich

AU office: Truganina

DE office: FDS GmbH, Neuer Höltingbaum 36, 22143 Hamburg, Deutschland

FR office: Saint Vigor d'Ymonville

PL office: Gdańsk

