




USER MANUAL – EN

IN 21318 Treadmill inSPORTline inCondiT30i



CONTENTS

SAFETY INSTRUCTIONS.....	3
ASSEMBLY	4
TRANSPORTATION	11
CONSOLE	12
MAINTENANCE GUIDE	14
ADJUSTING THE RUNNING BELT.....	14
LUBRICATING THE TREADMILL	15
TROUBLESHOOTING	16
DIAGRAM	18
PARTS LIST	20
ENVIRONMENT PROTECTION	21
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS.....	21



SAFETY INSTRUCTIONS

- Read the manual carefully and keep it for future reference.
- Always clip the safety key to your clothes or belt before starting exercising.
- Move naturally, forward. Do not look on your feet. Only for one person can use the product on the same time.
- Speed increase gradually, not instantly.
- In case of danger, press the stop button or pull out the safety key.
- Leave the device after it stopes moving.
- Follow the assembly instructions. Assembly can be done by adult person.
- Keep away from kids and pets. Do not leave kids and pets unattended near the treadmill. Treadmill is for adults only.
- Before starting any exercise, program ask your physician. It is important if you have heath issues or ongoing treatment or have high blood pressure.
- Regularly check all bolts and nuts. They must be tightened properly. Regularly check the treadmill for damage or signs of wear. Do not use damaged or wear treadmill.
- Regularly check the treadmill for signs of wear or damage. If any sharp edge appears stop using the treadmill.
- Please the treadmill on flat, dry and cleat surface. Keep safety distance of at least 0.6 m around the treadmill. Do not use in humid areas. Do not place the treadmill on thick carpet.
- If the power cable is damaged do not use the device. Buy new one in authorized shop.
- Protect the treadmill from humidity and water.
- Place the treadmill not to cover socket.
- Do not use aerosol sprays in the area around treadmill.
- If the treadmill is running, do not remove the protective cover. If you need to remove the protective cover during maintenance, unplug the treadmill from socket.
- Always wear sport clothes. Do not wear loose clothes that can get stuck. Always wear sport boots.
- Do not turn on the treadmill if you are standing on it. There is a delay when you turn on the treadmill. Before starting the treadmill stand on the side.
- Do not exercise 40 min after eating food.
- Always do warm ups before exercise.
- Do not place foreign object to ventilation or sockets.
- Maintenance should be done only according to the manual, to prolong the lifespan.
- Do not modify the product.
- Exercise reasonably and do not overextend. If you exercise for the first time, hold your handles firmly until you get used to the device.
- In case of error or damage stop the exercising immediately. If the treadmill suddenly increases its speed, remove the safety key.
- Connect the treadmill to socket after the treadmill is assembled. Use only grounded socket.
- If you are not using the device unplug it from socket and safety key removed.
- Any part of the treadmill cannot prohibit the movement of the user.
- Do not use outdoors.



- Do not expose to direct sunlight.
- Do not place in areas with high humidity (pools, sauna etc.)
- Continuous use cannot be longer than 2 hours.
- If the treadmill is not in use, remove the safety key.
- **Operation temperature:** 5 – 40 °C
- **Max. user weight:** 120 kg
- **Category:** HC (according to EN 957) suitable for home use.

SAFETY WARNING: Do not use heart rate sensors in the handle at speeds above 14 km / h.

WARNING! The heart rate monitoring system may not be accurate. Overextending during training can cause serious injury or death. If you feel nauseous, stop the exercise immediately!

ASSEMBLY


The package includes:

No.	Name	Spec.	Picture	Qty.
A	Treadmill			1
B	Console			1
C14	Safety key			1
E08	Power cable			1
B08	Wrench /w screwdriver	S=13, 14, 15		1
B09	Allen key	S5		1
D05	Allen bolts	M8x45		4
D09	Allen bolts	M8x15		4
D24	Washer	Ø8		2
D29	Washer	Ø8		2



STEP 1

Carefully pull out the belt (A) and console (B) out of the box.





STEP 2

Before fixing with bolts, check that the cables from the handles are connected to the cables leading to the posts.

Attach the posts (A04 and A05) to the treadmill (A) with 2x bolts (D05) on each side.

Attach the handrails (A03) to the posts (A04 and A05) with 2x washers (D29) and 2x bolts (D09).




	B09 5#(1x)	D05 M8*45(4x)
		
	D09 M8*15(2x)	D29 $\phi 8$ (2x)
		




STEP 3

Connect the console cables to the cables from the console bracket as shown.

Then attach the console (2) to the console bracket (A03) with 2x washers (D24) and 2x bolts (D09).




	B09 5#(1x)	D09 M8*15(2x)
		
	D24 ø8(2x)	
		





STEP 4

Cut the tape.




STEP 5

Lift the belt and attach the feet (f) to the belt with the screws (b), then attach the feet (f) to the bottom frame with the screws (b).



KROK 6


The treadmill is ready for use, attach the safety key for use and check function.




TRANSPORTATION

Lift the treadmill by the rear part (K) and secure with the bracket (F). Then tip and move the treadmill using the transport wheels.

If the belt is heavy, ask another person for help.



CONSOLE



Button function:

1. **INSTANT INCLINE:** Press 3, 6, 9 to quickly change incline.
2. **INSTANT SPEED:** Press 3, 6, 9 to quickly change speed.
3. **INCLINE +:** Press to increase incline.
4. **INCLINE -:** Press to decrease incline.
5. **START:** Press to turn on the treadmill.
6. **MODE:** Press the button to display TIME, DISTANCE, CALORIES WORKOUT TARGETS, 15 programs, 3 user programs and BODY FAT.
7. **STOP/PAUSE:** Press to stop / pause the treadmill.
8. **SPEED -:** Press to reduce speed.
9. **SPEED +:** Press to increase speed.

Media (optional):

1. **MP3:** Use 3 mm cable to connect.
2. **USB:** You can use USB port to charge your device.

Console function:

1. **Calories:** Display burned calories.
2. **Distance:** Display distance.
3. **Incline:** Display incline.



4. Time: Display time use.
5. Speed: Displays current speed. You can adjust the speed by the buttons.
6. Pulse: Displays the current heart rate. Grasp the sensors on the handles. The sensors start detecting the pulse after 5 seconds. Displayed values are for reference only and are not for medical or healing purposes.
7. Mode: Press the MODE button to change the value of TIME, DISTANCE, CALORIES, 15 programs, 3 user programs and BODY FAT
 - 7.1. Set time, distance and calories: Press the MODE button in the STANDBY MODE, values of time, distance and calorie values lights up.
 - 7.2. Press SPEED +/- or INCLINE +/- buttons to set the speed and incline values.

Press the START button to start the treadmill in 3 seconds.

Press SPEED +/- to adjust the speed.

Press INCLINE +/- to adjust the incline.
 - 7.3. 5 preset programs: Press MODE repeatedly in STANDBY MODE to display the 15 preset programs.

Use the SPEED +/- and INCLINE +/- buttons to set the training value.

Each program is divided into 10 parts, the console will sound a sound when entering a new segment.

Use the SPEED +/- and INCLINE +/- buttons to adjust the speed and incline of each segment.

The console sounds 6 beeps when the program is completed.
 - 7.4. 3 user programs: Press MODE repeatedly in STANDBY MODE to display 3 user programs.

Use the SPEED +/- and INCLINE +/- buttons to set the training value.

Each program is divided into 10 parts, the console will sound a sound when entering a new segment.

Use the SPEED +/- and INCLINE +/- buttons to adjust the speed and incline of each segment.

The console sounds 6 beeps when the program is completed.
 - 7.5. To start the body fat test: Press MODE repeatedly, in STANDBY MODE, FAT is displayed.

Press MODE to enter.

Use the SPEED +/- buttons to set the values. F-1 to F-4 values (F-1 - GENDER, F-2 - AGE, F-3 HEIGHT, F-4 WEIGHT)

Then use the MODE button to enter F-5 (BODY FAT TEST), grasp the sensors on the handles and the console will display the values after 3 seconds.

Values are for guidance only and are not for medical or healing purposes.

F-1	GENDER	01 MALE	02 FEMALE
F-2	AGE	10 – 99	
F-3	HEIGHT	100 – 200 cm	
F-4	WEIGHT	20 – 150 kg	
F-5	RESULT	≤ 19	Underweight
	RESULT	20-25	Normal weight
	RESULT	26-29	Overweight
	RESULT	≥30	Obesity



LUBRICATION NOTIFICATION

The treadmill automatically alerts the user. A warning is displayed after 300 km. The console will sound a beep every 10 seconds and the OIL will be displayed. Read the user manual before lubricating and then apply the lubricant to the center of the treadmill. After lubrication, press the STOP button for 3 seconds to turn off the alarm and notification.

SAFETY KEY

If the safety key is removed during exercising, the treadmill will stop. The display shows --- together with the beep. The treadmill will not work until the key is inserted again.

SAVING MODE

The belt is equipped with a power saving mode that starts after 10 minutes when the treadmill is not in use. Console shuts down, press any button to wake up console,

TURNIN ON / OFF THE TREADMILL

Press the button to turn on / off the treadmill (I) and (O) .

WARNING

- We recommend that you start exercising at a slower speed. Hold on to the handrails until you are confident to start exercising on higher speeds.
- Connect the safety key to the console and then to your clothes. In case of malfunction or problems, pull out the key.
- To stop safely, press the STOP button or remove the safety key.

MAINTENANCE GUIDE

General cleaning will help to prolong the life and improve performance on your treadmill. Keep the unit clean and maintained by dusting the components on a regular basis, cleaning the two exposed sides of the running belt to prevent dust from accumulating underneath the belt. Keep your running shoes clean so that dirt from the shoes does not wear the running belt. Clean the surface of the running belt using a clean damp cloth. Keep liquids away from electrical parts and running belt.


To prolong the lifespan of the treadmill it is recommended to turn it off every 2 hours of continues use for at least 10 minutes.

A loose running belt will result in the runner sliding off when running, while too tight running belt will result in decrease of the motors performance and will also create more friction between the roller and running belt. The most suitable tightness for the belt is distance of 50-75mm from the running board.


ADJUSTING THE RUNNING BELT

Place the treadmill on level ground and set it at 3.5 – 5 km/h to check and see if the running belt (20) drifts from the center.



If the running belt (20) drifts to the right, turn the adjusting bolt on the right side $\frac{1}{4}$ turn clockwise, then turn the left adjustment bolt $\frac{1}{4}$ turn counter-clockwise. If the belt does not move, repeat this step until it centers. Refer to image A.



If the running belt (20) drifts to the left, turn the adjusting bolt on the left side $\frac{1}{4}$ of a turn clockwise, then turn the right adjustment bolt $\frac{1}{4}$ turn counter-clockwise. If the belt does not move, repeat this step until it centers. Refer to image B.



Over time, the running belt (20) will loosen. To tighten the belt, turn both the left & right-side adjustment bolts one full turn clockwise. Check the tension of the belt. Continue this process until belt is at the correct tension. Make sure to adjust both sides equally to ensure even belt alignment. Refer to image C.



LUBRICATING THE TREADMILL

Lubricating the running belt & the running board is essential as the friction affects the life span and operations of the treadmill. Therefore, we suggest you to inspect the running belt regularly.

WARNING: Always unplug the treadmill from the electrical outlet before cleaning, lubricating, or repairing the unit.

The following time table is recommended:

Light user (less than 3 hours/week)	Every 6 months
Medium user (3 - 5 hours/week)	Every 3 months
Heavy user (more than 5 hours/week)	Every 2 months


How to lubricate the treadmill:

Lift up the belt on one side and apply a lubricant, then apply lubricate to entire surface with a cloth. repeat on the other side.

All moving parts must move freely and quietly. Abnormal movement may impair product safety. Check and tighten all screws regularly.

Proper and regular maintenance extends the lifespan of the treadmill.





TROUBLESHOOTING


PROBLEM	CAUSE	SOLUTION
Treadmill will not start	Not plugged in.	Plug the cord into the outlet.
	Safety key not inserted.	Insert safety key.
Running belt not centered	Running belt tension not proper on the left or right side of the running board.	Tighten the adjustment bolts on the left and right side of the rear roller.
Computer not working	Wires from the computer and bottom control board not properly connected.	Check wire connections from the computer to the control board.
	Transformer is damaged.	If the transformer has become damaged, contact customer service.
E01 & E13: Communication failure	No communication from console to control board.	Check wire connections from the computer to the control board and replace wires and/or control board if necessary.
E02: Burst clash protection	Incoming voltage is lower than 50% of the required voltage.	Check the incoming voltage against the required voltage. Check wire connections to the motor. Check the control board, replace if necessary.
E05: Current overload protection (Self Protecting System))	The incoming voltage is too low or too high. The control board is damaged.	Restart the treadmill. Check if the incoming voltage is correct. Check the control board, replace if damaged.



	A moving part of the treadmill is stuck and therefore the motor is unable to rotate properly.	Inspect the moving parts of the treadmill to ensure that they are operating correctly. Check the motor, listen for strange noises and check for a burning smell. Replace the motor if necessary.
E06: Motor error	The motor wire is not connected or the motor is damaged.	Check motor wires to see if the motor is connected. If the wire has been punctured or damaged, you will need to replace it. If the problem is not solved, you may need to replace the motor
E08: Control Board Abnormality	The control board is not connected.	Check the upper and middle wires to see if the control board is connected. If the wire has been punctured or damaged, you will need to replace it. If the problem is not rectified, you may need to replace the control board.
E10: Motor abnormality	The motor is damaged or a moving part of the treadmill is stuck and therefore the motor is unable to rotate properly.	The torque is too big, please adjust the torque. Check moving parts of the treadmill to ensure that they are operating correctly. Replace the motor if necessary. Lubricate the treadmill.



DIAGRAM



PARTS LIST

No.	Name	Spec.	Qty.	No.	Name	Spec.	Qty.
A01	Base frame		1	C21	Ring-shape wire plug		2
A02	Main frame		1	C22	EVA cushion		1
A03	Console bracket		1	C23	EVA cushion		2
A04	Left upright tube		1	C24	Console wire cover		1
A05	Right upright tube		1	D01	Nut	M6	6
A06	Incline bracket		1	D02	Nut	M8	8
A07	Console fixed bracket		1	D03	Nut	M10	6
B01	Front roller		1	D04	Bolt	M10*55 L20	4
B02	Back roller		1	D05	Bolt	M8*55	4
B03	Safety key shrapnel		2	D06	Bolt	M8*40 L20	4
B04	Left pulse steel plate		2	D07	Bolt	M8*30 L15	1
B05	Right pulse steel plate		2	D08	Bolt	M8*25	2
B06	Cylinder		1	D09	Bolt	M8*15	6
B07	Incline bracket bushing		8	D10	Bolt	M10*45 L15	1
B08	Wrench w/screw driver	S=13, 14, 15	1	D11	Bolt	M6*65	2
B09	5# Allen wrench	5 mm	1	D12	Bolt	M6*55	1
C01	Motor top cover		1	D13	Bolt	M6*35	6
C02	Motor bottom cover		1	D14	Bolt	M5*16	4
C03	Left back end cover		1	D15	Bolt	M5*12	7
C04	Right back end cover		1	D16	Bolt	M5*10	2
C05	Decorative cushion		2	D17	Screw	ST4.2*45	4
C06	Side rail		2	D18	Screw	ST4.2*20	8
C07	Console top cover		1	D19	Screw	ST4.2*12	18
C08	Console bottom cover		1	D20	Screw	ST4.2*12	20
C09	Panel top cover		1	D21	Bolt	M10*95 L25	1
C10	Pane bottom cover		1	D22	Screw	ST2.9*8	20
C11	Handle cover		2	D23	Screw	ST2.9*6	4
C12	Running belt		1	D24	Lock washer	8	8
C13	Motor belt		1	D25	Lock washer	10	6
C14	Safety key		1	D26	Flat washer	8	6
C15	Blue cushion		6	D27	Bolt	M8*55 L20	2
C16	Transport wheel		2	D28	Spring washer	8	2
C17	Square plug		2	D29	Arc-gasket	8	2
C18	Adjustable wheel		2	D30	Lock washer	6	3
C19	Foot pad		4	D31	Bolt	M8*15	2
C20	Washer		2	D32	Bolt	M5*15	2



E01	Running board		1	E23	Safety key sensor bottom signal wire		2
E02	DC motor		1	E24	Keyboard connecting wire		1
E03	On-off switch		1	E25	Incline motor		1
E04	Overload protector		1	F01	Filter		1
E05	Power socket		1	F02	Inductance		1
E07	Magnetic core		1	F03	AC single wire		1
E08	Power wire		1	F04	Grounding wire		1
E09	AC signal wire	Brown 200	1	F05	Screw	ST4.2*12	4
E10	AC signal wire	Brown 350	2	H01	USB board		1
E11	AC signal wire	Blue 350	2	H02	USB power wire		1
E12	Ground wire		1	H03	Screw	ST2.9*8	2
E14	Console		1	G01	Power amplifier board		1
E15	Control board		1	G02	Audio input and output board		1
E16	Top signal wire		1	G03	Power amplifier power wire		1
E17	Middle signal wire		1	G04	Audio socket wire		1
E18	Bottom signal wire		1	G05	Speaker 1		1
E19	Hand pulse top signal wire		1	G06	Speaker 2		1
E20	Hand pulse bottom signal wire		2	G07	Mp3 wire		1
E21	Keyboard		1	G08	Screw	ST2.9*8	14
E22	Safety key sensor top signal wire		2				

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.



The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the



damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ
SEVEN SPORT s.r.o.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR
Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK
inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723
VAT ID: SK2020177082

Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk

