

Be sure to read this manual before use

XPERIA 1V

SOG10

Quick Start Guide

Packaged items

Before you start using the product, make sure that you have all these packaged items with the product.

- Main unit


- ・クイックスタートガイド (Quick Start Guide) (Japanese)




These items are not included in the package.

- microSD memory card
- AC adapter
- Earphones
- USB Type-C™ cable

- Information

- Purchase a specified charger (sold separately).
 - The battery is built into the product.
 - Illustrations used in this manual are just images for explanations. They may be different from actual ones.

Names and functions of parts




- 12 Power key/Fingerprint sensor
- 13 Shutter key
- 14 Flash/Photo light
- 15 5G/4G antenna*3
- 16 Main camera
- 17 Third microphone*1*2
- 18 4G antenna/Wi-Fi®/Bluetooth®/GPS antenna*3
- 19 mark
- 20 Back cover*4
- 21 5G antenna*3
- 22 Wireless charging position
- 23 Wi-Fi®/Bluetooth® antenna*3
- 24 SIM card*5

- *1 Do not jab with a sharp object such as a needle. Doing so may cause a malfunction.
- *2 Note that covering these parts with stickers or fingers, etc. may hinder product performance.
- *3 The antenna is built into the main unit. Covering around the antenna by your hand may affect the quality of call/communication.
- *4 The back cover is not removable. Removing forcibly might cause damage or a malfunction. Also, battery is built into the main unit and not removable by customers.
- *5 For details on handling SIM card, refer to “取扱説明書 詳細版 (Full instruction manual)” (Japanese).

SIM card

Your phone number etc. is recorded in SIM card.




Attaching SIM card

Before attaching SIM card, make sure to turn off the product.


- 1 Remove the tray from the main unit

Put your fingertip (nail) into the groove of the microSD memory card/SIM card slot and draw the cover straight out.




- 2 Set SIM card into the tray with the IC (metal) part facing up

Pay attention to the location of the notch. Surely set SIM card into the tray not to come off.



- 3 Keep the product horizontal and then push the tray in straight

Pay attention to the direction the tray is being pushed in. Firmly press where circled O, and check that there is no gap between the main unit and the microSD memory card/SIM card slot cover.



Turning the power on/off

Turning the power on

- 1 Press and hold Power key until the product vibrates

When the product is powered on, the lock screen appears. When “ようこそ (Welcome)” appears after the product is powered on, follow the onscreen instructions to set the initial settings. Swiping (flicking) the screen up displays the Home screen.

Turning the power off

- 1 Press Power key and the upper part of the volume key at the same time

■ Information

・ To restart the product in safe mode (start with almost default state), press Power key and the upper part of the volume key at the same time → Long-touch “Power off” → [OK].

Forcedly turning the power off

- 1 Press and hold Power key and the upper part of the volume key at the same time for 10 seconds or more, and release your fingers after the product vibrates three times consecutively

FCC ID

To view the regulatory compliance mark

- In the Home screen, slide the screen up → [Settings] → [About phone] → [Certificates] Regulatory compliance mark such as FCC ID is displayed on the screen.

When using the product

Before you start using the product, make sure to read the “Safety Precautions” to ensure correct use.

Before you assume that the product is malfunctioning, refer to “故障とお考えになる前に (Check here first)” in “取扱説明書 詳細版 (Full Instruction Manual)” (Japanese).

- Communication is not possible even inside of the service area in places where the signal does not reach (e.g. tunnels and basements). Also, communication is sometimes not possible in poor signal reception areas. Communication is sometimes interrupted if you move into poor signal reception area during communication.
- Since the product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated. (Though 5G/LTE/WiMAX 2+/GSM/UMTS system has highly secure confidential communication features.)
- For connecting to the emergency call acceptance organization, only VoLTE (LTE network) can be used.
- Since the product is a radio station under the Radio Law, you may be asked to temporarily submit the product for inspection in accordance with the Radio Law.
- The IMEI information of your mobile phone is automatically sent to your carrier for maintenance and monitoring operational status of your mobile phone.
- Before you start using the product overseas, check the relevant laws and regulations of the country/region you visit.
- The Company is not liable for any damages or lost income arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentional, mistaken, or incorrect use by the customer, or use under other unusual conditions outside the responsibility of the Company.
- The Company is not liable for any incidental damages (change/disappearance of described content, loss of business income, disruption of business, etc.) arising from use of the product or inability to use the product.
- The Company is not liable for any damages or lost income arising from failure to observe the described content of the “Instruction Manual”.
- You cannot use information obtained from the measuring sensor or GPS equipped with the product for the purpose which requires high reliability, as the obtained information is just used for a guide. Note that the Company is not liable for any damage or lost income arising from the difference caused by measurement.
- The Company is not liable for any damages or lost income arising, for example, from malfunction caused by combination with connected devices or software not related to the Company.

- Captured image data or downloaded data may sometimes be altered or lost due to faults, repair or other handling of the product. The Company is not liable for any damage or lost income resulting from recovery of these data.
- It is recommended you keep a copy of important data on your PC’s hard disk etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data.
- Data saved in the product, such as images/videos, might be altered or lost by an accident, fault, repair or mishandling. Be sure to keep a copy of important contents. Note that the Company assume no responsibility for any damages or lost income resulting from altered or lost contents.
- Note that contents data (both charged or free content) saved to the product cannot be returned to the customer when the product is replaced for repair of a fault, for example.
- Although an afterimage may occur when a same screen has been displayed for a long time, it is not a malfunction. You are recommended to set the sleep time to a short one to avoid occurrence of afterimage and save the battery consumption.
- Although the display used for the product is made using high-precision technology, some pixels (dots) might be lit or out at all times. This is not a malfunction.
- It is recommended that you store separate copies of data such as still pictures/videos and music saved on the product on your PC or cloud services, etc. Note, however, that you may not be able to make copies of any copyrighted data even by the above-mentioned means.
- Do not discard the product together with regular trash. Please cooperate in the collection of the product (including optional accessories) when it is no longer needed to protect the environment and effectively use resources.
- “The Company” as appears in the manual refers to your carrier and the manufacturer (Sony Corporation).

- Notice

- Reproduction of the content of “Instruction Manual” in part or in whole is prohibited.
 - The content of “Instruction Manual” is subject to change without notice.
 - Some functions may be unavailable due to change of specification of the OS or change/termination of services.
 - Every effort has been made in the preparation of “Instruction Manual”. Should you notice any unclear points, omissions, etc., feel free to contact us.

Safety Precautions (Observe Strictly)

- Before using this product, thoroughly read these safety precautions for proper use.

■ These “Safety Precautions” describe instructions that should be observed to prevent damage to property or injury to the customer or others using the product.

■ The following symbols indicate the different levels of injury or damage that may result if the guidelines are not observed and the product is used improperly.

	Danger	This symbol indicates that “death or serious injury” ^{*1} may directly and immediately result from improper use*.
	Warning	This symbol indicates that “death or serious injury” ^{*1} may result from improper use*.
	Caution	This symbol indicates that “minor injury” ^{*2} and/or property damage ^{*3} may result from improper use*.

- *1 Serious injury: This refers to loss of sight, injury, burns (high- and low-temperature), electric shock, broken bones, injuries with residual aftereffects from poisoning etc., and injuries requiring hospital admission for treatment or long-term hospital attendance as an outpatient.
- *2 Minor injury: This refers to injuries, burns (high- and low-temperature), electric shock, etc. that do not require hospital admission for treatment or long-term hospital attendance as an outpatient.
- *3 Property damage: This refers to extended damage to buildings, furniture, livestock, pets, etc.

Explanation of graphic symbols

	Indicates an action that is not allowed.		Indicates that handling with wet hands is not allowed.
	Indicates that disassembly is not allowed.		Indicates compulsory actions in accordance with instructions.
	Indicates that use in a place where the product is likely to get wet or allowing the product to get wet is not allowed.		Indicates that the power plug must be disconnected from an outlet.

Precautions common to the main unit, internal battery, charging equipment, SIM card, peripheral devices

	Danger	Be sure to read the following hazards before use.
	Do not use, store or leave the equipment in a location where it is subject to high temperature or accumulation of heat (e.g. by the fire, near a heater, under a kotatsu or bedding, in direct sunlight, in a car in the hot sun).	Doing so might cause fire, burns, injury, electric shock, etc.
	Do not put the equipment in cooking appliances such as microwave ovens, IH cooking heaters, or high pressure containers such as pressure cookers. Do not place the equipment near such cooking appliances.	Doing so might cause fire, burns, injury, electric shock, etc.
	Do not splash sand, soil or mud, or do not directly place the equipment on it. Also, do not touch the equipment with hands with sand etc. adhered.	Doing so might cause fire, burns, injury, electric shock, etc.
	Do not splash sand, soil or mud, or do not directly place the equipment on it. Also, do not touch the equipment with hands with sand etc. adhered.	Doing so might cause fire, burns, injury, electric shock, etc.
	Do not splash sand, soil or mud, or do not directly place the equipment on it. Also, do not touch the equipment with hands with sand etc. adhered.	Doing so might cause fire, burns, injury, electric shock, etc.
	Do not splash sand, soil or mud, or do not directly place the equipment on it. Also, do not touch the equipment with hands with sand etc. adhered.	Doing so might cause fire, burns, injury, electric shock, etc.

Caution

Be sure to read the following cautions before use.

	Caution	Be sure to read the following cautions before use.
	When using the motion sensor, check the safety around you, hold the product firmly, and do not shake it unnecessarily.	Failure to do so might cause an accident such as injury.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.
	If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and hands, clothes, etc.	Doing so might cause injury etc. on your eyes or skin. If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water. In the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.

Magnetic components are used in the product’s main camera (top right of display, top left on back), earpiece/speaker (top center of display), speaker (bottom left on back), and vibrator (top right on back); make sure no metal objects (cutter blade, staple, etc.) are attached to the product. Attached objects might cause injury, etc.

Do not leave the main unit in the reach of children or persons requiring supervision.

The product uses magnets. If swallowed, there is a risk of choking or serious harm to internal organs. If the magnet has been swallowed, immediately consult a doctor.

Do not bring the main unit near medical devices.

The product uses magnets; they may affect pacemakers, variable-pressure hydrocephalus shunts, and other medical devices. Do not bring the product near persons using these devices. If you use such a device, consult your doctor before using the product.

Watch the display in an adequately bright place taking a certain distance from it.

Watching in a dark place or closely might reduce visual acuity etc.

Charging equipment

	Warning	Be sure to read the following warnings before use.
	Do not use the specified charging equipment (sold separately) or Wireless Charging Pad (sold separately) if the cable is damaged.	Doing so might cause fire, burns, electric shock, etc.
	If you hear thunder, do not touch the specified charging equipment (sold separately) or Wireless Charging Pad (sold separately).	Doing so might cause electric shock etc.
	Do not short-circuit the charging terminal while it is connected to an outlet. Do not touch the charging terminal with your hands, fingers, or any part of your body.	Doing so might cause fire, burns, electric shock, etc.
	Do not place heavy objects on a cable of the specified charging equipment (sold separately) or Wireless Charging Pad (sold separately), or do not apply unreasonable force to the cable such as pulling.	Doing so might cause fire, burns, electric shock, etc.

Do not allow liquids such as water (drinking water, sweat, seawater, urine of pet animals, etc.) to get inside the charging terminal, the USB Type-C port, or the headset jack.

Doing so might cause fire, burns, injury, electric shock, etc.

For waterproofness, refer to “Notes on waterproof and dustproof properties” (▶P.29).

Use only optional parts specified by the Company for the product.

Using devices other than specified, or those with indefinite manufacturer, retailer, or specifications might cause fire, burns, injury, electric shock, etc.

Warning

Be sure to read the following warnings before use.

	Do not subject the equipment to strong force, impacts, or vibration such as letting it fall, stepping on it or throwing it.	Doing so might cause fire, burns, injury, electric shock, etc.
	Do not allow conductive materials (such as metal objects and pencil lead) to come into contact with the charging terminal, the USB Type-C port, or the headset jack, or allow dust to get inside of it.	Doing so might cause fire, burns, injury, electric shock, etc.
	Do not cover or wrap the equipment with a cloth or bedding in use or while charging.	Doing so might cause fire, burns, etc.
	Do not attach a metal object (e.g. a sticker whose material contains metal) to the Wireless Charging Pad (sold separately) or the product.	Doing so might cause fire, burns, injury, etc.
	Do not place a metal object (e.g. a strap or clip whose material contains metal) between the Wireless Charging Pad (sold separately) and the product.	Doing so might cause fire, burns, injury, etc.
	Remove the cover etc. from the product when charging with the Wireless Charging Pad (sold separately).	Charging may fail depending on material or thickness of cover or foreign object between the product and the cover resulting in fire, burns, injury, etc.

Do not contact metal objects to the specified charging equipment (sold separately) when connecting the plug to or disconnecting it from an outlet.

Doing so might cause fire, burns, electric shock, etc.

Do not connect the voltage converter (such as a travel converter for overseas travel) to the specified charging equipment (sold separately).

Doing so might cause ignition, overheating, electric shock, etc.

Do not put an excessive force to the connection part with the specified charging equipment (sold separately) connected to the product.

Doing so might cause fire, burns, injury, electric shock, etc.

Do not charge the product when it is wet with liquids such as water (drinking water, sweat, seawater, urine of pet animals, etc.) with the Wireless Charging Pad (sold separately).

Also, do not charge the product in a place where water comes in contact such as bathroom or near a humidifier.

Doing so might cause fire, burns, injury, electric shock, etc.

Never connect the USB Type-C plug to the product or the specified charging equipment (sold separately) when it is wet.

Although the product has the waterproof property, inserting USB Type-C plug to the product when it is wet might cause electric shock or short-circuit due to the moisture or foreign substance on the product or USB Type-C plug, or might cause abnormal overheating, fire damage, fire, burns, or a fault if corrosion occurs.

Do not touch the cable, charging terminals or power plug of the specified charging equipment (sold separately) or Wireless Charging Pad (sold separately) with wet hands.

Doing so might cause fire, burns, electric shock, etc.

Power off the product near electronic devices or equipment operating on high precision control or weak signals.

The radio waves from the product might interfere with the operation of electronic devices or equipment.

- * The following are some electronic devices or equipment that you should be careful of: Hearing aids, implantable cardiac pacemaker, implantable cardioverter defibrillator, other electronic medical equipment, and other automatically controlled devices or equipment. If you use an implantable cardiac pacemaker, implantable cardioverter defibrillator, or other electronic medical equipment, check with the medical electronic equipment manufacturer or vendor whether the operation can be affected by radio waves.

If charging does not finish after specified time, stop charging.

Failure to do so might cause fire, burns, injury, etc. due to overcharge etc.

Always turn off the product before you enter a place where flammable gas may be present, or a place where dusts are generated. Stop charging the product if you are charging it.

Ignition of flammable gas might cause explosion, fire, etc.

Follow the instructions of a gas station or other such location before using the product there.

Do not charge the product at a gas station, etc.; in particular, do not use the product while filling. Ignition of flammable gas might cause explosion, fire, etc.

If you notice anything unusual about the equipment such as an unusual odor, abnormal noise, smoke generation, overheating, discoloration or deformation during operation, charging or storage, perform the following measures carefully.

- Remove the power plug from an outlet
- Turn off the power of the product

Failure to do so might cause fire, burns, injury, electric shock, etc.

Caution

Be sure to read the following cautions before use.

Do not use damaged product or peripheral devices.

Doing so might cause fire, burns, injury, etc.

Use the adapter only on the specified power supply and voltage.

When charging the battery overseas, use AC adapter that can be used overseas (sold separately).

Using the incorrect power supply and voltage might cause fire, burns, electric shock, etc.

AC adapter (sold separately): 100V AC (Connect to the AC outlet for internal household use)

AC adapter (sold separately) that can be used overseas: 100V AC to 240V AC (Connect to the AC outlet for internal household use)

Clean dust from the power plug.

Using it with dust adhered might cause fire, burns, electric shock, etc.

Firmly insert the specified charging equipment (sold separately) into an outlet.

Insecure inserting might cause fire, burns, electric shock, etc.

When you disconnect a power plug of the specified charging equipment (sold separately) from an outlet, do not apply excessive force to it such as pulling the cable. Instead, hold the adapter main unit to disconnect.

Pulling the cable of the specified charging equipment (sold separately) might damage the cable causing fire, burns, electric shock, etc.

If you wear electronic medical equipment such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator, consult a doctor for using the Wireless Charging Pad (sold separately) in advance.

The radio waves from the product might have harmful effects on the operation of the electronic medical equipment.

When plugging/unplugging the specified charging equipment (sold separately) into/from the product, plug/unplug it straight toward the product without applying excessive force such as pulling the cable.

Incorrect plugging/unplugging might cause fire, burns, injury, electric shock, etc.

If the charging terminal is deformed such as being bent, stop using immediately. Do not use it with the deformation restored.

Doing so might cause fire, burns, injury, etc. due to short-circuit of the charging terminal.

