

1. Package Contents

Thank you for purchasing PLANET Industrial 5G NR Cellular Gateway, ICG-2515 series. The descriptions of these models are as follows

ICG-2515-NR	Industrial 5G NR Cellular Gateway with 5-Port 10/100/1000T
ICG-2515W-NR	Industrial 5G NR Cellular Wireless Gateway with 5-Port 10/100/1000T

“Cellular Gateway” is used as an alternative name in this Quick Installation Guide.

Open the box of the **Cellular Gateway** and carefully unpack it. The box should contain the following items:

- Industrial 5G NR Cellular Gateway x 1
- Quick installation guide x 1
- PLANET CloudViewer QIG x1
- Wall-mount plate w/screw x 1 set
- RJ45 dust cap x 6
- 5G NR antenna x 4
- 5G NR antenna extension with magnetic base x 4
- Dual band Wi-Fi antenna x 2 (for ICG-2515W-NR)
- Antenna dust cap x 4 (ICG-2515W-NR x 6)

If any item is found missing or damaged, please contact your local reseller for replacement.

2. Requirements

- Workstations running Windows 10/XP/2003/Vista/7/8/2008, MAC OS X or later, Linux, UNIX, or other platforms are compatible with TCP/IP protocols.
- Workstations are installed with Ethernet NIC (Network Interface Card).
- Ethernet Port Connection
 - Network cables -- Use standard network (UTP) cables with RJ45 connectors.
 - The above PC is installed with Web browser.

Note

It is recommended to use Internet Explorer 8.0 or above to access the Cellular Gateway. If the Web interface of the Cellular Gateway is not accessible, please turn off the anti-virus software or firewall and then try it again.

3. Hardware Installation

Refer to the illustration and follow the simple steps below to quickly install your **Cellular Gateway**.

3.1 SIM Card Installation


A. Insert an ejector pin into the yellow button next to the tray to loosen the tray.



B. Pull out the tray gently from the tray slot. Place the SIM card on the tray with the gold-colored contacts facing upwards.

C. Insert the tray back into the tray slot.

A mini SIM card with 5G NR and 4G LTE subscription



3.2 5G NR Antenna Installation

Step 1: Connect 5G NR antennas to the 5G NR antenna extension.


Step 2: Fasten the 5G NR antenna extensions to the connectors.



3.3 Wi-Fi Antenna Installation

Step 1: Fasten the two dual-band antennas to the antenna connectors on the front panel of the Cellular Gateway.

Step 2: You can bend the antennas to fit your actual needs.



Two Wi-Fi RP-SMA connectors


3.4 Wiring the Power Inputs

The 6-contact terminal block connector on the top panel of Cellular Gateway is used for two redundant power inputs. Please follow the steps below to insert the power wire.

Caution

When performing any of the procedures like inserting the wires or tightening the wire-clamp screws, make sure the power is OFF to prevent from getting an electric shock.


1. Insert positive and negative DC power wires into contacts 1 and 2 for POWER 1, or 5 and 6 for POWER 2.



Note

Please make sure the input voltage is under the specification of the Cellular Gateway.

2. Tighten the wire-clamp screws for preventing the wires from loosening.



Note

The wire gauge for the terminal block should be in the range between 12 and 24 AWG.

Note


PWR1 and PWR2 must provide the **same DC voltage** while operating with dual power input.

3.5 Grounding the Device

User MUST complete grounding wired with the device; otherwise, a sudden lightning could cause fatal damage to the device. EMD (Lightning) DAMAGE IS NOT COVERED UNDER WARRANTY.

3.6 Wiring the Fault Alarm Contact

The fault alarm contacts are in the middle of the terminal block connector as the picture shows below. Inserting the wires, the Cellular Gateway will detect the fault status of the power failure or port failure, and then will form an open circuit. The following illustration shows an application example for wiring the fault alarm contacts



Insert the wires into the fault alarm contacts


Note

1. The wire gauge for the terminal block should be in the range between 12 and 24 AWG.
2. Alarm relay circuit accepts up to 24V (max.) and 1A current.

4. Starting Web Management

The following shows how to start up the **Web Management** of the Cellular Gateway. Note the Cellular Gateway is configured through an Ethernet connection. Please make sure the manager PC must be set to the same **IP subnet address**.

For example, the default IP address of the Cellular Gateway is **192.168.1.1**, then the manager PC should be set to **192.168.1.x** (where x is a number between 2 and 254), and the default subnet mask is 255.255.255.0.



The DHCP server of the Cellular Gateway is enabled. Therefore, the LAN PC will get IP from the Cellular Gateway.

4.1 Logging in to the Cellular Gateway

1. Use Internet Explorer 8.0 or above Web browser and enter IP address **<http://192.168.1.1>** (the factory default IP address or the one that you have just changed in console) to access the Web interface.
2. When the following dialog box appears, please enter the default user name **"admin"** and password **"admin"** (or the password you have changed before) as shown in Figure 4-2.

Default IP Address: **192.168.1.1**
Default User Name: **admin**
Default Password: **admin**
Default SSID (2.4G): **PLANET_2.4G (for ICG-2515W-NR)**
Default SSID (5G): **PLANET_5G (for ICG-2515W-NR)**



Figure 4-2: Login Screen

3. After entering the password, the main screen appears as shown in Figure 4-3.



Figure 4-3: Web-based Main Screen of Cellular Gateway

Now, you can use the Web management interface to continue the Cellular Gateway management or manage the Cellular Gateway by console interface. Please refer to the user's manual for more.

Administrators are strongly suggested to change the default password and Wi-Fi SSID on the first login to safeguard system security.

5. Recovering Back to Default Configuration

■ IP address has been changed or admin password has been forgotten –

To reset the IP address to the default IP address **"192.168.1.1"** or reset the login password to default value, press the hardware **reset button** on the front panel for about **15 seconds**. After the device is rebooted, you can log in the management Web interface within the same subnet of 192.168.1.xx.



Figure 5-1: ICG-2515-NR Series Reset Button



Quick Installation Guide

www.PLANET.com.tw

Industrial 5G NR Cellular Gateway
with 5-Port 10/100/1000T
ICG-2515-NR/ICG-2515W-NR

PLANET Technology Corp.
10F., No. 96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan

Warning:
This device is compliant with Class A of CISPR 32.
In a residential environment this device may cause radio interference.
2010-B90470-000



6. Customer Support

You can browse our online FAQ resource and User's Manual on PLANET Web site first to check if it could solve your issue. If you need more support information, please contact PLANET support team.

PLANET online FAQs:
<https://www.planet.com.tw/en/support/faq.php?method=keyword&keyword=ICG-2515>

Support team mail address:
support@planet.com.tw

ICG-2515-NR and ICG-2515W-NR User's Manual:
<https://www.planet.com.tw/en/support/downloads?&method=keyword&keyword=ICG-2515&view=3#list>



Copyright © PLANET Technology Corp. 2021.
Contents are subject to revision without prior notice.
PLANET is a registered trademark of PLANET Technology Corp.
All other trademarks belong to their respective owners.