

ISOVOX

ISOPOP

INSTALLATION AND USER INSTRUCTIONS

Version 1.00 | 2022

INTENDED USE

The ISOPOP is intended to be used as a mountable pop filter for professional vocal recording. The ISOPOP is intended to be used on standard microphone stands. The ISOPOP should only be used in households, normal recording studios or similar environments.

The product shall only be used according to the instructions as described in this manual. All use other than described in this manual is seen as unintended use. This will also invalidate the warranty.

SAFETY INSTRUCTIONS


WARNING

Read and understand this manual and its safety instructions before using this product. Failure to do so can result in injury or material damage.

- Never leave children unattended with the packaging material. The packaging material represents a danger of suffocation. Children frequently underestimate the dangers. Always keep children away from the packaging material. The ISOPOP is not a toy.
- Never leave children unattended with the product. The product is made out of small components that may form a choking hazard.
- Do not clamp the product onto your fingers or any other body parts. This may cause personal injury.
- Do not clamp any devices with too much force, this may cause material damage.
- Only use the product when correctly and completely installed. Be aware that the manufacturer cannot be held responsible for personal injuries or material damage resulting from the incorrect installation of the product.
- Always keep the instructions for future reference. The information in this manual is subject to change without notice.


PRODUCT ELEMENTS

- a. Housing
- b. Pop filter
- c. Thumbscrew
- d. Pin holder
- e. Clamp
- f. Neck



HOW TO USE THE ISOPOP


1. Loosen the **thumbscrew** (C) and put the **clamp** (E) around a **microphone stand** (not included). Tighten the **thumbscrew** (C) to safely attach the **ISOPOP** to a **microphone stand**.



2. Put the **pop filter** (B) in front of the **microphone** (not included) by articulating the **neck** (F).


NOTICE

Carefully articulate the neck. Using too much force may break the neck.




HOW TO CLEAN THE ISOPOP

1. Push the **pop filter** (B) out of the **housing** (A).




2. Clean the **pop filter** (B) with water under a faucet.



3. Wring the **pop filter** (B) out and leave it to dry.
4. Push the **pop filter** (B) back into the **housing** (A).

NOTICE

Make sure the pop filter is dry before pushing it back into the housing. Water may drip onto the microphone and cause damage.



DISPOSAL

The packaging is made of environmentally friendly materials, which may be disposed of through your local recycling facilities. By disposing of the packaging and packaging waste in the proper manner, you help to avoid possible hazards for the environment and public health.

ISOVOX AB, Skyttevägen 41, 302 44, Halmstad, Sweden - www.isovoxbooth.com

