



All-in-1 ConfCam 1080P Remote

Quick guide


134-23



www.sandberg.world



Product overview




- 1** Blue LED indicator for video ON/OFF
- 2** HD wide view angle lens
- 3** Tilt movement wheel
- 4** Omni-directional microphone
- 5** Work status LEDs Indicator
- 6** Speaker
- 7** Touch buttons (see scheme next page)
- 8** USB-C port

Touch buttons ⑦ and LED indicator ⑤

Touch buttons		LED indicator color	
	Microphone Mute	Blue	Microphone working
		Red	Mute Microphone
	HiFi Mode	Blue	Conference Interaction
		Green	HiFi mode for music playing
	Volume Down	LED Indicator blinking while Volume down	
	Volume Up	LED indicator blinking while Volume UP	

NOTE: Mic is automatically muted if in "HiFi mode" (LED is green).

Connect webcam to USB port on computer




Software installation


The camera works driver-less and is compatible with most chat-applications.

If you want to get further options for video-effects and image adjustments, please follow this link:
www.sandberg.world/webcamguide

Choose this device name on the device list
for video-camera, speaker and
recording microphone:



Remote control



Open the back of the remote control and insert 2 x AAA batteries.

Digital Pan, Tilt and Zoom functions (EPTZ)


Zoom:

The camera supports EPTZ 3x digital zoom. When you zoom into the image the option opens for moving Up / Down (Tilt) and Left / Right (Pan).






1. Press Zoom+  on the remote control to zoom in image.



Zoom+




2. After the image is zoomed in, you can move the image viewing angle Up / Down (Tilt) and Left / Right (Pan).



Picture in Picture (PIP)


After the image is zoomed in, you can see the full out-zoomed image in a small overlay frame (PIP).



1. Press "Camera OSD Menu (Middle)", select "Image".



2. Select "PIP" to "On". Picture in Picture function turns on, users can see small picture-in-picture window at the bottom of right.



On-Screen-Display (OSD) menu




Image Setup

► Exposure

Brightness: Adjust image brightness Adjustable Value: 0-255; Default: 64
 Backlight: Adjust the backlight Optional: Off / On; Default: Off
 AE: Adjust the exposure settings Optional: Auto/ Shutter; Default: Auto
 Shutter: Shutter speed Optional: 1/10000-1/25; Default: 1/25
 Flicker: Anti-flicker adjustment Optional: 50/60; Default: 50
 Back: Back to previous menu

► Color

Hue: Adjust image hue Optional: 0-100; Default: 50
 Saturation: Adjust image saturation Optional: 0-100; Default: 50
 Sharpness: Adjust image sharpness Optional: 0-127; Default: 50
 WB: Select white balance mode Optional: Auto/Manual; Default: Auto
 Color Temp: Adjust color temperature Optional: 1500-15000; Default: 5000
 Back: Back to previous menu

► Image

Image Flip: Mirror and rotate image Optional: Off/All/Flip/Mirror;
 Default: Off
 Frame: Select image frame Optional 30/25; Default: 30
 Image Mode: Select image style Optional Normal/Clear/Bright/Beauty
 Default: Normal

PIP: Picture in picture function, Optional: Off/On;
Default: Off

Back: Back to previous menu

► **Information**

Version: Firmware version info.

Model: Camera model info.

Date: Firmware version date.

*The information may vary according to product updates.

► **Language**

OSD menu language.

► **Restore Defaults**

Restore camera parameters to default values.



1. No Pan/Tilt movement function while OSD Menu on screen.
2. Shutter can only be adjusted if it is selected as Shutter in the AE menu.



Support

<http://helpdesk.sandberg.world>

Warranty

*There is a five-year warranty on your Sandberg product.
Please read the warranty terms and register your new
Sandberg product at www.sandberg.world/warranty*

5
Years
Warranty

For information on handling electronic waste, see www.sandberg.world/weee

