



EN Instruction manual

الاستخدام



220-240V~ / 50/60Hz / 1300-1500 W  
Toaster Steel Style 2 long slot  
جهاز تصميص الخبز طويل  
صنع في الصين  
01.142389.09.001

PARTS DESCRIPTION / وصف الأجزاء



[WEEE Logo]



## EN Instruction manual

### SAFETY

- By ignoring the safety instructions the manufacturer cannot be held responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord cannot become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Keep the appliance and its cord out of reach of children less than 8 years.
- The temperature of accessible surfaces may be high when the appliance is operating.
- The bread may burn, therefore do not use the toaster near or below combustible material, such as curtains.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- To prevent fire or shock hazard do not expose this appliance to rain or moisture.

- Surface is liable to get hot during use.
- This appliance is intended to be used in household and similar applications such as:
  - Staff kitchen areas in shops, offices and other working environments.
  - By clients in hotels, motels and other residential type environments.
  - Bed and breakfast type environments.
  - Farm houses.

### PARTS DESCRIPTION

- Bread groove
- Crumb tray
- Bun warmer
- Color controller
- Lift handle
- Defrost button
- Reheat button
- Cancel button

### BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- Put the power cable into the socket. (Note: Make sure the voltage which is indicated on the device matches the local voltage before connecting the device. Voltage 220V-240V 50/60Hz)
- When the device is turned on for the first time, a slight odour will occur. This is normal, ensure adequate ventilation. This fragrance is only temporary and will disappear soon.

### USE

- The device is adjustable with the color controller of just crispy roasted to dark brown. To achieve the degree of browning desired, you can experiment with the setting. Also the quality and condition of the bread is also a factor. Dry and stale bread toasts more quickly, fresh and frozen bread take a little longer. Do not use a knife, cutlery or any other object to remove the bread from the device or to clean the device. If the bread becomes lodged in the toaster, unplug the appliance before attempting to remove it. Caution! Bread can burn.
- Put a slice of bread in one of the slots. Make sure the crumb tray is in place before use.
- Plug the power cord into a grounded outlet. Turn the color controller to your desired position. Press the handle completely down to start the toasting process.
- Once the bread has been toasted to the desired color, the handle will pop up automatically.
- During toasting, you can check the color of the bread. If it is to your satisfaction, you can press the cancel button to cancel the operation at any time.
- If the bread is frozen, perform the same operations and press the defrost button. The indicator will be illuminated. In this mode the bread will be toasted to your desired color.
- If you want to reheat cold toasted bread, press the reheat button and the indicator will be illuminated. This mode has a fixed time setting.
- The carriage handle will automatically spring up and end up the reheating process.
- The toaster is equipped with a bun warmer, this rack can be used for warming up buns and baguettes.

### CLEANING AND MAINTENANCE

- Before cleaning, unplug the appliance and wait for the appliance to cool down.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the electrical device in water or any other liquid. The device is not dishwasher proof.
- Pull out the crumb tray and remove the crumbs. By using the device frequently, repeat this every week.
- Do not use a metal object (fork, knife ....) to clean the inside of the appliance as this may damage the heating elements.

### WARRANTY

- This product is warrantied for 2 Years, for detailed terms, please refer to the Warranty Card.
- Following parts are not covered by warranty:
  - Knobs.
  - Any broken body parts.

Approximate life of this appliance under normal conditions is 3 Years.

For service and repairs, please call the following numbers:

United Electronics Co.  
Saudi Arabia (Toll-free) 800 124 0900

### ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

### Support

You can find all available information and spare parts at  
www.princesshome.eu!

## AR دليل الإرشادات

### السلامة

- تجاهل تعليمات السلامة، لا يمكن اعتبار الشركة المصنعة مسؤولة عن التلف.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله من قبل الشركة المصنعة أو وكيل الخدمة أو الأشخاص المؤهلين بالمثل لتجنب المخاطر.
- لا تقم أبدًا بنقل الجهاز عن طريق سحب السلك وتأكد من أن السلك لا يمكن أن يتشابك.
- يجب وضع الجهاز على سطح مستو وثابت.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء
- هذا الجهاز مخصص للاستخدام في الأغراض المنزلية وللغرض المصنوع من أجله فقط.
- لا يجوز استخدام هذا الجهاز من قبل الأطفال الذين تقل أعمارهم عن 8 سنوات. يمكن استخدام هذا الجهاز من قبل الأطفال الذين تتراوح أعمارهم بين 8 سنوات وما فوق والأشخاص ذوي القدرات البدنية أو الحسية أو العقلية المتخفضة أو الأشخاص الذين لديهم نقص في الخبرة والمعرفة إذا تم تزويدهم بالإشراف أو التعليمات المتعلقة باستخدام الجهاز بطريقة آمنة ويفهم المخاطر المتضمنة. يجب عدم لعب الأطفال بالجهاز. اجعل الجهاز والسلك الخاص به بعيدين عن متناول الأطفال الذين تقل أعمارهم عن 8 سنوات. يجب عدم تنظيفه وصيانته من قبل الأطفال إلا إذا كان عمرهم أكبر من 8 سنوات ويتم الإشراف عليهم.
- لحماية نفسك من الصدمة الكهربائية، لا تمس السلك أو المقيس أو الجهاز في المياه أو أي سائل آخر.
- احرص على وضع الجهاز والسلك بعيدًا عن متناول الأطفال الأقل من 8 سنوات.
- قد تكون درجة حرارة الأسطح الظاهرة مرتفعة عند تشغيل الجهاز.
- قد يتعرض الخبز للاحتراق لذلك لا تستخدم جهاز التحميص بالقرب من مادة قابلة للاحتراق أو أسفل منها مثل الستائر.
- هذا الجهاز غير مخصص للتشغيل من خلال مؤقت خارجي أو نظامتحكم عن بعد منفصل.
- لا تعرض هذا الجهاز للمطر أو الرطوبة لمنع مخاطر حدوث حريق أو صدمة كهربائية.

- السطح معرض للتسخين أثناء الاستخدام.
- هذا الجهاز مخصص للاستخدام المنزلي وللاستخدام في الأماكن المشابهة مثل:
  - أماكن مطابخ الموظفين في المتاجر والمكاتب وأماكن العمل الأخرى.
  - أو من قبل نزلاء الفنادق والاستراحات والأماكن السكنية الأخرى.
  - والأماكن التي تقدم مينيًا ووجبة إفطار.
  - والمنازل الريفية.

### وصف الأجزاء

- فتحة الخبز
- صينية الخبز
- حامل تسخين الكيك
- تحكم في درجة اللون
- الرفع لأعلى
- زر الذاكرة
- زر إعادة التسخين
- زر الإلغاء

### قبل الاستخدام الأول

- قم بإخراج الجهاز والملحقات خارج العلية. قم بإزالة الملصقات، أو البلاستيك أو ورق الألومنيوم الواقى عن الجهاز.
- ضع الجهاز على سطح ثابت مستو وتأكد من وجود حد أدنى من المساحة الخالية حول الجهاز قدرها 10 سم. هذا الجهاز غير مناسب للتركيب في خزانة أو للاستخدام الخارجي.
- ضع كبل الطاقة في المقيس. (ملاحظة: تأكد من أن الجهد الذي يشار إليه على الجهاز يتطابق مع الجهد المحلي قبل توصيل الجهاز. الجهد 220 فولت- 240- فولت 50/60 هرتز)
- عند تشغيل الجهاز للمرة الأولى، ستصدر رائحة خفيفة. هذا أمر طبيعي، تأكد من وجود تهوية كافية. هذه الرائحة ما هي إلا رائحة مؤقتة وستختفي سريعًا.

### الاستخدام

- إن الجهاز قابل للضبط باستخدام وسيلة التحكم في درجة اللون سواء للخبز المحمص والمقرمش حتى البني الداكن. للحصول على درجة اللون البني المطلوبة، يمكنك تجربة الإعدادات. كذلك تعتبر جودة الخبز وحمالته أحد العوامل. يحمص الخبز المكافء والثابت أسرع بكثير، بينما يستغرق الخبز الطازج والمجمد وقتًا أطول. لا تستخدم السكين أو أدوات المائدة أو أية أشياء أخرى لإزالة الخبز من الجهاز أو لتنظيفه. إذا أصبح الخبز ملتصقًا في جهاز التحميص، قم بفصل الجهاز من المقيس قبل محاولة إزالة الخبز. تنبيه! يمكن أن يتعرض الخبز للاحتراق.
- ضع شريحتين من الخبز في إحدى الفتحتين. تأكد من تركيب صينية الخبز في مكانها قبل الاستخدام.
- ومثل سلك الطاقة بالمخرج المؤمّزض. اضبط وسيلة التحكم في اللون على الوضع المرغوب. اضغط على المقيس إلى الأسفل بأكامل لتبدأ عملية التحميص.
- بعدد أن يأخذ الخبز المحمص درجة اللون المطلوبة، سيرفع المقيس لأعلى تلقائيًا.

- أثناء التحميص، يمكنك تفقد لون الخبز. إذا كان لون الخبز مرضيا بالنسبة لك، يمكنك الضغط على زر الإلغاء لإلغاء التشغيل في أي وقت.
- إذا كان الخبز مجمد، قم بإجراء العمليات نفسها واضغط على زر إزالة التجميد. سيضئ المؤشر. في هذا الوضع، سيتم تحميص الخبز حسب اللون الذي ترغب فيه.
- إذا كنت ترغب في إعادة تسخين الخبز المحمص البارد، اضغط على زر إعادة التسخين وسيضيء المؤشر. يحتوي هذا الوضع على إعداد وقت ثابت.
- سينتفع مقيض الحاضن التوماتيكيًا إلى أعلى وستنتهي عملية إعادة التسخين.
- مخمصة الخبز مزودة بحامل تسخين الكيك يمكن استخدامه لتسخين الكيك والخبز الفرنسي.

### التنظيف والصيانة

- قبل التنظيف فصل الجهاز من المقيس وانتظر حتى يبرد الجهاز.
- نظف الجهاز بقطعة قماش رطبة. لا تستخدم مطلقًا مواد تنظيف قوية أو كاشطة، أو اللوف الخشن أو الألياف السليكية التي قد يتسبب في تلف الجهاز.
- احرص ألا تمس الجهاز الكهربائي أبدًا في الماء أو أي سائل آخر. لا يمكن تنظيف الجهاز في غسالة الأطباق.
- امسح صينية الفتات إلى الخارج وقم بإزالة الفتات. عند استخدام الجهاز عدة مرات، كرر هذا كل أسبوع.
- لا تستخدم أداة أدوات معدنية (شوكة، سكين ....) لتنظيف الجهاز من الداخل؛ لأن ذلك قد يثلف عناصر التسخين.

### ضمان

- هذا الجهاز مضمون لمدة عامين. لمعرفة أحكام الضمان يرجى قراءة كرت ضمان المنتج.
- المكونات أبدًا غير مشمولة بالضمان:

– المقابض.

– أجزاء البدن القابلة للكسر.

العمر الافتراضي للجهاز يعتمد على ظروف التشغيل العادية. العمر الافتراضي 3 سنوات تقريبا. يرجى الاتصال على أرقام خدمة الصيانة والتصلج الآتية:

الشركة المتحدة للإلكترونيات

المملكة العربية السعودية (الهاتف المجاني) 800 124 0900

### البيئة



لا ينبغي وضع هذا الجهاز في قمامة المنازل في نهاية مثته، ولكن يجب تقديمه في أي نقطة مركزية تقوم بإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. يقوم هذا الرمز الموجود على الجهاز وتبلى التعليمات والتعبئة بلفت انتباهك إلى هذه المشكلة المهمة. يمكن إعادة تدوير الأجزاء المستخدمة في هذا الجهاز. عن طريق إعادة تدوير الأجهزة المنزلية المستخدمة، فإك تساهم في دفع عجلة حماية بيئتنا. اسأل السلطات المحلية للحصول على معلومات بشأن النقطه التي تقوم بإعادة التدوير.

### الدعم

يمكنك الحصول على جميع المعلومات وقطع الغيار المتوفرة عبر الموقع الإلكتروني  
www.princesshome.eu

Made in China

صنع في الصين

© Princess 2020

