

Bluetooth Speaker Rezo Home Series One  User Manual Thank you for purchasing Bluetooth Speaker Rezo Home Series One. Please carefully read user guide in properly and keep this for further reference.	1 Fashionable and elegant design. Portability, easy to carry. 2 Use a high-performance Bluetooth module for smoother use. 3 With TF card, USB, Support MP3 and other music format decoding. 4 Support for call function. 5 High-efficiency digital amplifier, green and environmentally friendly. 6 Built-in lithium-ion battery for repeated charging. 7 Built-in high quality speakers. The sound quality is pure and beautiful. 8 Built-in bass boost diaphragm design, the bass is outstanding. Specifications: Bluetooth version: 5.0 Wireless transmission distance: 10m(without obstacles) SNR: >85dB Speaker: 40SW*2 Charging voltage: DC 5V Key Function Description: PWR: Power button, Long press the switch. Play/pause/receive call/hang up call/callback call/automatic search. M: MODE KEY / press to change mode. -: Previous song/previous radio, long press volume minus. + : Next song/next station, long press volume plus. Light button: Short press this button light. There are several modes of breathing.	Port Guide: AUX: AUX input TF: TF/Micro TF card USB: USB DC 5V: Charging input Bluetooth Mode: Turn on the phone/ other devices or press the mode button to switch to the Bluetooth mode. And the ringtone prompt is synchronized, the machine will prompt the Bluetooth status, and after pairing with other devices and successfully connected, Bluetooth music and Bluetooth call functions can be realized. Using TF/USB: Insert the TF card/USB, the machine will automatically recognize and play the music of the TF card. At this time, the playback control can be performed by the previous song, play/pause, etc. FM radio operation Link the CHG line first and then enter the mode button M to switch the radio mode. Press the Power button to enter the radio search mode. When it find a clear radio, then it will continue to search for the next clear radio. After searching for all clear stations, it will stop automatically. Choose to press the "+" "-" key, select the station to start listening. Using AUX: Plug the audio cable into the AUX port of the machine and connect it to the headphone output jack of your phone or computer. Press the button M to switch to the external audio mode. You can play music by turning on the audio software of your phone or computer.	Attention 1 If you saw smoke coming out of the machine or other improper phenomenon , please contact the retailer to solve the issue immediately 2 If the machine get wet by the rain, please make it dry by anyway 3 Do not bake the machine, it will easy to burn and damage the electronic components. 4 Do not play the machine under burning sun or any hot environment. 5 Do not throw the machine. 6 Do not try to replace the battery by yourself. Note! In order to improve product performance, our products are constantly updated. It is no additional notice about technical issues and this manual is for reference only, please forgive. Thank you for your purchase.
--	---	---	---

Loa Bluetooth Rezo Home Series One  Hướng dẫn sử dụng Cảm ơn bạn đã lựa chọn Loa Bluetooth Rezo Home Series One. Vui lòng kỹ hướng dẫn để sử dụng đúng cách và giữ lại để tham khảo thêm.	1 Thiết kế thời trang và thanh lịch. Có tính di động, dễ mang theo. 2 Sử dụng sản phẩm có Bluetooth hiệu suất cao để sử dụng mượt mà hơn. 3 Với thẻ TF, USB, hỗ trợ MP3 và đầu vào nhiều nguồn phát nhạc khác nhau. 4 Hỗ trợ chức năng nghe gọi. 5 Bộ khuếch đại kỹ thuật số hiệu suất cao, thân thiện với môi trường. 6 Pin lithium-ion tích hợp để sạc nhiều lần. 7 Tích hợp loa chất lượng cao. Chất lượng âm thanh trong trẻo và chân thực. 8 Thiết kế mang loa tích hợp làm nổi bật âm thanh. Thông số kỹ thuật: Phiên bản Bluetooth: 5.0 Khả năng cách truyền không dây: 10m (không có chướng ngại vật) Tỷ lệ tín hiệu tín hiệu: >85dB Công suất loa : 40SW*2 Điện áp sạc: DC 5V Mô tả chức năng chính: Phản: Ngủ nguồn, Nhấn và giữ công tắc. Phản/Nhấn dừng/nhấn cuộc gọi/giữ cuộc gọi/gọi lại/tìm kiếm tự động. M: MODE KEY / nhấn để thay đổi chế độ qua chế độ kết nối khác: Bluetooth/ TF card/ FM/USB. -: Nhấn nhanh để phát bài hát /đổi phát thành trước đó, nhấn và giữ nút giảm âm lượng để giảm âm thanh. +: Nhấn nhanh để phát bài hát /đổi phát thành tiếp theo, nhấn và giữ nút tăng âm lượng để tăng âm thanh. Nút đèn: Nhấn nhanh nút này để có thể chuyển qua những màu sắc ánh sáng khác nhau.	Hướng dẫn sử dụng cổng kết nối: AUX: Đầu vào AUX – Jack 3.5 TF: Thẻ TF/Micro USB: USB DC 5V: Đầu cắm sạc Chế độ Bluetooth: Bật đèn thoại/ thiết bị nghe nhạc khác có thể kết nối Bluetooth hoặc nhấn nút M để chuyển sang chế độ Bluetooth nếu đang sử dụng chế độ khác. Và âm thanh sẽ vang lên, thiết bị sẽ gọi ý trạng thái kết nối Bluetooth; sau khi kết nối với thiết bị thành công thì có thể nghe nhạc và sử dụng chức năng nghe gọi bằng Bluetooth. Sử dụng TF/USB: Cắm thẻ TF/USB, máy sẽ tự động nhận dạng và phát nhạc của thẻ TF. Tại thời điểm này, các nút điều khiển có thể sử dụng để tìm bài hát trước hoặc sau đó, phát/tạm dừng, v.v. Hoạt động của đài FM Liên kết dây sạc trước rồi nhấn nút M để chuyển chế độ radio. Nhấn nút nguồn để vào chế độ tìm đài. Khi tìm thấy một kênh có tín hiệu, thì loa sẽ tiếp tục tìm kiếm kênh có tín hiệu tiếp theo. Sau khi tìm kiếm tất cả các kênh có tín hiệu, thiết bị sẽ tự động dừng tìm kiếm. Khi đó chọn nhấn phím "+" "-", sau đó có thể chọn đài bất kỳ nghe. Sử dụng AUX: Cắm đầu 3.5 vào cổng AUX của loa và kết nối nó với giắc cắm đầu ra của điện thoại hoặc máy tính của bạn. Nhấn nút M để chuyển sang chế độ âm thanh được kết nối với AUX. Bạn có thể phát nhạc bằng cách bất nhạc trên điện thoại hoặc máy tính kết nối với dây AUX.	Chú ý 1 Nếu bạn nhìn thấy khói bốc ra từ loa hoặc hiện tượng bất thường khác vui lòng liên hệ với nhà bán lẻ để giải quyết vấn đề ngay lập tức. 2 Nếu loa bị ướt, hãy làm khô bằng mọi cách. 3 Không để thiết bị ở nơi có nhiệt độ cao sẽ dễ làm cháy và hỏng các linh kiện điện tử. 4 Không sử dụng máy dưới trời nắng gắt hoặc bất kỳ môi trường có nhiệt độ cao nào. 5 Không tác động mạnh hoặc để vật nặng lên loa. 6 Không tự ý thay pin. Ghi chú! Để nâng cao hiệu suất của sản phẩm, sản phẩm của chúng tôi được cập nhật liên tục. Nội dung có thể thay đổi mà không báo trước và sách hướng dẫn này chỉ mang tính chất tham khảo, mong bạn thứ lỗi. Cảm ơn bạn vì đã mua hàng.
---	--	---	--

要求：105克铜版纸 单色双面印刷 风琴折页 成品尺寸：90*67mm

