105克铜版纸，彩印,装钉
142.50 mm
GEEPAS (GK38050)说明书20210427
193.00 mm

GEEPAS®

ELECTRIC TURKISH COFFEE MAKER

MODEL NO.:GK38050
www.geepas.com
WESTERN INTERNATIONAL

Dear Customer,

You are now a proud owner of a Geepas product. Let's welcome you to the Geepas customer family. We hope you will be happy using it as millions of our satisfied customers already are. Our products continue to be the favorites on account of their superior quality, reliability and performance.

In order to provide you the ultimate satisfaction, the minutest part of each product is thoroughly tested and examined under stringent conditions. The objective of Geepas is to bring cutting edge technology to your everyday life.

In the unlikely event that the product needs warranty service, please refer the enclosed warranty card.

Although it is highly improbable, yet in case you have any issues with the product kindly contact your nearest Geepas dealer or get in touch with us directly. We assure you that an appropriate action would be taken as per our customer service policy.

Before you start enjoying the product we strongly urge you to spare a few minutes to go through this manual so that you may derive the maximum benefits out of the product.

General Safety Guidelines

Read the user manual before operating any appliance or equipment.

1. Check the voltage available at your home and ensure that it matches with the voltage mentioned on your appliance, before switching it on.
2. The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are under supervision or have been given correct and necessary instructions.
3. If the power cord is damaged, please get it replaced at a service center or by a person who is designated by the manufacturer or a qualified person, in order to avoid electric shock.
4. Always keep the unit on a dry and flat surface.
5. Never touch any appliance or equipment with wet or damp hands.
6. While plugging or unplugging a power cord, hold it by the plug; never pull the cord.
7. Do not connect the equipment to an extension cord or a multiple socket adaptor. Always connect the unit to the main socket; this is to prevent short circuits and sparks, which can shorten the life of the unit and prove risky for your life.
8. Do not let the power cord hang over the edge of the table or a work surface as a sharp edge can damage the cable over a period of time.
9. Do not let it get tangled or come into contact with a hot surface.
10. Do not attempt to repair the unit in case of any malfunction, always take it to an authorized service center.
11. Do not use any attachments other than the ones supplied by or specified by the manufacturer.
12. Never leave the unit unattended while in operation especially, when children are around.
13. Children should be supervised to ensure that they do not play with the appliance.
14. The equipment is for household use only, do not use it for commercial purposes.
15. All appliances and equipment are designed for indoor use. Do not use them outdoors unless specifically mentioned in the instruction manual.
16. Always unplug the unit from the power source during lightning and thunderstorms, or when the unit is not going to be used for a long period of time.
17. To avoid risk of electric shocks, do not immerse the equipment in water or use it in damp conditions.
18. The unit should be cleaned with a damp cloth and immediately wiped dry. Do not use detergents or chemical cleaning agents to clean the unit.
19. Always clean cooking appliances soon after use, this will prevent food from sticking to the unit and the possible bacterial growth.
20. WARNING: If the surface is cracked, switch off the appliance to avoid electric shock.

تعليمات سلامة عامة

اقرأ دليل المستخدم قبل تشغيل أي جهاز
تحقق من الفولطية المتوفرة في منزلك وتأكد من مطابقتها للجهد المذكور على الجهاز
١ ، قبل تشغيله
لا يجوز استخدام الجهاز من قبل الأشخاص (بالاضافة الأطفال) بقدرات مادية أو حسية
أو عقلية منخفضة ، أو عدم وجود خبرة ومعرفة ، إلا إذا كانوا تحت إشراف أو تم
٢ .إعطاء التعليمات الصحيحة والضرورية
٣ .لا تقم بتشغيل أية أجهزة لها سلك طاقة تالف
في حالة تلف سلك الطاقة ، يرجى استبداله من مركز خدمة أو بواسطة شخص معين من
٤ .قبل الشركة المصنعة أو شخص مؤهل ، لتجنب الصدمات الكهربائية
٥ .احتفظ بالوحدة دائمًا على سطح جاف ومسطح
٦ .لا تلمس أبدًا أي جهاز بأيد مبللة أو رطبة
٧ .أثناء توصيل سلك الطاقة أو فصله ، احتفظ به بواسطة القابس ؛ أبدا لاتسحب السلك
لا تقم بتوصيل الجهاز بسلك توصيل أو بمحول مقبس متعدد. قم دائمًا بتوصيل الوحدة
بالمقبس الرئيسي ؛ هذا هو لمنع الدوائر القصيرة والشرر ، والتي يمكن أن تقصر عمر
٨ .الوحدة وتثبت خطرا على حياتك
لا تدع سلك الطاقة معلقاً على حافة الطاولة أو على سطح العمل لأن الحافة الحادة قد
تؤدي إلى تلف الكابل على مدى فترة زمنية. لا تدعها تتشابك أو تتلامس مع سطح
٩ .ساخن
لا تحاول إصلاح الوحدة في حالة وجود أي عطل ، فتأخذ دائمًا إلى مراكز خدمة
١٠ .معتمد
لا تستخدم أي مرفقات غير المرفقات المقدمة من قبل الشركة المصنعة أو المحددة
١١ .منها
١٢ .لا تترك الوحدة دون مراقبة أثناء تشغيلها خصوصاً عندما يكون الأطفال حولها
١٣ .يجب الاشراف على الاطفال للتأكد من أنهم لا يلعبون مع الجهاز
١٤ .المعدات مخصصة للاستخدام المنزلي فقط ، ولا تستخدمها لأغراض تجارية
جميع الأجهزة والمعدات مصممة للاستخدام في الأماكن المغلقة. لا تستخدمها في
١٥ .الهواء الطلق ما لم يذكر على وجه التحديد في دليل التعليمات
قم دائمًا بفصل الوحدة عن مصدر الطاقة أثناء الصواعق والعواصف الرعدية ، أو عند
١٦ .عدم استخدام الوحدة لفترة طويلة من الزمن
لتجنب خطر التعرض للصدمات الكهربائية ، لا تغمس المعدات في الماء أو استخدمها
١٧ .في ظروف رطبة
يجب تنظيف الوحدة بقطعة قماش رطبة ومحوها على الفور. لا تستخدم المنظفات أو
١٨ .مواد التنظيف الكيميائية لتنظيف الوحدة
قم دائماً بتنظيف أجهزة الطهي بعد وقت قصير من الاستعمال ، وهذا سيمنع الغذاء من
١ .الوصول إلى الوحدة والنمو البكتيري المحتمل
تحذير: إذا كان السطح مكسورا ، فقم بإيقاف تشغيل الجهاز لتجنب الصدمات
١ .الكهربائية

1. Pouring mouth
2. Kettle body
3. Indicator light
4. Handle
5. Base
6. Switch



1. By using your coffee maker, you can prepare coffee.
2. Before first use, fill the coffee maker with clean water to maximum capacity and boil. Discard the water and repeat the process.
3. The coffee maker should always be unplugged when filling or adding water.
4. Fill the coffee maker with water to the desired level. Do not overfill or there will be a risk of spillage or spitting. The water level indicator will assist you to measure the correct amount.
5. Put sufficient quantity of cold water into your coffee maker according Max.300ML
6. Place the appliance onto the power base unit, and switch on the coffee maker by simply pressing on/off switch by GEEPAS coffee maker.
7. At this time mix you r coffee for one or two times using stainless steel measuring and mixing spoon
8. When the coffee starts bloating out, turn off the appliance and pour a little coffee into the cups.
9. Replace your appliance onto the power base unit and restart the coffee maker, then pour the coffee to the cup when the prepared coffee bloats out again.
10. You can prepare coffee in different measures according to your personal taste.
11. An automatic safety cut-out has been fitted for protection against running dry. If you do not put in enough water, or switch on when it is empty, the safety cut-out will switch off the power automatically. If this happens, wait a few minutes for the element to cool,then refill and use as normal.
12. Place the power base on a dry, flat surface. Place the coffee maker on the power base. The electrical connection will be made automatically as the coffee maker slides onto the power base.
13. Plug the cord set into an earthed power socket and switch on by depressing the switch of the coffee maker to the"ON" position. for GEEPAS coffee maker.
14. Let GEEPAS coffee maker After allowing the coffee maker to cool down for 15-12 seconds, the water can be brought back to the boil by pushing the switch back to the"ON" position. During the cooling down time do not force the on/off switch into the "ON" position as this can damage the operating mechanism.

15. Do not remove the coffee maker from the power base without switching off first.
16. Remember, if you do not wish to re-boil the coffee, switch it off.
17. The coffee maker may be switched off manually at any time by setting the on/off switch into the "OFF" position.
18. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
19. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
20. This appliance is intended to be used in household and similar applications such as:
    - Staff kitchen areas in shops, offices and other working environments
    - Farm houses
    - By clients in hotels, motels and other residential type environments
    - Bed and breakfast type environments
21. Potential injury may cause from misuse
22. Switch off the appliance and disconnect from supply before changing accessories or that move in use approaching parts

HOW TO CARE FOR YOUR COFFEE MAKER

Wipe the exterior of the coffee maker with a soft, damp cloth or sponge. Remove stubborn spots with a cloth moistened with mild liquid detergent. Do not use abrasive scouring pads or powers. Never immerse the coffee maker in water or other liquids.
From time to time, dependent on the nature of your water supply, a lime scale deposits naturally formed and can be found mostly adhered to the heating element, thus reducing the heating capacity. The amount of lime scale deposited (subsequently the need to clean or re scale) largely depends on the water hardness in your area the frequency with which the coffee maker is used. Lime scale is not harmful to your health. But if poured into your beverage, it can give a powdery taste to your drink. Therefore, the coffee maker should be descaled periodically as indicated below:

DESCALING

Descale coffee maker regularly. With normal use: at least twice a year.

1. Fill the coffee maker up to "MAX" with a mixture of one part ordinary vinegar and two parts water. Switch on and wait for the appliance to switch off automatically.
2. Let the mixture remain inside the coffee maker overnight.
3. Discard the mixture the next morning.
4. Fill the coffee maker with clean water up to "MAX" mark and boil again.
5. Discard the boiled water to remove any remaining scale and vinegar.
6. Rinse the inside of the coffee maker with clean water.

ENVIRONMENT FRIENDLY DISPOSAL

You can help protect the environment!
Please remember to respect the local regulations: hand in the non-working electrical equipment to an appropriate waste disposal center.

The heating element surface is subjected to residual heat after use.
If the kettle is overfilled, boiling water may be ejected.

1. فم الصب
2. جسم غلاية
3. ضوء المؤشر
4. مقبض
5. قاعدة
6. مفتاح



1. باستخدام ماكينة صنع القهوة ، يمكنك تحضير القهوة.
2. قبل الاستخدام الأول ، قم بملء ماكينة صنع القهوة بالماء النظيف لأقصى سعة ثم قم بغليها. تخلص من الماء وكرر العملية.
3. يجب فصل صانعة القهوة عن مصدر الكهرباء دائمًا عند تعبئة الماء أو إضافته.
4. املأ صانعة القهوة بالماء إلى المستوى المطلوب. لا تفرط في الملء وإلا سيكون هناك خطر الانسكاب أو البصق. سيساعدك مؤشر مستوى الماء على قياس الكمية الصحيحة.
5. ضع كمية كافية من الماء البارد في آلة صنع القهوة وفقًا لحد أقصى 300 مل
6. ضع الجهاز على وحدة قاعدة الطاقة ، وقم بتشغيل ماكينة صنع القهوة بمجرد الضغط على مفتاح التشغيل / الإيقاف بواسطة ماكينة صنع القهوة من جيباس.
7. في هذا الوقت ، قم بخلط القهوة لمرة أو مرتين باستخدام ملعقة قياس ومزج من الفولاذ المقاوم للصدأ
8. عندما تبدأ القهوة بالانتفاخ ، أغلق الجهاز واسكب القليل من القهوة في الأكواب.
9. استبدل جهازك في وحدة قاعدة الطاقة وأعد تشغيل صانعة القهوة ، ثم اسكب القهوة في الكوب عندما تنتفخ القهوة المحضرة مرة أخرى.
10. يمكنك تحضير القهوة بمقاييس مختلفة حسب ذوقك الشخصي.
11. تم تركيب قاطع أمان أوتوماتيكي للحماية من الجفاف. إذا لم تضع كمية كافية من الماء ، أو قمت بتشغيلها عندما تكون فارغة ، فسيقوم قاطع الأمان بإيقاف تشغيل الطاقة تلقائيًا. إذا حدث ذلك ، انتظر بضع دقائق حتى يبرد العنصر ، ثم أعد ملئه واستخدمه كالمعتاد.
12. ضع قاعدة الطاقة على سطح جاف ومستو. ضع صانع القهوة على قاعدة الطاقة. سيتم إجراء التوصيل الكهربائي تلقائيًا عندما تنزلق آلة صنع القهوة على قاعدة الطاقة.
13. قم بتوصيل السلك بمقبس طاقة مؤرض وتشغيله عن طريق الضغط على مفتاح صانعة القهوة إلى وضع "ON" لماكينة صنع القهوة من جيباس.
14. دع ماكينة صنع القهوة من جيباس بعد ترك صانعة القهوة تبرد لمدة 15-20 ثانية ، يمكن إعادة الماء إلى درجة الغليان عن طريق دفع المفتاح مرة أخرى إلى وضع "ON". أثناء وقت التبريد ، لا تقم بإجبار مفتاح التشغيل / الإيقاف على وضع "ON" لأن هذا قد يؤدي إلى إتلاف آلية التشغيل.
15. لا تقم بإزالة صانعة القهوة من قاعدة الطاقة بدون إيقاف تشغيلها أولاً.
16. تذكر ، إذا كنت لا ترغب في إعادة غلي القهوة ، أطفئها.
17. يمكن إيقاف تشغيل صانعة القهوة يدويًا في أي وقت عن طريق ضبط مفتاح التشغيل / الإيقاف على وضع "إيقاف التشغيل".
18. في حالة تلف سلك الإمداد ، يجب استبداله من قبل الشركة المصنعة أو وكيل الخدمة الخاص بها أو شخص مؤهل مماثل من أجل تجنب الخطر.

The appliance is only to be used with the stand provided
يتم استخدام الجهاز فقط مع الحامل المزود
Avoid spillage on the connector
تجنب التسرب على الموصل

19. هذا الجهاز غير مخصص للاستخدام من قبل الأشخاص (بالاضافة الأطفال) الذين يعانون من ضعف القدرات الجسدية أو الحسية أو العقلية ، أو نقص الخبرة والمعرفة ، ما لم يتم منحهم الإشراف أو التعليمات المتعلقة باستخدام الجهاز من قبل الشخص المسؤول عن سلامتهم. يجب مراقبة الأطفال للتأكد من أنهم لا يعبثون بالجهاز.
20. هذا الجهاز مقصود به الاستعمال المنزلي أو ما ماثله من التطبيقات كالتالية:
    - **مناطق مطابخ الموظفين بالمحلات والمكاتب وغيرها من البيئات العملية.**
    - **منازل المزارع.**
    - **من قبل العملاء في الفنادق والموتيلات ونحوها من نوعية البيئات السكنية.**
    - **بيئات نوعية السرير والفطور.**
21. قد يتسبب سوء الاستخدام في حدوث إصابة محتملة
22. إيقاف تشغيل الأجهزة وقطع من تزويد الطاقة قبل تغيير الملحقات أو تقرب الأجزاء التي تتحرك عند الاستخدام

كيفية عناية بصانع القهوة الخاص بك

امسح الجزء الخارجي من صانعة القهوة بقطعة قماش ناعمة ومبللة أو إسفنجة. قم بإزالة البقع الصعبة بقطعة قماش مبللة بمنظف سائل معتدل. لا تستخدم منصات أو فوط جلي كاشطة. لا تغمر آلة صنع القهوة في الماء أو السوائل الأخرى.
من وقت لآخر ، اعتمادًا على طبيعة إمدادك بالمياه ، تتشكل رواسب مقياس الجير بشكل طبيعي ويمكن العثور عليها في الغالب ملتصقة بعنصر التسخين ، وبالتالي تقليل سعة التدفئة. تعتمد كمية مقياس الجير المودعة (بعد ذلك الحاجة إلى التنظيف أو إعادة القياس) إلى حد كبير على عسر الماء في منطقتك وتكرار استخدام ماكينة صنع القهوة. مقياس الجير ليس ضارًا بصحتك. ولكن إذا تم سكبه في مشروبك ، يمكن أن يعطي طعمًا ناعمًا لمشروبك. لذلك ، يجب إزالة الترسبات الكلسية من ماكينة صنع القهوة بشكل دوري كما هو موضح أدناه.

إزالة الترسبات الكلسية

قم بإزالة الترسبات من صانع القهوة بانتظام. مع الاستخدام العادي: على الأقل مرتين في السنة.

1. املأ ماكينة صنع القهوة حتى "ماكس" بمزيج من جزء من الخل العادي وجزأين من الماء. قم بتشغيل الجهاز وانتظر حتى يتم إيقاف تشغيله تلقائيًا.
2. اترك الخليط داخل آلة صنع القهوة طوال الليل.
3. تجاهل الخليط في صباح اليوم التالي.
4. املأ صانعة القهوة بالماء النظيف حتى علامة " ماكس " ثم قم بغليها مرة أخرى.
5. تخلص من الماء المغلي لإزالة أي بقايا من القشور والخل.
6. اشطف صانعة القهوة من الداخل بماء نظيف.

التخلص من البيئة بطريقة صديقة

يمكنك المساعدة في حماية البيئة!
يرجى تذكر احترام اللوائح المحلية: قم بتسليم المعدات الكهربائية التي لا تعمل إلى مركز التخلص من النفايات المناسب.

سطح عنصر التسخين عرضة للحرارة المتبقية بعد الاستخدام
.إذا كانت الغلاية ممتلئة أكثر من اللازم ، فقد يتم إخراج الماء المغلي

GEEPAS®

CUSTOMER HAPPINESS CENTER

UNITED ARAB EMIRATES - DUBAI
Customer Happiness Center, Western International Group,
P.O.Box # 18742, National Industrial Park, Mina Jebel Ali, Dubai, UAE.
Tel : +971 4 816 3120,, Email: csreception@westernint.com
TOLL FREE 800 433 727

SAUDI ARABIA - RIYADH
Customer Happiness Center, Geepas Warehouse,P B Box # 40414
Ad Dar Al Baida, Riyadh 14516, Saudi Arabia Tel: +966 53 742 1593,
+ 966 11 286 5540, Email: csriyadh@westernint.Com

SAUDI ARABIA - JEDDAH
Customer Happiness Center, Al Khumra, Tel: +966 12 653 2525,
Mob: +966 53 920 3787, Email: csjeddah@westernint.com

SAUDI ARABIA - JEDDAH
Customer Happiness Center, Sharafiyya, Opp. Post Office
Tel: +966 12 653 2525, Mob: +966 53 756 6782
Email: cssharafiyya@westernint.Com

SAUDI ARABIA - KHAMEES MUSHAIT
Customer Happiness Center, Khamees Mushait Road, Near Saudi
Germen Hospital Aseer., Tel: + 966 17 220 6616,
Mob: +966 53 920 3787, Email: cskamis@westernint.com

SAUDI ARABIA - DAMMAM
Customer Happiness Center, Al Eatisam Al Khaliji Commercial Ltd. Co.,
Salman Al Farist St., Al Khalidiyah al Janubiyah
Tel: +966 3 858 8126 , +966 53 920 3274
Email: csdammam@westernint.com

BAHARAIN - MANAMA
Customer Happiness Center, 2nd Floor, Nesto Supermarket - Building
No : 513, Shaikh Abdulla Road 329,Manama Center 302, Bahrain.
Tel : +973 1 722 6177, Mob: +973 6676 5281,
Email: csbahrain@westernint.com

KUWAIT
Customer Happiness Center, Muhammed Al Bahar Building,
mubarakiya, Kuwait City, Tel : +965 2 487 8055, +965 5 020 6882
Email: cskuwait@westernint.com,

OMAN
Customer Happiness Center, Al Gharbia International LLC, PB No.
453, PC No.131 Ghala Industrial Area, Sultanate Of Oman
Tel: +968 2 450 6033, Mob: +968 9 882 4462,
Email: csoman@westernint.com

OMAN -BURAIMI
Customer Happiness Center, East West International LLC , CR No.
1103699 , Buraimi, Sultanate Of Oman, Tel: +968 2 450 6033,
Mob: +968 9 446 4661 , +968 9 882 4462,
Email: csoman@westernint.com, csreception@westernint.com

OMAN - SALALAH
Customer Happiness Center, Al Gharbiya International LLC. PB
No.453,PCNo.131,Al Ikhlas Street, Salalah,Sultanate Of Oman
Tel: +968 2 329 4069, +968 2 450 6033, Mob : +968 9 882 4462
Email: cssalalah@westernint.com, csoman@westernint.com

QATAR
Customer Happiness Center, Western International Marketing
Co.W.L.L, P.O Box No: 32480, GWC Bu Sulba Warehousing Park,
B17 ,Store No.18 Birkat Al Awamer, Al Wakra Road Wukair
Tel : +974 4 416 8493, Mob: +974 6 640 1016,
Email: csqatar@westernint.com

BANGLADESH - DHAKA
Customer Happiness Center, Ridge dale Shopping Complex,
Cha-75/2 North Badda,Progati Sharani,Badda, Dhaka-1212, Shop
No. 104-105, (1st Floor). Tel : +88 025 881 1579,
Mob: +880 174 222 5190, Email: bangladeshcs3@gmail.com

NEPAL - KATHMANDU
Customer Happiness Center, Alliance PVT. LTD, Putalisadak,
Kathmandu, Nepal, Tel: +9771 416 8211, Mob: +977 98 4103 0824
Email: alliancelaptop123@gmail.com, adm_ap41@yahoo.com

AFGHANISTAN-KABUL
M/s Sadaqat Kochi Ltd, Jada Nadir Pashtoon Kherkhwa
Market Shop No 1
Tel: +93 202 108001, +93 799 468807

AFGHANISTAN-KABUL
M/s Sadaqat Kochi Ltd, Jada Nadir Pashtoon Kabul
Electronics Market Shop No 1.
Tel: +93 202 109121, +93 782 300200

PAKISTAN-PESHAWAR
M/s Saleem Khan Electronics Shop No 22-25, Block A
Khyber Market, Jamrud Road Karkhano, Peshawar
Tel: +92 91 5812436, +92 91 5816619
Email: S.kltd@yahoo.com

PAKISTAN-LAHORE
M/s Saleem Electronics, Al Rasheed Trade Center,
Shop: 2,3,4, Plastic Dana Market,
Shah-alam Market, Lahore,
Mob: +92 423 7673957, +92 322 8888864.

INDIA - CALICUT (VADAKARA)
Customer Happiness Center, Nesto Grand Squire Mall, 2ND Floor,
Edodi, Vatakara, Calicut, Kerala 673101,India,
Toll Free : 1800 425 3727, Tel : +91 496 2523940, +91 496 252 3941
Mob : + 91 938 870 6111 , Email: cco@westernint.com

INDIA - KANNUR
Customer Happiness Center, Kunnath Electro Craft, A Block, 3rd Floor
Room No.1 Casamarina Complex Talap Kannur - 670004,
Tel : +91 496 252 3940, Mob : +91 892 177 3390 , +91 938 870 6111
Email: kannurcs110@gmail.com

UK
Contact details
Western international group(uk) ltd
Unit 5,Alpha Business Park,Bevan Way,
Smethwick,Birmingham, B66 1BZ ,
UNITED KINGDOM

Customer Service / Technical Support
Telephone: 01217286969
Email: support@geepas.co.uk
Web: www.geepas.co.uk
*Register online for warranty.

Following you.
Following your needs.
For over 3 decades.

- **Available in over 86 Countries**
- **Over 300 Million Satisfied Customers**
- **Over 1500 Products**
- **World Class Service Support**

Every Geepas product is inspired by you. Your desire to have something that can touch your life and make it better. Whether they are Home Appliances, Kitchen Appliances, Entertainment Products, Personal Care or Lighting Devices. We are constantly evolving and innovating to make sure that you get to choose only the best from our range of over 1500 products. So the next time you pick up any Geepas product, you know it's made just For you. For life.

UAE TOLL FREE - 800 433 727
INDIA TOLL FREE - 1800 425 3727
Email : customercare@geepas.com

LEARN MORE ABOUT GEEPAS PRODUCTS RANGE

geepas_official geepas official
MADE IN CHINA صنع في الصين
www.geepas.com

Disposal of the appliance

Correct Disposal of This Product
(Waste Electrical & Electronic Equipment)
(Applicable in the European Union and other European countries with separate collection systems)
This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.
Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business user should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.