T8(ATS)
Crystal(3)



快速入门指南
Quick Start Guide
Crystal (3) Color Bluetooth Earbuds

ACEFAST

Volume the future

温馨提示
Friendly Reminder
注意事項

● 首次使用充电仓充电以及充电仓唤醒，请确保充上的触点干燥，防潮，否则会导致充电异常。
● 初次充电时请先合盖充电。

For the first use, you need to take the earbud out of the charging case, turn off the insulating sticker on the earbud and the earbud will automatically turn on and enter pairing mode.
Please charge the earbud first when the power is low.

● 初めて充電する際は、充電ケースからイヤホンを取り出し、イヤホンの絶縁シールを外すと、イヤホンが自動電源ON・ペアリングモードに入ります。
● 充電ケースの接点が乾燥していることを確認してください。電気が切れた場合は必ず充電してください。

Product Information 产品信息 製品情報 EN



Touch area: Earbud touch area
Earbud indicator: Indicates the status of the earbuds. Turn red/blue alternately when earbuds are in pairing mode. Turn red when earbuds are charging.

Parameter / Product list 产品参数 製品パラメータ EN

Bluetooth version	Bluetooth 5.3
Bluetooth version	Bluetooth 5.3 (TWS)
Bluetooth range	10m
Supported codec	SBC, AAC
Earbuds specifications	5.8mm / 38mAh
Earbuds weight	4.5g*2
Charging case capacity	500mAh
Call time	About 6h (70% volume level)
Standby time	About 30h
Charging case battery	500mAh, fully charged about 2.5 hrs
Charging case weight	45g
Charging port	Type-C
Working temperature	-10°C to 55°C
Earbuds IP rating	IP54
Charging case IP rating	IP54
Net weight	About 53g
Gross weight	About 98g

Product list



Instructions for use 使用说明 使用方法 EN



Pairing
1. Take out the earbuds from the charging case to enter the automatic pairing mode of the connected earbud. Both left and right earbuds can be connected to the device separately or at the same time.
2. Turn on the Bluetooth function of your device and search for Bluetooth devices. Select the corresponding Bluetooth name to connect.
3. If the earbuds are not connected to the device, they will enter pairing mode automatically after 5 minutes.
4. If you want to pair with another device, please turn off the Bluetooth function of the connected device first.

Reconnecting
Take out the earbuds from the charging case, the earbuds will connect to the last connected device automatically.

Operation mode 操作模式 操作モード EN

Left earbud
Double tap the touch area

Right earbud
Double tap the touch area

Operation method 操作方法 操作方法 EN

Volume control (Default setting)
1. Triple tap the touch area of the right earbud to increase the volume. Triple tap the touch area of the left earbud to decrease the volume.
2. Triple tap the touch area of the earbud to switch between volume control and track control.

Track control
1. Triple tap the touch area of the right earbud to play the next track.
2. Triple tap the touch area of the left earbud to play the previous track.
3. Triple tap the touch area of the earbud to switch between volume control and track control.

Switching between volume control and track control
Triple tap the touch area of the earbud to switch between volume control and track control.

Customizing touch control settings
Open the Acefast Buds app, select the device, select the touch function, and customize the touch settings.

Operation method 操作方法 操作方法 EN

Answering a call
1. Tap the touch area of the left earbud
2. Tap the touch area of the right earbud
3. Double tap the touch area of either earbud

Rejecting a call
Press and hold the touch area of either earbud for 2 seconds

Ending a call
1. Tap the touch area of the left earbud
2. Tap the touch area of the right earbud
3. Double tap the touch area of either earbud

Operation method 操作方法 操作方法 EN

Activating voice assistant
Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Waking the AI chat
Double tap the touch area of either earbud to wake the AI chat. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Switching AI chat
Double tap the touch area of either earbud to switch the AI chat. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Waking low latency mode
Double tap the touch area of either earbud to wake the low latency mode. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Switching low latency mode
Double tap the touch area of either earbud to switch the low latency mode. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Charge
1. Please use the original charging cable to charge the earbuds to avoid the failure of the connection between the earbuds and the charging case.
2. Please charge the earbuds when the battery is low.
3. Please charge the earbuds in a dry environment.
4. The earbuds will automatically turn off when they are placed in the charging case for more than 10 seconds.

Wireless charging
The charging case supports wireless charging. Place the charging case on a wireless charging pad and charge it.

Power on/off 开关机 電源のオン/オフ EN

Automatic power on/off
Automatic power on: Take out the earbuds from the charging case, the earbuds will automatically power on and enter pairing mode.
Automatic power off: Put the earbuds back into the charging case, the earbuds will automatically power off and enter charging mode.

Manual
Power on: Double tap the touch area of either earbud to power on.
Power off: Press and hold the touch area of either earbud for 5 seconds to power off.

Left earbud
Press and hold the touch area for 5 seconds

Right earbud
Press and hold the touch area for 5 seconds

Power on/off 开关机 電源のオン/オフ EN

Automatic power on/off
Automatic power on: Take out the earbuds from the charging case, the earbuds will automatically power on and enter pairing mode.
Automatic power off: Put the earbuds back into the charging case, the earbuds will automatically power off and enter charging mode.

Manual
Power on: Double tap the touch area of either earbud to power on.
Power off: Press and hold the touch area of either earbud for 5 seconds to power off.

Left earbud
Press and hold the touch area for 5 seconds

Right earbud
Press and hold the touch area for 5 seconds

Power on/off 开关机 電源のオン/オフ EN

Automatic power on/off
Automatic power on: Take out the earbuds from the charging case, the earbuds will automatically power on and enter pairing mode.
Automatic power off: Put the earbuds back into the charging case, the earbuds will automatically power off and enter charging mode.

Manual
Power on: Double tap the touch area of either earbud to power on.
Power off: Press and hold the touch area of either earbud for 5 seconds to power off.

Left earbud
Press and hold the touch area for 5 seconds

Right earbud
Press and hold the touch area for 5 seconds

Mode & operation 模式 & 操作 モード & 操作 EN

Ecomode / Ajustar
Ecomode: Ajustar el modo de ecualización predefinido. Por defecto, ajustado como Ecomode. Ajustar: Ajustar el modo de ecualización predefinido. Toque el área táctil del auricular izquierdo o derecho para cambiar entre Ecomode y Ajustar. Los auriculares se apagarán automáticamente tras permanecer en la caja de carga.

Game Mode
Ajustar el modo de ecualización predefinido. Toque el área táctil del auricular izquierdo o derecho para cambiar entre Ecomode y Ajustar. Los auriculares se apagarán automáticamente tras permanecer en la caja de carga.

Left earbud
Triple tap the touch area of the left earbud to switch the mode.

Right earbud
Triple tap the touch area of the right earbud to switch the mode.

Warning: Avoid using at high volume for long periods to protect your hearing.

Mode & operation 模式 & 操作 モード & 操作 EN

Mode & operation
Ecomode / Adjust: Adjust the preset equalization mode. By default, set to Ecomode. Adjust: Adjust the preset equalization mode. Tap the touch area of the left or right earbud to switch between Ecomode and Adjust. The earbuds will automatically power off after staying in the charging case for a while.

Game Mode
Adjust the preset equalization mode. Tap the touch area of the left or right earbud to switch between Ecomode and Adjust. The earbuds will automatically power off after staying in the charging case for a while.

Left earbud
Triple tap the touch area of the left earbud to switch the mode.

Right earbud
Triple tap the touch area of the right earbud to switch the mode.

Warning: Avoid using at high volume for long periods to protect your hearing.

Mode & operation 模式 & 操作 モード & 操作 EN

Ecomode / Ajustar
Ecomode: Ajustar el modo de ecualización predefinido. Por defecto, ajustado como Ecomode. Ajustar: Ajustar el modo de ecualización predefinido. Toque el área táctil del auricular izquierdo o derecho para cambiar entre Ecomode y Ajustar. Los auriculares se apagarán automáticamente tras permanecer en la caja de carga.

Game Mode
Ajustar el modo de ecualización predefinido. Toque el área táctil del auricular izquierdo o derecho para cambiar entre Ecomode y Ajustar. Los auriculares se apagarán automáticamente tras permanecer en la caja de carga.

Left earbud
Triple tap the touch area of the left earbud to switch the mode.

Right earbud
Triple tap the touch area of the right earbud to switch the mode.

Warning: Avoid using at high volume for long periods to protect your hearing.

Battery/earbuds 电池/耳机 バッテリー/イヤホン EN

Earbuds charging
Place the earbuds in the charging case and charge them via the Type-C charging port. The earbuds will automatically power off when charging.

Charging case battery
Charge the charging case via the Type-C charging port.

Low battery indicator
Left earbud: When the battery is low, the left earbud will turn red every 15 seconds.
Right earbud: When the battery is low, the right earbud will turn red every 15 seconds.

Charging case battery indicator
When the charging case is charging, the battery indicator will turn red.
When the charging case is fully charged, the battery indicator will turn off.

Reset
Put the earbuds in the charging case, press and hold the touch area of both earbuds for 10 seconds. The earbuds will restart and enter pairing mode.

Battery/earbuds 电池/耳机 バッテリー/イヤホン EN

Earbuds charging
Place the earbuds in the charging case and charge them via the Type-C charging port. The earbuds will automatically power off when charging.

Charging case battery
Charge the charging case via the Type-C charging port.

Low battery indicator
Left earbud: When the battery is low, the left earbud will turn red every 15 seconds.
Right earbud: When the battery is low, the right earbud will turn red every 15 seconds.

Charging case battery indicator
When the charging case is charging, the battery indicator will turn red.
When the charging case is fully charged, the battery indicator will turn off.

Reset
Put the earbuds in the charging case, press and hold the touch area of both earbuds for 10 seconds. The earbuds will restart and enter pairing mode.

Battery/earbuds 电池/耳机 バッテリー/イヤホン EN

Via Charola Multifunción / Uso a Prueba de Agua y Sudoración del Estuche de Carga
Cuando los auriculares se colocan en el estuche de carga, se cargan automáticamente. Cuando la batería del estuche de carga está baja, conéctelo a una fuente de alimentación para cargarlo. Los auriculares y el estuche de carga tienen una clasificación IP54 y son resistentes al sudor y al agua.

Carga de auriculares
Coloque los auriculares en el estuche de carga y cárguelos a través del puerto de carga Type-C. Los auriculares se apagarán automáticamente cuando se carguen.

Batería del estuche de carga
Cargue el estuche de carga a través del puerto de carga Type-C.

Indicador de batería baja
Auricular izquierdo: Cuando la batería esté baja, el auricular izquierdo parpadeará en rojo cada 15 segundos.
Auricular derecho: Cuando la batería esté baja, el auricular derecho parpadeará en rojo cada 15 segundos.

Indicador de batería del estuche de carga
Cuando el estuche de carga se esté cargando, el indicador de batería se encenderá en rojo.
Cuando el estuche de carga esté completamente cargado, el indicador de batería se apagará.

Reset
Coloque los auriculares en el estuche de carga, mantenga presionada el área táctil de ambos auriculares durante 10 segundos. Los auriculares se reiniciarán y entrarán en modo de emparejamiento.

Multi-device & Reinstatement 多设备 & 恢复出厂设置 マルチデバイス & 初期化 EN

Automatic connection
Automatic connection to the last connected device: Take out the earbuds from the charging case, the earbuds will automatically connect to the last connected device.
Automatic connection to multiple devices: Take out the earbuds from the charging case, the earbuds will automatically connect to multiple devices.

Reset
Put the earbuds in the charging case, press and hold the touch area of both earbuds for 10 seconds. The earbuds will restart and enter pairing mode.

Software upgrade
Please download the Acefast Buds app and upgrade the firmware version of the earbuds.

Multi-device & Reinstatement 多设备 & 恢复出厂设置 マルチデバイス & 初期化 EN

Automatic connection
Automatic connection to the last connected device: Take out the earbuds from the charging case, the earbuds will automatically connect to the last connected device.
Automatic connection to multiple devices: Take out the earbuds from the charging case, the earbuds will automatically connect to multiple devices.

Reset
Put the earbuds in the charging case, press and hold the touch area of both earbuds for 10 seconds. The earbuds will restart and enter pairing mode.

Software upgrade
Please download the Acefast Buds app and upgrade the firmware version of the earbuds.

Multi-device & Reinstatement 多设备 & 恢复出厂设置 マルチデバイス & 初期化 EN

Automatic connection
Automatic connection to the last connected device: Take out the earbuds from the charging case, the earbuds will automatically connect to the last connected device.
Automatic connection to multiple devices: Take out the earbuds from the charging case, the earbuds will automatically connect to multiple devices.

Reset
Put the earbuds in the charging case, press and hold the touch area of both earbuds for 10 seconds. The earbuds will restart and enter pairing mode.

Software upgrade
Please download the Acefast Buds app and upgrade the firmware version of the earbuds.

Tidy place 收纳 収納 EN

Earbuds
Put the earbuds in the charging case for storage.

Charging case
Put the charging case in a dry and ventilated place for storage.

Tidy place 收纳 収納 EN

Earbuds
Put the earbuds in the charging case for storage.

Charging case
Put the charging case in a dry and ventilated place for storage.

Tidy place 收纳 収納 EN

Earbuds
Put the earbuds in the charging case for storage.

Charging case
Put the charging case in a dry and ventilated place for storage.

Write by touch/movement 触摸/动感操作 タッチ/モーション操作 EN

Warning: Activation
Activation: Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Volume control
Triple tap the touch area of the right earbud to increase the volume. Triple tap the touch area of the left earbud to decrease the volume.

Track control
1. Triple tap the touch area of the right earbud to play the next track.
2. Triple tap the touch area of the left earbud to play the previous track.

Switching between volume control and track control
Triple tap the touch area of the earbud to switch between volume control and track control.

Customizing touch control settings
Open the Acefast Buds app, select the device, select the touch function, and customize the touch settings.

Write by touch/movement 触摸/动感操作 タッチ/モーション操作 EN

Warning: Activation
Activation: Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Volume control
Triple tap the touch area of the right earbud to increase the volume. Triple tap the touch area of the left earbud to decrease the volume.

Track control
1. Triple tap the touch area of the right earbud to play the next track.
2. Triple tap the touch area of the left earbud to play the previous track.

Switching between volume control and track control
Triple tap the touch area of the earbud to switch between volume control and track control.

Customizing touch control settings
Open the Acefast Buds app, select the device, select the touch function, and customize the touch settings.

Write by touch/movement 触摸/动感操作 タッチ/モーション操作 EN

Warning: Activation
Activation: Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Volume control
Triple tap the touch area of the right earbud to increase the volume. Triple tap the touch area of the left earbud to decrease the volume.

Track control
1. Triple tap the touch area of the right earbud to play the next track.
2. Triple tap the touch area of the left earbud to play the previous track.

Switching between volume control and track control
Triple tap the touch area of the earbud to switch between volume control and track control.

Customizing touch control settings
Open the Acefast Buds app, select the device, select the touch function, and customize the touch settings.

触控/动感

警告：激活
激活：双击任一耳机的触控区域以激活语音助手。激活可能基于您手机的语音助手，如 Siri、Google Assistant、Bixby 等。请参阅您手机的说明。

音量控制
三击右耳机的触控区域以增加音量。三击左耳机的触控区域以减小音量。

曲目控制
1. 三击右耳机的触控区域以播放下一曲目。
2. 三击左耳机的触控区域以播放上一曲目。

在音量控制和曲目控制之间切换
三击耳机的触控区域以在音量控制和曲目控制之间切换。

自定义触控设置
打开 Acefast Buds 应用程序，选择设备，选择触控功能，并自定义触控设置。

触控/動作

警告：啟動
啟動：雙擊任一耳機的觸控區域以啟動語音助理。啟動可能基於您手機的語音助理，例如 Siri、Google Assistant、Bixby 等。請參閱您手機的說明。

音量控制
三擊右耳機的觸控區域以增加音量。三擊左耳機的觸控區域以減小音量。

曲目控制
1. 三擊右耳機的觸控區域以播放下一曲目。
2. 三擊左耳機的觸控區域以播放上一曲目。

在音量控制和曲目控制之間切換
三擊耳機的觸控區域以在音量控制和曲目控制之間切換。

自訂觸控設定
開啟 Acefast Buds 應用程式，選擇裝置，選擇觸控功能，並自訂觸控設定。

Write by touch/movement 触摸/动感操作 タッチ/モーション操作 EN

Warning: Activation
Activation: Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Volume control
Triple tap the touch area of the right earbud to increase the volume. Triple tap the touch area of the left earbud to decrease the volume.

Track control
1. Triple tap the touch area of the right earbud to play the next track.
2. Triple tap the touch area of the left earbud to play the previous track.

Switching between volume control and track control
Triple tap the touch area of the earbud to switch between volume control and track control.

Customizing touch control settings
Open the Acefast Buds app, select the device, select the touch function, and customize the touch settings.

触控/動作

警告：啟動
啟動：雙擊任一耳機的觸控區域以啟動語音助理。啟動可能基於您手機的語音助理，例如 Siri、Google Assistant、Bixby 等。請參閱您手機的說明。

音量控制
三擊右耳機的觸控區域以增加音量。三擊左耳機的觸控區域以減小音量。

曲目控制
1. 三擊右耳機的觸控區域以播放下一曲目。
2. 三擊左耳機的觸控區域以播放上一曲目。

在音量控制和曲目控制之間切換
三擊耳機的觸控區域以在音量控制和曲目控制之間切換。

自訂觸控設定
開啟 Acefast Buds 應用程式，選擇裝置，選擇觸控功能，並自訂觸控設定。

触控/动感

警告：激活
激活：双击任一耳机的触控区域以激活语音助手。激活可能基于您手机的语音助手，如 Siri、Google Assistant、Bixby 等。请参阅您手机的说明。

音量控制
三击右耳机的触控区域以增加音量。三击左耳机的触控区域以减小音量。

曲目控制
1. 三击右耳机的触控区域以播放下一曲目。
2. 三击左耳机的触控区域以播放上一曲目。

在音量控制和曲目控制之间切换
三击耳机的触控区域以在音量控制和曲目控制之间切换。

自定义触控设置
打开 Acefast Buds 应用程序，选择设备，选择触控功能，并自定义触控设置。

触控/動作

警告：啟動
啟動：雙擊任一耳機的觸控區域以啟動語音助理。啟動可能基於您手機的語音助理，例如 Siri、Google Assistant、Bixby 等。請參閱您手機的說明。

音量控制
三擊右耳機的觸控區域以增加音量。三擊左耳機的觸控區域以減小音量。

曲目控制
1. 三擊右耳機的觸控區域以播放下一曲目。
2. 三擊左耳機的觸控區域以播放上一曲目。

在音量控制和曲目控制之間切換
三擊耳機的觸控區域以在音量控制和曲目控制之間切換。

自訂觸控設定
開啟 Acefast Buds 應用程式，選擇裝置，選擇觸控功能，並自訂觸控設定。

Write by touch/movement 触摸/动感操作 タッチ/モーション操作 EN

Warning: Activation
Activation: Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Volume control
Triple tap the touch area of the right earbud to increase the volume. Triple tap the touch area of the left earbud to decrease the volume.

Track control
1. Triple tap the touch area of the right earbud to play the next track.
2. Triple tap the touch area of the left earbud to play the previous track.

Switching between volume control and track control
Triple tap the touch area of the earbud to switch between volume control and track control.

Customizing touch control settings
Open the Acefast Buds app, select the device, select the touch function, and customize the touch settings.

Warning: activation 警告：激活 警告：アクティベーション EN

Warning: Activation
Activation: Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Warning: activation 警告：激活 警告：アクティベーション EN

Warning: Activation
Activation: Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Warning: activation 警告：激活 警告：アクティベーション EN

Warning: Activation
Activation: Double tap the touch area of either earbud to activate the voice assistant. The activation may be based on the voice assistant of your mobile phone, such as Siri, Google Assistant, Bixby, etc. Please refer to the instructions of your mobile phone.

Precautions 注意事项 注意事項 EN

1. Please use the original charging cable to charge the earbuds to avoid the failure of the connection between the earbuds and the charging case.
2. Please charge the earbuds when the battery is low.
3. Please charge the earbuds in a dry environment.
4. The earbuds will automatically turn off when they are placed in the charging case for more than 10 seconds.
5. Please do not use the earbuds in a humid environment, such as in the bathroom, to avoid damage to the earbuds.
6. Please do not use the earbuds in a high-temperature environment, such as in a car in summer, to avoid damage to the earbuds.
7. Please do not use the earbuds in a low-temperature environment, such as in a refrigerator, to avoid damage to the earbuds.
8. Please do not drop the earbuds from a high place, to avoid damage to the earbuds.
9. Please do not use the earbuds for a long time at high volume, to protect your hearing.
10. Please do not use the earbuds for a long time in a confined space, to protect your hearing.
11. Please do not use the earbuds for a long time in a noisy environment, to protect your hearing.
12. Please do not use the earbuds for a long time in a quiet environment, to protect your hearing.
13. Please do not use the earbuds for a long time in a windy environment, to protect your hearing.
14. Please do not use the earbuds for a long time in a rainy environment, to protect your hearing.
15. Please do not use the earbuds for a long time in a snowy environment, to protect your hearing.
16. Please do not use the earbuds for a long time in a foggy environment, to protect your hearing.
17. Please do not use the earbuds for a long time in a dusty environment, to protect your hearing.
18. Please do not use the earbuds for a long time in a smoky environment, to protect your hearing.
19. Please do not use the earbuds for a long time in a polluted environment, to protect your hearing.
20. Please do not use the earbuds for a long time in a noisy environment, to protect your hearing.

注意事项



1. 请使用原装充电线为耳机充电，以免耳机与充电仓连接失败。
2. 电量低时请及时充电。
3. 请在干燥环境下为耳机充电。
4. 耳机放入充电仓超过10秒后会自动关机。
5. 请勿在潮湿环境（如浴室）中使用耳机，以免损坏耳机。
6. 请勿在高温环境（如夏天车内）中使用耳机，以免损坏耳机。
7. 请勿在低温环境（如冰箱）中使用耳机，以免损坏耳机。
8. 请勿将耳机从高处掉落，以免损坏耳机。
9. 请勿长时间大音量使用耳机，以保护听力。
10. 请勿长时间在密闭空间使用耳机，以保护听力。
11. 请勿长时间在嘈杂环境中使用耳机，以保护听力。
12. 请勿长时间在安静环境中使用耳机，以保护听力。
13. 请勿长时间在风大环境中使用耳机，以保护听力。
14. 请勿长时间在雨天环境中使用耳机，以保护听力。
15. 请勿长时间在雪天环境中使用耳机，以保护听力。
16. 请勿长时间在雾天环境中使用耳机，以保护听力。
17. 请勿长时间在灰尘环境中使用耳机，以保护听力。
18. 请勿长时间在烟雾环境中使用耳机，以保护听力。
19. 请勿长时间在污染环境中使用耳机，以保护听力。
20. 请勿长时间在噪音环境中使用耳机，以保护听力。

注意事項

1. 充電ケースからイヤホンを取り出すと、自動的にペアリングモードに入ります。
2. 充電ケースの接点が乾燥していることを確認してください。電気が切れた場合は必ず充電してください。
3. 初めて充電する際は、充電ケースからイヤホンを取り出し、イヤホンの絶縁シールを外すと、イヤホンが自動電源ON・ペアリングモードに入ります。
4. 充電ケースの接点が乾燥していることを確認してください。電気が切れた場合は必ず充電してください。

产品保修凭证

产品名称：Acefast 无线蓝牙耳机	型号/规格：T8(ATS) Crystal(3)
产品编号：	保修期：一年
购买日期：	购买渠道：
客户姓名：	联系电话：
维修记录：	

产品維修保証

製品名	型番/規格	製造日	保証期間

Shenzhen Acefast Technology Co., LTD
Address: 1-2/F, Building A, Zhongchuang Industrial Park, No.67, Lanxin Road, Xingdong Community, Yutang Street, Guangming District, Shenzhen, P.R. China

售后服务

1. 本产品享受一年保修服务，保修期从购买之日起计算。
2. 保修期内，因产品质量问题导致的故障，我们将免费为您维修或更换。
3. 保修期外，我们将收取合理的维修费用。
4. 请保留好您的购买凭证，以便我们为您提供保修服务。

保証書

1. 本製品は1年間の保証サービスを受けることができます。保証期間は購入日から起算されます。
2. 保証期間内に、製品の品質問題による故障が発生した場合、無料で修理または交換いたします。
3. 保証期間外の場合、合理的な修理費用を請求させていただきます。
4. 購入証明書を大切に保管してください。保証サービスを受ける際に必要となります。

保修卡

1. 本产品享受一年保修服务，保修期从购买之日起计算。
2. 保修期内，因产品质量问题导致的故障，我们将免费为您维修或更换。
3. 保修期外，我们将收取合理的维修费用。
4. 请保留好您的购买凭证，以便我们为您提供保修服务。

保証書

1. 本製品は1年間の保証サービスを受けることができます。保証期間は購入日から起算されます。
2. 保証期間内に、製品の品質問題による故障が発生した場合、無料で修理または交換いたします。
3. 保証期間外の場合、合理的な修理費用を請求させていただきます。
4. 購入証明書を大切に保管してください。保証サービスを受ける際に必要となります。

保修卡

1. 本产品享受一年保修服务，保修期从购买之日起计算。
2. 保修期内，因产品质量问题导致的故障，我们将免费为您维修或更换。
3. 保修期外，我们将收取合理的维修费用。
4. 请保留好您的购买凭证，以便我们为您提供保修服务。

保証書

1. 本製品は1年間の保証サービスを受けることができます。保証期間は購入日から起算されます。
2. 保証期間内に、製品の品質問題による故障が発生した場合、無料で修理または交換いたします。
3. 保証期間外の場合、合理的な修理費用を請求させていただきます。
4. 購入証明書を大切に保管してください。保証サービスを受ける際に必要となります。

保修卡

1. 本产品享受一年保修服务，保修期从购买之日起计算。
2. 保修期内，因产品质量问题导致的故障，我们将免费为您维修或更换。
3. 保修期外，我们将收取合理的维修费用。
4. 请保留好您的购买凭证，以便我们为您提供保修服务。

保証書

1. 本製品は1年間の保証サービスを受けることができます。保証期間は購入日から起算されます。
2. 保証期間内に、製品の品質問題による故障が発生した場合、無料で修理または交換いたします。
3. 保証期間外の場合、合理的な修理費用を請求させていただきます。
4. 購入証明書を大切に保管してください。保証サービスを受ける際に必要となります。

Warranty & Customer Support / 保修及客户支持 / 保証とサポート

Thank you for choosing Acefast products. Acefast is committed to providing you with high-quality products and professional after-sales service.

If you have any questions, please contact us via the following channels:
Amazon US store: support@acefast.com
Amazon DE store: support@acefast.com
Amazon UK store: support@acefast.com
Other regions store: support@acefast.com

感谢您选择 Acefast 产品。Acefast 致力于为您提供高品质的产品和专业的售后服务。

如有任何问题，请通过以下渠道联系我们：
Amazon US store: support@acefast.com
Amazon DE store: support@acefast.com
Amazon UK store: support@acefast.com
Other regions store: support@acefast.com

Acefastをお選びいただきありがとうございます。Acefastは、高品質な製品と専門的なアフターサービスを提供することをお約束します。

ご質問がございましたら、以下のチャンネルからお問い合わせください：
Amazon US store: support@acefast.com
Amazon DE store: support@acefast.com
Amazon UK store: support@acefast.com
Other regions store: support@acefast.com

FCC

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC Caution

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'exploitation est autorisée aux deux conditions suivantes :

1) l'appareil ne doit pas produire de brouillage, et

2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet appareil est conforme aux normes CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Copyright © 2024 Shenzhen Acefast Technology Co., LTD. All rights reserved.