



P-BUA-TRANSIT CONNECT

Wiring Harness for Backup Alarm 2014-2021 Ford Transit Connect

INSTALLATION MANUAL





Thank you for purchasing the **P-BUA-TRANSIT CONNECT**



Table of Contents

Page 3 - Tools Required For Installation

WHAT'S INCLUDED:

- Vehicle Specific Wire Harness (P-BUA-TRANSIT CONNECT)

COMPATIBLE ACCESSORIES:

- 97dB Backup Alarm (BUA-97C)
- 97dB White Noise Backup Alarm (BUA-97WNC)



TOOLS REQUIRED:



1. 10mm Nut-setter
2. Impact Drill
3. Panel Removal Tool
4. Fish Tape
5. Knife

STEP 1:

Locate and disconnect the OEM tail lamp connector that is in the driver side rear corner of the vehicle



STEP 2:

Install the P-BUA-TRANSIT CONNECT harness between the OEM connectors



STEP 3:

Route the harness down the driver side rear corner cavity.



STEP 4:

Remove the pictured grommet, so that the harness may pass through.

Use a fish tape to route the 2 pin connector of the harness down through the bottom of the rear corner cavity and below the vehicle



STEP 5:

Use an impact drill and 10mm nut-setter to install a compatible backup alarm on the underside of the vehicle

Note: (2) 10mm TEK screws are provided with the compatible backup alarm



STEP 6:

Plug the backup alarm connector into the mating connector on the P-BUA-TRANSIT CONNECT harness. Use a knife to make a small cut in the grommet before it is re-installed



STEP 7:

Test the backup alarm



Phone – 866-766-2267

E-Mail – support@aampglobal.com



EchoMaster is a Power Brand of AAMP Global

EchoMaster.com

