



Installation Instructions for Kodlin Curved Universal License Plate Kit KUS20200/KUS20201

This kit is designed to be used with a Kodlin application specific license plate mounting bracket.

1. Remove your existing license plate mount and any associated wiring.
2. Following your instructions for the Kodlin application specific mounting bracket, install the mounting bracket.
3. Mount the license backing plate to the mounting bracket using the hardware provided with mounting bracket.
4. Bend your existing license plate to match radius of backing plate. The test fit license frame and license. You may need to notch license to clear wires from the light on the frame. Using four small taper head screws install the frame and license on the backing plate. Use the small flat washers and nuts on the back and tighten. Do not over tighten.
5. Run the license frame wire with light colored stripe to a switched 12 vdc power source and the all black wire to a chassis ground. Cut the length as needed.

NOTE: This is a custom part. Kodlin USA is not responsible for stock parts or accessories fitting after the installation. No warranty coverage is provided by Kodlin that is due to improper installation or lack of maintenance. Periodic maintenance and inspection are required. It is the installer's responsibility to ensure that all the fasteners are tightened before operation of the motorcycle. We recommend following the Mfg.'s torque specifications.

For the latest install guides, video's, FAQ's. and Tech-Tip's scan QR code!



Revision Date: 5/26/2022

www.kodlinusa.com

