

ScreenBeam Mini2 Kit Firmware Update Instruction

1. Download the ScreenBeam Mini 2 Kit firmware (sbmini2_FW_x.x.xx.x.zip)
2. Extract the zip file. You should see the "autorun" folder, the "install" file and this upgrade instructions guide.
3. Insert your USB flash drive to an available USB port on your Laptop/PC.
4. Copy both the "autorun" folder and "install" file to the top directory of the USB flash drive
Note: Do not use a portable hard drive. You should use a formatted FAT/FAT32 USB flash drive only.
5. Make sure the HDTV connected to the Receiver is powered on and the correct HDMI input is selected.
6. **Note:** You must disconnect all wireless devices (Ultrabooks, smartphones and tablets) from the Receiver before upgrading the firmware.
7. When the "Ready to Connect" screen appears, plug the USB flash drive into the female port of the included USB cable.
8. Wait a few seconds and the firmware upgrade will start automatically. You should see the firmware upgrade message appears on your TV.
9. **Note:** *The HDTV screen may go temporarily blank for a few seconds during the upgrade process.*
10. **Warning!** *Do not power off the Receiver or remove the USB flash drive while the upgrade is in progress. This may cause the firmware upgrade to fail.*
11. When the upgrade completes, the "Ready to Connect" screen reappears on the HDTV, with the new firmware version information displayed at the bottom left corner.
12. The ScreenBeam receiver is now upgraded. Now you can remove the USB flash drive.



