


MCX

Grab Sample Kit (Kit #28176S)

To install the grab sample tubing:

1. Turn off water supply to the instrument.
2. Install shut-off valve on the inlet supply line.
3. Cut tubing to desired lengths necessary for each specific installation.
4. Run a piece of tubing from the shut-off valve to the tee, then continuing in-line, add another piece of tubing from the tee to another shut-off valve. From the shut-off valve, run a piece of tubing to the grab sample. Then add another piece of tubing coming out of the tee to the instrument.
5. To run from the sample line, open the inlet shut-off valve and close the second shut-off valve. To draw from a sample, close the inlet shut-off valve and open the second shut-off valve.



A WATTS Brand

