

POWER VISION 3 MOUNT

2020-2021 Can-Am X3

PARTS LIST



- | | |
|-----------------|------------------|
| 1 MOUNT BASE | 1 BOLT (6X45MM) |
| 1 EXTENSION ARM | 2 SCREW (5X18MM) |
| 1 CLAW MOUNT | |

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION.



I61300092.01

POWER VISION

®



INSTALLATION INSTRUCTIONS

- 1 On the left side of the dashboard, remove the existing torx bolt.
- 2 Using the supplied 6x45mm bolt, secure the base mount to the dashboard.
- 3 Using the supplied 5x18mm screws, secure the extension and claw mount as shown.



INSTALL BASE AND CLAW MOUNT



BASE, EXTENSION, AND CLAW MOUNT



PUSH THE LIMIT

2191 MENDENHALL DRIVE, NORTH LAS VEGAS, NV 89081 - 800-992-4993 - DYNOJET.COM
© 2021 DYNOJET RESEARCH ALL RIGHTS RESERVED

