



How To Install Adjustable Roman Door Shades

Step 1. Decide the desirable position you want to place the shade.

Use a dry cloth to wipe the surface to ensure it is dust free, as the dust will affect the quality of the adhesive tape.

Mark both sides of the door with a dim pencil, in even positions: left, right, upper.

Step 2. Peel the cover off the adhesive tape, slowly place the tape on the door frame, and make sure the shade is in a parallel position.

Step 3. Roll the shade up and connect the straps to the hooks behind the valance to place the shade into a raised-up position. Release the straps to lower the shade.

Important: The adhesive tape cannot be re- applied to the door, as it loses its strength. Only place the shade on the marked positions once prepared.

