



**RATHER WATCH
A QUICK VIDEO?**

SCAN HERE




Plug the green cord into the green jack on the back of your headset base



Plug the other end of the green cord into the headset jack of your phone

If you don't have a headset button on your desk phone, unplug the curly cord from the base of the desk phone and plug it into the blue jack of the headset base. Now plug the other end of the green cord into the handset jack of the phone (where the curly cord was previously connected)



Plug the power cord into your headset base and into a power outlet



Plug the USB cord into the USB port on the back of the headset base. Plug the other end into your computer or laptop



5



Gently pull the tab from your headset to activate the battery. Set your headset in the base and let it charge for at least 4 hours before first use

6

MAKE US YOUR FIRST CALL!

We want to help you sound perfect.
Call us at 800-511-3181 to make sure your headset is sounding and feeling great