

Carbon Fiber Pillar Cover Installation Instructions for 2020-22 Chevrolet Corvette

Required Tools:

1- Phillips screwdriver

1. Open door

2. Pull weatherstrip outward to un-snap (3) retaining clips at end of pillar



3. Pull weatherstrip down and let it hang from the top of pillar



4. Remove (5) screws with phillips screwdriver along the pillar and (1) screw at the top of pillar. You will need to pull weatherstrip back a bit to access top screw.



5. Remove the OE factory pillar cover



6. Install the carbon fiber pillar cover

7. Reverse the removal process to secure pillar cover. Repeat steps for other pillar cover.

