

RECOMMENDATIONS FOR CUTTING WOVEN WIRE GRILLES

STEP 1:

We suggest making a template of the desired grille size, made of heavy paper or cardboard. Measure the routed opening that the grille will need to be placed into - deduct 1/8" from each dimension for clearance.

Example: The outer edges of the routed opening measure 14" x 28".

The template should measure 13-7/8" x 27-7/8"

STEP 2:

Place the template on a flat surface large enough to hold the grille material. Lay the grille over the template and position it so the design is centered from top to bottom and from side to side. Be sure that the wires "run into" each corner (see illustration below).



STEP 3:

Using a permanent ink marker or lumber crayon, mark the grille wires corresponding to your template. (If more than one grille of each size is to be cut, use a marker to outline one 'diamond' on the template near each of the four corners. This will assist in positioning the remaining material on the template).

STEP 4:

Cut the grille with wire or bolt cutters, carefully following your marked lines. Any loose corner wires may be secured once the grille is mounted into the routed opening.

Architectural Products by Outwater L.L.C.

24 River Road • Bogota, NJ 07603

Phone: 1.800.835.4400

www.outwater.com

