

01



Figure out a place that you wanna hang the mirror. Then mark the height using a pencil align a ruler with the top of the holes on the back of the mirror



02



Point on the wall with a power drill,
and drill a pilot hole for the anchor

03



Insert the anchor and gently hammer it until they are both flush with the wall

04



Next insert the screw into the anchor make sure there is 1/8 of an inch between a screw and the wall

05



Carefully attach the mirror to the wall
with the screw and clean the mirror

