

INDOOR INSTALLATION

STEP 1

Make sure your subfloor is flat, level, and free from any dust or debris.

STEP 2

Next measure your area and map out where the artificial turf will be installed.

STEP 3

Glue down underlayment or padding to increase the longevity of your new indoor turf area.

STEP 4

Once your underlayment or padding is installed you will then glue down your artificial turf grass.

STEP 5

Allow for ample time (15-30 minutes) for the adhesive to air dry before laying the artificial turf

STEP 6

Take your time and move slowly when making cuts (only from the back) during the installation process, make sure to keep the turf blades going in the same direction when installing.

STEP 7

After you have glued down the artificial turf, use a weighted roller to roll the newly turfed area. This added step will help insure that your new artificial turf installation is properly glued down and adhered to the subfloor.

STEP 8

The last step (OPTIONAL) is to add the turf fill.

- a. Use a large brush broom to make the turf blades stand up.
- b. Apply the turf fill, using a drop spreader, to the brushed turf area.
- c. Make sure to spread the fill evenly as possible across the brushed turf area.
- d. Once the fill has been spread evenly, brush it in lightly to create a finished look.
- e. The artificial turf grass blades should be standing straight up with turf fill underneath.



OUTDOOR INSTALLATION

STEP 1

Make sure your area is flat and has been graded to level.

STEP 2

Next measure your area and map out where the artificial turf will be installed.

STEP 3

Once you have a proper substrate (concrete, rock bed, or sand) you are ready for installation.

STEP 4

Take your time and move slowly when making cuts (only from the back) during the installation process, make sure to keep the turf blades going in the same direction when installing

STEP 5

Use a weighted roller as you are installing the turf down to your substrate. This will help prevent bunching or creases.

STEP 6

Add the turf fill.

- a. Use a large brush broom to make the turf blades stand up.
- b. Apply the turf fill, using a drop spreader, to the brushed turf area.
- c. Make sure to spread the fill evenly as possible across the brushed turf area.
- d. Once the fill has been spread evenly, brush it in lightly to create a finished look.
- e. The artificial turf grass blades should be standing straight up with turf fill underneath.

Warranty

Limited Lifetime Warranty

NANCE
INDUSTRIES

SINCE 1972

WOMEN
OWNED

