

FRONT DOOR DECOR

Assembly Instructions

Includes 1 Sign and Ribbon

ASSEMBLY TIP: Lay out the 3 **Sign Pieces** on a flat surface in descending order to help you visualize the completed sign. The **Top Piece** has one pre-cut hole for hanging.

CARE TIP: For best results, display in temperatures no higher than 130°F and hang on outermost door as placing between two doors risks exposure to excessive heat.

-  Remove **Ribbon** from packaging and cut **1st Ribbon Strip** to desired length for hanging **Sign**. Cut **2nd** and **3rd Ribbon Strips** into 30-inch lengths.
-  Take the **Top Piece** and string **1st Ribbon Strip** through the top hole. Tie **Ribbon** ends into a knot.
-  Along the back of the **Sign**, string **2nd Ribbon Strip** into the top holes of the **Middle Piece** and through the bottom holes of the **Top Piece**.
-  Tie **Ribbon** in a knot behind the **Top Piece**.
-  Using the **3rd Ribbon Strip**, connect the **Bottom Piece** to the **Middle Piece** in the same manner as step 3. Tie **Ribbon** in a knot behind the **Middle Piece**.
-  Hang the **Sign** in your desired location.

