

Car Multimedia Player

Operation Manual

4-5130-001A



Preface

In order to make sure the product fits for the car 100%, customers need to take the measurement of dashboard installation before purchase, mainly the length and height of panel.

In order to prevent injuries and fires, please pay attention to the following instruction:

Please check the car horn line carefully before installation, if it is grounded or collided, you need to rewire the car horn line and connect the product, otherwise the machine will be burned.

In order to prevent short circuit and so on, do not drop the metal object in the device.

If there is smoke or peculiar smell of the device, please turn off the power at once.

Please do not make the device falling or strong collision.

In order to prevent device failure, please observe the following note:

Please do not install the device in the place of strong sunlight, high temperature, high humidity or dusty.

Please replace the fuse which is the same specification. If you are using different specification of fuse, may cause failure of the device.

In order to prevent short circuit, please pull out the power wire when you replace the fuse.

In order to be able at any time to deal with road and traffic conditions change, please lower the volume when driving.

Please do not get the device wet when washing car, this may cause short circuit, then fire or failure will be caused.



Precautions

1. If any abnormal behavior of the unit is found, please use spiky object to press **RESET/RES** key to resume factory default.
2. If you have parked the car in hot or cold weather for a long time, please wait until the temperature in the car becomes normal before operating the unit.
3. No fierce impact to the unit for preventing damage to any mechanisms inside.
4. The unit consists of high precision parts, please do not open the lid or adjust any component without authorization. Any maintenance needed, please go to professional after-sale service center for services.
5. Operate the unit correctly according to this manual to prevent unnecessary problem. The guarantee won't be valid if the problem is caused by inappropriate operation.

Warning

1. Only connect the unit to a DC 12V power supply with negative grounding. If connect 24V will burned the unit.
Remark: Only marked the 24V can be used on the 24V unit.
2. Never install the unit where the operation for safety driving is restrained.
3. Never use the video display function in the front when driving to prevent the violation of laws regulation and also to reduce the risk of traffic accident except using for rear view video camera.
4. Never expose the unit, amplifier, speakers to moisture or water to prevent electronic sparks or fires.
5. Please don't change the fuse in the power cord without professional guidance; improper fuse may cause damage to this using unit or even cause fire.



Installation

The unit installs for security , please install it refer to the following diagram description:

1. Please make the unit in proper place, connect the unit refer to the diagram, and test it works well or not.
2. Please wrapped the connection line with insulation tape to ensure complete wiring after testing well.
3. Please bend the hook of metal ① , and insert the metal to instrument panel then fixed it.
4. Put the unit into metal hook until it lock.


Remove

Note:

1. Please ensure install the unit in the position that doesn't interfere with the normal operations of driver, and no harm for emergency braking.
2. For exactly install, please use the accessories provided by the unit only, otherwise it will cause unnecessary damages. If more holes or other changes in facing or structures are needed, please contact with dealer nearby.
3. Installed after the first power test please press the reset button, then press the clock button to set the clock, the unit can be used normally.

Dismantling:

The unit without key, you can pull out by your hand.



General Features

Support MP4/3GP/AVI/MOV/MPG/M4V/DAT/VOB Video format

Support MP3/WMA/WMV/OGG/APE/ACC/FLAC Audio format

Support JPEG/BMP/GIF Image format

7 Color Backlight

Support FM/AM/RDS radio function and 30 stations preset

Support High Capacity TF card / U-Disk

Support front AUX Audio Input

Clock function

Support EQ Sound Adjust

Support Rear View Camera function

Support Steering Wheel Remote Control

Support SWC Remote / Remote Control function

Support **Boot LOGO** setting

Support BT Call / BT Music function

Support **Rear Microphone** Input

ISO Power Interface

1 way video Input

2 way audio Input

1 way video output

2 way audio output


1 way Subwoofer output

Basic Operation

1. When use reversing rear view function, reversing video signal from the corresponding port input connection back line, when reversing will automatically switch to reversing visual state.
2. Video & Audio output
Connect audio / video lines, when play the video, press button () on the bottom bar of the screen can output the video & audio to the other device.
3. BT function (Only for the unit with BT)
Firstly, open BT function of your phone, and then search BT name of the unit, pairing, enter the **password "0000"** (if it is need), after pairing successfully, the BT symbol  will be turn blue, that will be ok.
When calls come in, it will enter the interface of BT automatically, press  to answering the phone, press  to hanging the phone.




Front Panel Function Description




1. : When power is off, press short time to turn on power; When power is on, short press is turn on/off mute function, long press is turn off power, rotate left or right to adjust volume,
2. **MODE** : Mode switch.
3. : Home Page.
4. **BAND** : Band switch between (FM1/FM2/FM3/AM1/AM2).
5. : **USB / TF Card / BT Music Mode:** Press to select previous track;
Radio Mode: Auto searching radio station backward.
6. : **USB / TF Card / BT Music Mode:** Play / Pause;
Radio Mode: Next radio station stored in (1~6) position.
7. : **USB / TF Card / BT Music Mode:** Press to select next track;
Radio Mode: Auto searching radio station forward.
8. : Switch to **BT Mode** when BT is connected / Answer an incoming call.
9. : **USB / TF Card Mode:** Press to switch between Music and Video mode.
10. : Hang up the phone / Reject the incoming call.
11. **RES** : Reset the unit.

Remote Control Description



- | | |
|--------------------------------------|------------------------|
| 1. Power switch | 10. Menu |
| 2. ◀ Previous Page | 11. Confirm/Play/Pause |
| 3. Mode switch | 12. ▶ Next Page |
| 4. Previous Track | 13. ▼ Under |
| 5. USB/SD | 14. Next Track |
| 6. Volume- | 15. Choice |
| 7. Band/Automatic/
Station search | 16. Volume+ |
| 8. Digital key | 17. Answer the phone |
| 9. ▲ UP | 18. Hang up |

Wire Diagram



Please check the speaker line carefully before installation. If any grounding or touching, please connection again, otherwise the unit will be burned.

Note: Make sure not to damage the unit, please wrap the exposed wires or unconnected

Specification

SNR	65dB
Frequency response	20Hz~20KHz
Loudspeaker impedance	4Ω~8Ω
Tone Control	Bass+/-7dB(100Hz) Treble+/-7dB(100Hz)
FM	
FM frequency	87.5MHz~108.0MHz
Sensitivity	25dB
Selectivity	60dB
Separation	35dB
AM	
Frequency	522KHz~1620MHz (Europe) 530KHz~1710MHz (USA)
Usable Sensitivity	25dB