

Cordless Task Lamps

H019 v02:14/10/20

Please read and retain these instructions for future reference

BERGSTRÖM



Dimensions

19.5cm x10cm x17cm

Composition

ABS

- WITH 12 ULTRABRIGHT LED LAMPS THIS CORDLESS LIGHT CAN BE TAKEN WITH YOU ANYWHERE
- GREAT FOR EMERGENCY LIGHTING, DIY, READING, WRITING, CARAVANNING ETC
- WITH A PIVOTING HEAD YOU CAN POSITION IT AT THE PERFECT ANGLE NEEDED
- LED LIGHTS LAST UP TO 100,000 HOURS
- PUSH BUTTON ON/ OFF SWITCH

Each lamp is powered by 3x 1.5V DC AA batteries (not supplied)

LEDs not replaceable



ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Requires 3x 1.5V 6 AA batteries (not included)

- Open the battery compartment lid
- Insert 3 AA batteries
- Replace the battery compartment lid.

On/Off button modes:

Press once to switch on

Press again to switch off



CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do not shine light directly towards eyes.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.

*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

- Wipe with a clean dry cloth.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

