





Parts List


A x 1


Thermal Grease


B x 1

Pinhead


C x 2


Cotton Swabs


D x 2

Alcohol Pads

Thermal Grease Application Method

⚠ WARNING: Avoid Aluminum Materials



Install the pinhead of TG-60.



Squeeze certain amount of Liquid Metal Thermal Grease on the CPU.
(Please wipe it out if overflowed)



Apply the thermal grease evenly
by cotton swabs.



Complete.