

Smart watch

User Manual



Thank you for choosing our smart watch. You can read this manual to get a comprehensive understanding of the function and operation of the device. The company reserves the right to modify the contents of this manual without prior notice without prior notice.

Product configuration: one package, one manual, one smart band

Operation Guide:

The home button: long press to switch watch, short press to return to the standby interface, when watch crashed, long press 10 seconds to restart .

Watch face switch: long press the screen, there will be a dial choice, tap confirm.


Main menu: Slide right/left to enter, slide left to next page. Slide right to return.



On/Off button

TP gestures: Slide right/left/up to enter the main menu, after entering each function, slip from left to right for return, slip from right to left for confirmation





Charging instructions:

Charging base,USB interface,5V standard charger for mobile phone
About 70 minutes full charge

The connection between the watch and the mobile phone:

First, the mobile phone needs to download the APP “Fundo” to the mobile phone and install it, two ways



- 一、 iOS, Android Mobile User:
Scan the next QR code through the mobile browser,
or use scanner to scan and download the Fundo App.
- 二、 Android Mobile User searches “Fundo” Play Store and
download. iPhone User searches “Fundo” on App Store
and download.

After installation, turn on cellphone Bluetooth and Fundo App,
confirm the notification enable, tap “More” at right bottom
corner, enter add device, search “Smart Watch” device and
tap connect,



then you are succeeding connected the Bluetooth 4.0;

Next go to watch side Bluetooth–searching Bluetooth–select turn on Bluetooth–tap your cellphone name in the list–confirm the connection at your cellphone end. Then you are succeeding connected Bluetooth 3.0.

Only when Bluetooth 3.0 & 4.0 both connected the watch can be abled full performance, slide down the watch you will see the Bluetooth icon, green color at upper means Bluetooth 3.0 is connected, Blue color at bottom means Bluetooth 4.0 is connected.

Only when Bluetooth 3.0 & 4.0 both connected the watch can be abled full performance, slide down the watch you will see the Bluetooth icon, green color at upper means Bluetooth 3.0 is disconnected, Blue color at bottom means Bluetooth 4.0 is connected.

As the Bluetooth protocol is different between all the mobile phone brands. Sometimes the Bluetooth connection will be instability between mobile phone and smart watch. Please restart the Bluetooth, then try to connect again, or restore factory settings. If appear system halted, please long press power button about 10 seconds to restart watch.

How to set the notifications:

Go to phone settings – application management, in “Fundo” – permission management, turn all on.

Notification management – turn “Fundo” all permissions on. Open “Fundo” App – More – App Notification Push – Turn on background run permissions.

Note: make sure that all the third-party Apps which you want receive notifications in the device make sure your phone is enable to receive the notifier in the phone notification bar.

Firmware upgrade:

Under normal connection of Bluetooth, enter “Fundo”, click more in the lower right corner, click firmware upgrade, if there is new version, there will be a progress bar, the upgrade process takes 3–5 minutes, after the upgrade is completed, the bracelet Will automatically power on and reconnect the device, please disconnect the Bluetooth, and then reconnect.



Main function introduction:

Calling

Dial:Bluetooth call via cellphone, talk at the watch end.

Phonebook:Sync all the contacts in the cellphone, max is 400 contacts.

Call logs:Sync all the calls history in the cellphone.

SMS:Sync all the messages in the cellphone (Not support iOS phone yet).

Bluetooth: Search the device you want connect, or disconnect the devices.

Pedometer: check the steps you walked during the day, calories burn and walk distance. Everyday 0 o'clock all the data will be saved automatically and reset to 0. Slide up enter option; status, on and off; history, it can check 7 days local records; Goal, set a target for everyday steps; put into all your information, such as Gender, Height, Weight etc. for more accurate measure your steps data.

Sleep monitor:The smart watch will turn on it automatically from 9p.m to 9a.m. It records your sleep duration and quality, help you adjust a better rest time, improve sleep quality. Slide up enter options; Status, On and Off; History, check out deep sleep and light sleep; instruction.

Heart rate monitor:Wear the watch tightly with your wrist, best position would be upper of the hand–wrist, around 20 seconds it will shows the real time heart rate data, slide down menu into history, mode includes single measure and continuous measure; and instruction. Generally speaking normal value is 60–90 times/min.

ECG: Adopt optical heart rate and ECG combine technology, about 30 seconds can show the data, after test will appear ToAPP, means ECG data save to phone “Fundo”.

Sedentary: Set a long–time reminder of sit, remind you have a stand when time up.



Gesture:Support for call turnover mute, alarm flip over mute, gesture wake up system (ie It is to raise the hand to automatically light screen), shake to answer the call.

Face:Have two standby face can be choose.

Clock:Clock type, there are 4 standby watch faces to choose.

Sound:You can select the caller profile, select Ringtones, select notification ringtones

Volume:Adjustable volume for media, ring tones, notifications, etc.

Alarm:Can setting 5 alarm, long press can cancel alarm.

Stopwatch:Single timing, tap the left icon to start timing, and tap to pause, tap again for cumulative time.

Bluetooth Setting:Turn on/off the Bluetooth in watch.

Power-saving mode:Turn watch on to enter clock mode, other functions are turned off; display, access to adjustable screen brightness and backlight off duration.

Anti-lost: Click “find phone”, connected phone will be ringing warning, after find the phone, tap “End” of the phone to stop the alarm, it works both watch and Apps sides.

Warranty:

1. If it appears quality problems caused by manufacturing, materials, design within one year (since the day of purchase) , we will offer free warranty for main part. We will offer free warranty for battery and adapter within 6 months. Premise is using normally and correctly.

2. About the fault caused by the users' personal reasons, we don't offer free warranty, as follows:

- 1). Disassemble or refit the product.
- 2). Caused by immodesty drop
- 3). All artificial damage or misuse (such as: make water into the host, the external force shatter, scratch damage of peripheral components, etc.), all these are beyond the scope of the warranty.

3. When ask for free warranty, you must provide a warranty card with the seal of purchase place and purchase date.

4. If you met problems during use, please contact the shop customer service which you bought from.

5. Please make the final products as the standard.

