


Hardware basics



Multimedia Hotkeys functions:

- FN+F1=Media Player
- FN+F2=Volume Down
- FN+F3=Volume Up
- FN+F4=Mute
- FN+F5=Play to suspend
- FN+F6=Previous Track
- FN+F7=Play/Pause
- FN+F8=Next Track
- FN+F9=Email
- FN+F10= Web home
- FN+F11=Screen Lock
- FN+W=W A S D and ↑ ↓ ← →swapping
- FN+Win-L= lock WIN andAPP key,
unlockWIN andAPP key

25Key support without conflict (“Q”, “A”, “Z”, “W”, “S”, “X”, “E”, “D”, “C”, “R”, “F”, “V”, “T”, “G”, “B”, “M”, “Space”, “↑(UP)”, “↓(Down)”, “←(Left)”, “(Right)→”, “Tab”, “Ctrl-L”, “Shift-L”, “Alt-L”,)

Safety intructions

- Please read the following carefully before using this product. Incorrect use of this product may result in reduced performance, permanent damage and void warranty:
1. Do not place this product near a heat source.
 2. Operating temperature of 5°C to 50°C. Storage temperature of -20°C to 60°C.
 3. Do not place this product near moisture nor liquids.
 4. Operate and store at humidity of 10% to 85% (non-condensing)
 5. Do not place heavy objects on this product.
 6. Do not drop this product.
 7. Do not dispose this product in the garbage. Take it to your local recycling centre.


Package includes

- 1 * Wired Keyboard
- 1 * Instruction Manual
- 1 * Cleaning brush

Model:SK-623

Instruction Manual

Wired keyboard



CAUTION: To use this device properly, please read the user’s guide before installation.

