


Remote Control

The remote distance is within 32.8 ft. It is magnetic so that you can put it on whatever contain iron, such as the iron pipe, patch and so on. The left key, which is black logo, is used for torchiere lamp and the right, which is white logo, is for reading lamp.



ON / OFF Button:
Short press this button to turn on the light, press it again to turn off.

Color Temperature:
Short press this button to select the color temperature (3000K, 4000K, 5000K).

Bright +:
Short press this button to enhance the brightness as you like.

Bright -:
Short press this button to lower the brightness as you like.

How to match the lamp and remote control?

Make sure the remote control is matching the lamp : power plug in the lamp, use the remote to control the lamp. Normally the remote controls the lamp perfectly ;

If the torchiere or reading remote control doesn't work, please re-match the control (torchiere lamp match by left key which is black logo and reading lamp by right key which is white key).

Matching procedure :

1 Press one power switch bottom of the remote control, hold pressing until match successfully.



2 Power plug in, then the light on automatically.



3 Continue hold pressing the power switch button for seconds, when LED lights flashes, matching successfully.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.

