


Box Contents




- A Wireless Transmitter
- B Wireless Receiver (3)
- C Attachment Clip (3)
- D USB A to C Charge Cable
- E 3-in-1 Charge Cable
- F 3.5mm AUX Cable
- G Mini Optical Cable
- H RCA to AUX Adapter
- I 60cm 3.5mm AUX Cable for Receivers (3)

For Advanced Set Up
Try our Full User Guide, FAQs,
Video Tutorials & More!



avantree.com/support/Audiplex


Charging



ANY
USB
5V/0.5-2A


RECEIVER COMPATIBILITY

Supports AUX/3.5mm .
Unterstützt AUX/3,5-mm .
Prend en charge les entrées AUX/3,5 mm .
Supporta ingressi AUX/3,5 mm .
Admite entradas AUX / 3.5 mm .



Setup

A Optical




OPTICAL ONLY


Ensure your TV/Audio source speaker is set to "External Speaker" and Audio Format is set to "PCM" or turn off Dolby/DTS.
Stellen Sie sicher, dass der Lautsprecher Ihrer TV-/Audioquelle auf eingestellt ist "Externer Lautsprecher" und Audioformat ist auf "PCM" eingestellt oder Schalten Sie Dolby/DTS aus.
Assurez-vous que votre haut-parleur source TV/Audio est réglé sur «External Speaker» et le format audio sont réglés sur «PCM» ou désactiver Dolby/DTS.
Assicurati che l'altoparlante della sorgente TV/audio sia impostato su "Altoparlante esterno" e Formato audio è impostato su "PCM" o disattivare Dolby/DTS.
Asegúrese de que el altavoz de la fuente de audio / TV esté configurado "Altavoz externo" y el formato de audio están configurados en "PCM" o apague Dolby / DTS.

Setup

B AUX 3.5mm



C RCA



Connectivity




Accessories & Add-Ons



Avantree®

Audiplex
Wireless Audio Set
Model # WSTR-2403-S



Quick Start Guide
Schnellanleitung | Guide de démarrage rapide
Guida Rapida all'uso | Guía de inicio rápido

www.avantree.com/support
support@avantree.com
USA/CA: 1-800-232-2078
Check your warranty card for your local region
Ask us about getting a free charger!

CE Recycled Z-PKQG-TR2403S-BLK-V4