


GETTING TO KNOW YOUR CURLING IRON



*Due to continuing product improvements, the actual product purchased may differ slightly from the one shown in this instruction book.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER – Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. **Always unplug appliance immediately after using.**
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into, water or other liquids.
5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

WARNING – To reduce the risk of burns, electrocution, fire, or injury to persons:

1. **This appliance should never be left unattended when plugged in.**
2. **Do not pull, twist, or wrap line cord around appliance.**
3. This appliance should not be used by, on or near children or individuals with certain disabilities.



USER MAINTENANCE


Your curling iron is virtually maintenance-free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION


NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.



KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

OPERATING INSTRUCTIONS

This curling iron is intended for household use. Use on Alternating Current (60 hertz) only. This unit is designed to be operated at 120V AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

TO CURL HAIR

Hair should be clean and dry or damp dry before using the curling iron. Plug the iron into an electrical outlet. Turn on unit. Allow unit to heat up for 30 seconds.

WARNING: The curling iron's nano tourmaline ceramic-coated barrel will get very hot within a few seconds and should not be placed in contact with the skin after the curling iron has been turned on.

13. Do not use an extension cord with this appliance.
14. Do not touch hot surfaces of the appliance. Use handles or knobs.
15. Do not attempt to touch the housing of your appliance near the barrel, as it is hot when in use.

SAVE THESE INSTRUCTIONS

LIMITED FIVE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 60 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed on back, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions.

In the absence of a purchase receipt, the warranty period shall be 60 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 60-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

GETTING STARTED

The iron's unique high heat temperature settings and Instant Heat technology provide styling versatility for all hair types. If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or hard-to-curl hair, keep the heat setting on high. You can vary the iron's temperature according to your particular need!

Temperature Setting Guide	
LED TEMP. CONTROL	HAIR TYPE
Power/Low/Damp 284°F	Delicate, thin, easy-to style hair/loose curls
Medium/Damp 311°F	Average-to-thick or treated hair loose curls
Med-High 338°F	Thick or wavy hair/tighter curls
High/Max 365°F-400°F	Hard-to-style hair/tighter curls

For best results, use a light styling product before blow-drying hair. Start curling with a hair section that is 1 in. wide and no more than ½ in. thick. Open the spoon and place hair section on the barrel, rolling up, close to the scalp. Release the pressure on the spoon clip and allow the hair section to slide out. Repeat process on additional sections of hair until you achieve the hair style you desire. Some experience is necessary when learning to use this curling iron. After using the iron several times, you will learn the ideal way to curl and style your hair.

A bonus protective heat shield has been included to safely store the product away when hot. Great for use at home or when traveling. Do not leave unit plugged in when not in use.

DRYING SYSTEM WITH UNIQUE WET • DRY DESIGN

This Wet • Dry Nano Tourmaline Ceramic Curling Iron features our exclusive vent and channel design, allowing for use on dry or damp hair. When used on damp hair, excess water is forced into channels where it can escape as steam. The steam evaporates through the vents in the housing, while the hair's natural moisture is sealed into the cuticle, creating silky, healthy-looking curls. Use on damp hair to create loose curls. Create tighter curls on completely dry hair.

CUSTOMIZE YOUR CURL



CAUTION: Steam evaporating through the vents may be hot. During use avoid touching or blocking the vents and direct steam vents away from your scalp and face.

Please register this product at:
www.conair.com/registration

©2011 Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

For info on any Conair or Infiniti by Conair product call: 1-800-3-CONAIR or visit us on the web at: www.conair.com/infiniti


11NP114079

IB-10032

infiniti**PRO** by CONAIR

1¼ in. **wet•dry**
nano tourmaline ceramic
curling iron

new
wet•dry iron
curl as you dry



Instruction & Styling Guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Model CD108WFN

STYLING WITH THE NEW NANO TOURMALINE CERAMIC EASY-GLIDE BARREL

The barrel of your new curling iron has a tourmaline ceramic easy-glide surface, the newest technology. This means it's not only simpler to clean off styling product residue, etc., after each use, but you'll find that hair glides easily over the surface of the barrel as you're curling. The nano tourmaline ceramic surface also helps smooth down flyaways and frizzies. It evenly distributes heat so that the style you create has a salon-perfect, silky smooth, shining finish. Hair also slips right through the barrel after it's curled.

The new NanoTourmaline Ceramic technology is a pleasure to work with and makes styling your hair easier and the results more professional.

Never leave your curling iron on and unattended. However, should you fail to turn the iron off, it will shut itself off automatically within 60 minutes.

USING INSTANT HEAT, THE 5 HIGH HEAT TEMPERATURE SETTINGS & UNIFORM HEAT RECOVERY SYSTEM

This styling iron features a ceramic heater that maintains constant temperature during use for precision styling.

This Instant Heat technology has 5 high heat temperature settings. There is a temperature range that's gentle and safe for every type of hair, from the finest to the curliest and most resistant, and helps you create the look you want. And that's not all. Conair's professional salon standards of engineering provide you with a uniform and improved heat recovery system that maintains the iron at constant temperatures. There is a constant surge of power to ensure that heat is continuously and quickly delivered for optimal styling results, unlike other units, which lose heat during use. This provides consistent styling power so that every strand of your hair is set with the same level of heat and comes out the same way for a perfect finish.

FAMILIARÍCESE CON SUS TENACILLAS



*El producto comprado puede diferir ligeramente del producto enseñado.

MEDIDAS DE SEGURIDAD IMPORTANTES

Siempre que use aparatos eléctricos, especialmente en la presencia de niños, debe tomar precauciones básicas de seguridad, entre las cuales las siguientes:

LEA TODAS LAS INSTRUCCIONES ANTES DE USARLO

MANTÉNGALO ALEJADO DEL AGUA

PELIGRO

- Cualquier aparato enchufado permanece bajo tensión, aunque esté apagado. Para reducir el riesgo de muerte o herida por descarga:

1. **Siempre desconecte el aparato inmediatamente después de usarlo.**
2. No lo use en el baño o la ducha.
3. No coloque ni guarde este producto donde pueda caer o ser empujado a una bañera o un lavabo.
4. No coloque el aparato ni lo deje caer al agua u otro líquido.
5. Si el aparato cayera al agua, desconéctelo inmediatamente. **No toque el agua.**

ADVERTENCIA

- Para reducir el riesgo de quemaduras, electrocución, incendio o heridas:

1. **Nunca deje el aparato desatendido ni cuando esté conectado.**

INSTRUCCIONES DE MANTENIMIENTO


Su aparato requiere poco mantenimiento. No necesita lubricación. Mantenga todas las aberturas libres de polvos y pelusas. Cuando sea necesario limpiarlo, desenchúfelo, permita que enfíe y limpie la superficie exterior con un paño humedecido. En caso de mal funcionamiento, desconecte el aparato, permita que enfíe y regréselo a un centro de servicio autorizado. No trate de repararlo.

PRECAUCIÓN


NUNCA jale, retuerza ni doble mucho el cable. Nunca lo enrolle con fuerza alrededor del aparato. Esto podría dañar la junta flexible que lo conecta al aparato, produciendo su ruptura o un cortocircuito. Revise el cable con frecuencia para asegurarse de que no esté dañado. Deje de usar el aparato inmediatamente si el cable parece dañado o si el aparato dejara de funcionar o funcionara de manera intermitente.

ALMACENAJE

Cuando no lo utiliza, su aparato es fácil de almacenar. Permita que enfíe y guárdelo en un lugar seco y seguro, fuera del alcance de los niños. No tiree ni retuerza el cable al nivel del enchufe. No enrolle el cable alrededor del aparato. Permita que el cable cuelgue o que la junta que lo conecta al aparato esté suelta y recta.



MANTÉNGALO ALEJADO DEL AGUA



Todos sabemos que no se debe mezclar la electricidad y el agua. Pero ¿Sabe usted que un aparato eléctrico permanece bajo tensión aunque esté apagado? Si está conectado, hay corriente. Por lo tanto, siempre desenchufe los aparatos eléctricos después de usarlos.

SIEMPRE DESENCHUFE LOS APARATOS PEQUEÑOS

15. El cuerpo del aparato cerca de la salida de aire se vuelve muy caliente durante el uso. No lo toque.

GUARDE ESTAS INSTRUCCIONES INSTRUCCIONES DE OPERACIÓN

Para uso doméstico solamente. Úselo solamente con Corriente Alterna (60 Hz) de 120 voltios (120V AC).

El cable de este aparato está dotado de una clavija polarizada (una pata es más ancha que otra). Como medida de seguridad, se podrá enchufar de una sola manera en la toma de corriente polarizada. Si no entrara en la toma de corriente, invíértela. Si aún no entrara completamente, comuníquese con un electricista. No intente ir en contra de esta función de seguridad.

FUNDAMENTOS DEL RIZADO

El cabello debe estar limpio y seco o húmedo. Enchufe el cable en una toma de corriente. Encienda el aparato. Permita que el aparato caliente durante 30 segundos.

ADVERTENCIA: El tubo se volverá extremadamente caliente en segundos. Evite todo contacto con la piel después de encender el aparato.

GARANTÍA LIMITADA DE CINCO AÑOS

Conair reparará o reemplazará (a su opción) su aparato sin cargo por un período de 60 meses a partir de la fecha de compra si presentara defectos de materiales o fabricación.

Para obtener servicio técnico bajo esta garantía, regrese su aparato al Centro de Servicio indicado al dorso, junto con su recibo de compra y un cheque o giro postal de US\$5.00 por gastos de manejo y envío. Los residentes de California sólo necesitan dar una prueba de compra y deben llamar al 1-800-3-CONAIR para recibir instrucciones de envío.

En ausencia del recibo de compra, el período de garantía será de 60 meses a partir de la fecha de fabricación.

CUALQUIER GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 60 MESES DE LA PRESENTE GARANTÍA ESCRITA. Algunos Estados no permiten limitaciones sobre la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted.

CONAIR NO SERÁ RESPONSABLE, EN NINGÚN CASO, POR NINGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA.

Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

FUNCIONAMIENTO BÁSICO

Este aparato ofrece 5 opciones de temperatura, para todo tipo de cabello, y calienta muy rápidamente. Si su cabello es fino, le recomendamos que utilice un nivel de temperatura bajo. Si su cabello es espeso, grueso, ondulado o resistente, le recomendamos que utilice un nivel de temperatura alto. ¡Personalice la temperatura, según su tipo de cabello!

Guía de temperatura

AJUSTE DE TEMPERATURA	TIPO DE CABELLO
Encendido/Bajo/Húmedo 284 °F	Cabello delicado, fino o dócil/rizos amplios
Medio/húmedo 311 °F	Cabello normal, espeso o tratado/rizos amplios
Medio-Alto 338 °F	Cabello grueso u ondulado/rizos apretados
Alto/Max 365 °F–400 °F	Cabello resistente/rizos apretados

Para lograr resultados óptimos, aplique una loción fijadora ligera sobre el cabello antes de peinarlo. Divida el cabello en secciones de 2 pulgadas de ancho por ½ pulgada o menos de espesor. Abra las tenacillas y ponga una sección de cabello entre la pinza y el tubo. Enrolle el cabello alrededor del tubo, hacia el cuero cabelludo. Presione la manija para aflojar el cabello. Repita el proceso con cada sección de cabello.

Será necesario experimentar un poco al principio. Con práctica, encontrará la manera perfecta para rizar su cabello fácil y rápidamente.

Su aparato también incluye protector térmico que le permitirá guardar el aparato aún caliente. Es ideal para uso en casa o cuando viaja. No deje el aparato conectado cuando no esté en uso.

EXCLUSIVO SISTEMA HÚMEDO • SECO

Este aparato puede usarse para rizar el cabello húmedo o seco, por lo que está equipado con nuestro exclusivo sistema de conductos y rejillas. Cuando el cabello está húmedo, el exceso de agua penetra en los conductos donde se transforma en vapor. Luego, el vapor sale por las rejillas. Este proceso preserva la hidratación del cabello, creando rizos sedosos y resplandecientes de salud. Úselo sobre el cabello húmedo para crear rizos amplios. Úselo sobre el cabello seco para crear rizos apretados.

RIZOS AL GUSTO



PRECAUCIÓN: El vapor que sale de las rejillas puede ser muy caliente. Evite tocar o bloquear las rejillas durante el uso y no dirija el vapor hacia el rostro o el cuero cabelludo.

INFINITI^{PRO} by CONAIR

32 mm para cabello húmedo•seco
cerámica/turmalina tenacillas

IVO
abello
•seco
riza
o paso



instrucciones cuidadosamente antes de usarlo.

Modelo CD108WFN

Para registrar su producto, visítenos en:
www.conair.com/registration

©2011 Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

Para más información sobre los productos Conair o Infiniti by Conair™, llame al:
1-800-3-CONAIR o visítenos en:
www.conair.com/infiniti

11NP114079

IB-10032