

CONFIER

Shiatsu foot massager



User Manual
CF-5250



Safety Instructions



Please read the following instructions carefully before putting your massage device into use to ensure trouble-free operation and optimum efficiency. Please retain these instructions for further reference!

- The device conforms to recognized technical principles and the latest safety regulations.
- This item is NOT A TOY. Close supervision is necessary when this appliance is used by, on, or near children or disabled persons. Do not allow children to play with product.
- Do not allow more than one person to use this product at a time.
- The device should never be left unattended when plugged in.
- Never use any power sources other than UL standard home adapter provided as original equipment with this massage device.
- Any possible repairs may only be carried out by authorized expert staff. Improper use and unauthorized repairs are not permitted for safety reasons and lead to loss of warranty.
- Please avoid contact of the device with water, high temperatures and direct sunlight.
- Do not damage, process, excessively bend, pull hard, twist or knot power cord.
- Do not use any damaged cables, plugs or loose sockets.
- Do not use the product when the power cord is damaged.
- In case of malfunction, disconnect immediately from the mains.
- Misuse or incorrect use excludes any liability for damage.
- Do not use while you sleep.
- In order to avoid excessively stimulating the muscles and nerves, the recommended massage time should not be exceeded 15 minutes at a time.
- Do not use this product for medical treatment.
- During use, if you feel abnormal, please stop using this product immediately, and then consult your doctor.



We recommend that those with any of the following conditions consult a doctor before using this massage device.

1. Those who are using electronic medical instrument imbedded in the body, such as cardiac, pacemaker etc.
2. Those who are being treated by doctors, especially those who feel uncomfortable.
3. Those who are malignant tumor patients, heart disease patients, acute patients.
4. Women who are pregnant or menstruating.
5. Those with osteoporosis or fracture spine.
6. Those with skin disease or those whose skins are injured.
7. Those whose body temperature is over 38 degrees (Febrile Phase).

Failure to observe the above instructions may constitute misuse of the product and can cause serious injury or burns.



Instruction

Thank you for purchasing COMFIER foot massager.

With normal care and proper treatment, it will provide years of reliable service.

Please read all instructions carefully before using this product.

Please retain this manual for future reference.

FEATURES

- 2 massage techniques combined: kneading & compression
- 3 Preprogrammed massage modes
- Optional heat function for insteps and soles of the feet
- 3 levels of massage intensity
- Detachable and washable foot sleeve
- A timer of 15 or 30 minutes to auto shut off

CONTENTS



12V home adapter

TECHNICAL DATA

Measurements:	17.5X7.5X13.6 inches
Weight:	8.25 lbs
Voltage:	Input: AC 100-240V ~50/60Hz Output: 12VDC 4.0A 48W
Nominal Power:	48W
Automatic runtime:	15 or 30 minutes



Setup and Operation

1. Please place the product on the flat floor.
2. Connect the adapter cable to the corresponding port on the massager



3. Plug the home adapter into electrical outlet (the adapter is safe to use with both 110-120V & 220-240V)
4. Turn on the device through operating control panel (instructions on page 5).




- Before plug ,please check and make sure the power cord is undamaged.
- Do not use the wet hand to plug in the adapter.
- Please don't use the product by standing posture or put any heavy object on the product to avoid any broken caused.
- Please don't stand or seat on the product.
- When moving the product, please don't pull the power cord or drag the product directly to avoid any damaged caused.
- Please don't let children and pets play the products for preventing any accident happened.
- Do not use the wet hand to pull out the power cord in order to avoid any electric shock.
- Do not use this product in damp environment to avoid electric shock.



Setup and Operation

- Please choose a chair with desired height and be seated, then put your feet on the product.
- Operate below control panel to get foot massages.



1.Power button: Press this button to turn on or turn off the product;
Default massage mode: 15 minutes, roller speed L block, air pressure L block, full foot heating mode open, corresponding indicators are always on (red);

2.Timer button:The timer is 15 minutes by default, and the indicator is red;
Press this key to switch to a 30-minute shutdown,and the indicator is blue;
The timing interval switches between 15 and 30 minutes.

3.Rolling massage mode button: Press this button,The default roller speed is L (low speed), ; Press this key to switch to M (medium speed); Press this key again, switch to H (high speed). Follow the "L→M→H→L" cycle,the corresponding indicator is red on

4.Airbag control button: In the boot state, the default pressure is L block (low pressure), ; Press this key to switch to M (moderate pressure); Press this key again, switch to H (high pressure); Follow the "L→M→H→L" loop switch,Follow the "L→M→H→L" cycle,the corresponding indicator is red on.

5.Heating button: Press this button to control the heating function; When the product is turned on, the default temperature for heating function is 45-50℃ (113-122 ℉) with blue indicator light on; If you feel that the temperature is low, press this button again. If the red indicator light is on, the temperature for the heating function would be 50-55℃ (122-131℉).

Note:

- Do not setup or use the device in a bathroom or similiary wet / damp areas.



Maintenance and Troubleshooting

- Before cleaning, make sure the power supply is turned off and the plug has been pulled out from the socket.
- Use a soft dry cloth to wipe the surface of the product and control panel.
- Do not pull the power plug by damp hands.
- Do not use water washing product, do not spray the water or other liquids to the interior of the product.
- Do not use corrosive cleaning agents like benzene or thinner to clean the Massager, otherwise, the color of upholstery will fade or the Massager will crack or be eroded.
- When product is wet, let the product dry naturally and thoroughly.

Removable & Washable Foot Sleeve

- Detach the sleeve and wash in machine or by hand. Allow to air dry

Maintenance

- Make sure the power supply is turned off and the plug has been pulled out from the socket.
- Sweep off the dust. Keep the foot massager clean and away from damp places.
- Store the massager in a cool, dry place out of reach of children.
- Avoid contact with sharp edges or pointed objects which might cut or puncture the cover of massager.

TROUBLESHOOTING GUIDE

Fault	Solutions
There is a clattering noise in the movement	This is normal caused by the working of the motor while in use.
The massage device switches off suddenly	Device may have been in use for 15 minutes. Auto-shut off function activated. Continue using by pressing the 'power' button after resting the unit for 15 minutes.
The massage device fails to start	Check if device has been used for more than 15 mins. If so, let device rest for 15 mins before continuing. Device may require longer time to cool in warmer environments.
	Check if adapter is plugged into socket.
	Check if adapter output is connected to device power inlet.

- After continuously using the massager for a prolonged period, the massager might turn off automatically due to the overheating protection feature. Please let the machine cool down for approximately half an hour before using the massager again.



Warranty

If you have any issue about the product, please feel free to contact us by sending email to supportus@comfier.com We will strive to provide the best service possible within 24 hours.

30 days unconditionally Return

Comfier product can be returned to receive a full refund for any reason within 30 days. Please contact our customers service (supportus@comfier.com), our staff will contact you within 24 hours.

90 days refund/replace

Comfier product can be returned / replaced within 90 days if the product break down in the period of proper use.

12 months Warranty

If the product break down within 12 months in the period of proper use, customers can enjoy the relevant warranty to get a replacement.

Attention!

No warranty will be given to any force majeure or man-made causes to the product, such as improper care, personal tear down and willful damage,etc.

Extend Warranty for Free

- 1) Enter the following URL or scan the QR code below to find COMFIER facebook page and like it, enter“Warranty” to messenger to extend your warranty from 1 year to 3 years.



<https://www.facebook.com/comfiermassager>

- OR 2) Send message“Warranty” and email us supportus@comfier.com to extend your warranty from 1 year to 3 years.

Have question ?

 **Tel:** (248) 819-2623
Monday-Friday 9:00AM-4:30PM

 **Email:** supportus@comfier.com



FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



COMFIER TECHNOLOGY CO.,LTD.
Address:573 BELLEVUE RD
NEWARK, DE 19713 USA
www.facebook.com/comfiermassager
supportus@comfier.com
www.comfier.com

