




AVERY OFFICE DESK


(OAK)

OVAVEROFDOA


COMPONENTS

Lay all components out on a clean floor and ensure all parts are included. If any pieces are missing, check all packaging thoroughly, then contact help.Kogan.com for assistance.

Parts




Hardware





ASSEMBLY

Step 1:


		
A (x4)	B	D




Step 2:




Step 3:

	
G (x8)	H (x8)





Step 4

	
H (x8)	J (x8)




Step 5




Step 6



							
A (x4)	C	E	F (x4)	G (x4)	K (x4)	L	M




Step 7








Step 8

			
N (x6)	O (x6)	I	P




Step 9

	
J	Q



Step 10



Complete!

NOTES

[illegible]



Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

kogan.com