


3 in 1 Flickering Flame Solar Lantern

K764 v001: 16/03/22

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

Always position in direct sunlight.



Wall mounted: H29x W29 x
D12.5cm



Large stake – H152 x W29 x
D12.5cm



Small stake - H54 x W26 x
D13cm – including stake
17cm stake

Includes 1x AA600mAh 1.2V
Ni-MH rechargeable battery
per lantern

- 2 FLICKERING LED (not replaceable)
- FREE STANDING, STAKE INTO THE GROUND AND WALL MOUNTABLE
- VICTORIAN STYLE LIGHTS
- REQUIRED FIXINGS ARE SUPPLIED
- WEATHER PROOF
- AUTOMATIC ON/OFF AT DUSK AND DAWN

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

**The Enterprise
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.



3 in 1 Flickering Flame Solar Lantern K764 Instructions for Use


Please read and retain these instructions for future reference

v001: 16/03/22

Assembly Instructions


Remove clear protective film off solar panel.

1. Turn lamp anti-clockwise to open the lamp. Turn clockwise to close (A). slide power switch to turn ON/OFF (B).



2. Insert lamps (A) into lamp holder (C). Then insert skirt piece (D) into lamp holder (C).

2.



Connect pole (E) with stake (F). Then grab pole (E) and press down firmly while carefully manoeuvring from side to side until stake is completely into the ground as shown in Step 4. To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil.

The Enterprise Department


UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU
Tel: 0844 4824400*, Fax: 01279 756595
www.coopersofstortford.co.uk
EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France
Tel: (+44) 1279 701269
*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.



3 in 1 Flickering Flame Solar Lantern K764 Instructions for Use


Please read and retain these instructions for future reference

v001: 16/03/22



3. Proceed to connect the rest of the poles (E). Then hold the top pole (E) firmly while inserting the skirt piece (D) into the pole.
4. Optional: Install wall mount (G) with the fixings provided. Remove skirt piece (D) from lamp holder (C) and connect lamps (C) with wall mount (G).

5.



Before using first time

Allow lamp to charge for at least 8 hours in full sunlight with the ON/OFF switch in the ON position. The ON/OFF switch is located inside the lamp. Once the batteries are fully charged, set the ON/OFF switch to ON. If the lamp does not turn on after dark refer to Maintenance section.

The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

3 in 1 Flickering Flame Solar Lantern K764 Instructions for Use

Please read and retain these instructions for future reference

v001: 16/03/22

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically.

Care and Maintenance Recommendations:

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.
3. Replacing used batteries: Only use 1x AA600mAh 1.2V Ni-MH rechargeable battery per lantern and note the +/- markings on the battery when fitting.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



**The Enterprise
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU
Tel: 0844 4824400*, Fax: 01279 756595
www.coopersofstortford.co.uk
EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France
Tel: (+44) 1279 701269
*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

