

PCG02 -AWOW-NV41A-操作指南
93.2*93.2 (R11.6mm) 折前372.8*93.2mm
105双铜-双面4C-封面过耐磨油-风琴折

AWOW®

NY41S

Quick Start Guide

Packing List

Thanks for choosing AWOW NY41S

NY41S

5V = 3A Switching Adaptor

UK

US

GS

* Plugs are optional depended on the sales regions

HDMI Extension cable

Quick Start Guide

Specification

OS

CPU

GPU

Memory

Storage

Wireless

Audio Output

Video Output

Connectivity

Windows® 10 (64-bit)

Intel® Gemini® Lake J4105

Intel® HD Graphics 600

4GB/8GB LPDDR4

64GB/ 128GB eMMC

802.11 ac/b/g/n WiFi & Bluetooth

HDMI , Mini DP , 3.5mm Audio Jack

HDMI 2.0, Mini DP 1.2

2 x USB 3.0 Host, Micro-SD Card Slot

1 x RJ45 LAN Port

Correct official paid—already Microsoft Windows 10 license, 6 kinds of languages kit pre-loaded and all other languages kits available to be installed.

Service

E-mail: support@awowtech.com

AWOW®

www.awowtech.com

CE

10

RoHS

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

NY41S

The LED indicator turns blue when you power on the Mini PC stick

Interface

Power Button

DC-IN

USB 3.0 Host

Micro-SD Card Slot

USB 3.0 Host

HDMI Output

Audio Jack

Mini DP Output

RJ45 LAN Port

Kensington Lock Slot

Connect to HDTV / Monitor

Adjusting the resolution of video output via HDMI / VGA to HDTV or Monitor

Follow the steps below to adjust the video output when connecting the mini PC to a HDTV or monitor via HDMI/ VGA

1. Presse right key of mouse and choose Graphics Propertis .

2. Double click Display.

3. Choose the correct "resolution" and "Refresh Rate" to adjust to correct display on TV.

Connect to HDTV / Monitor

Configuring audio output via an HDMI device or Audio digital devices

Follow the steps below to enable audio output when connecting the mini PC to a TV or audio digital devices via HDMI or 3.5mm audio jack.

1. Access the Sound settings via the system Control Panel.

2. Under Playback devices, click the display device that corresponds with your HDMI audiocompatible display

3. Click the Set Default button in the lower right hand corner.

4. Click OK to exit the setup.