

HAYLOU

产品介绍

麦克风2
LED灯

MFB键

麦克风1

充电触点

Haylou X1
降噪真无线蓝牙耳机
使用说明书

将耳机轻轻塞入耳道，调整耳机达到最佳佩戴状态。

Type-C
充电接口

LED灯

佩戴耳机

将耳机轻轻塞入耳道，调整耳机达到最佳佩戴状态。

充电

首次开机使用，将充电盒及耳机充满电。
插入充电线可同时给耳机和充电盒充电。
耳机充电：放入充电盒充电，红色灯常亮，充满后指示灯亮60s后熄灭。

充电盒电量指示说明

打开/关闭盖子，三个灯闪烁3次后，显示实际电量。电量大于30%，电量指示灯才会常亮10秒并发出两次常亮提示音，需再次充电；后续每次充电(满电)充电盒低电量提示：低于30%，LED频闪2s/烁3次，持续循环一分钟后再提示。

关机

放入充电盒中盖紧，耳机自动关机。

开机

耳机在充电盒内，开盖耳机自动开机。
耳机在充电盒外且关机状态下，长按MFB键约1.5秒开机。

连接配对

自动连接：开盖耳机自动开机，打开设备蓝牙搜索“Haylou X1”并点击完成连接。
如果连接失败，将耳机放回充电盒，重置上述操作。初次连接后，耳机开机可自动回连上一次配对设备（蓝牙需开启）。

功能说明

单击MFB键
音乐时，播放/暂停

双击MFB键
来电时，接听电话

双击左耳MFB键
音乐时，切换上一曲

双击右耳MFB键
音乐时，切换下一曲

长按MFB键约4s
切换ANC模式

三击左耳MFB键
待机时，启动/关闭游戏模式

三击左耳MFB键
待机时，启动语音助手

耳机重置

如果耳机无法正常连接使用，请参照以下方式：
耳机在充电盒内且充电盒有电量情况下，长按双耳MFB按钮10秒，此时耳机自动恢复出厂设置（包括清除两耳只耳机串联记录和与设备配对的记录）。
若操作不成功，请重复以上步骤；或登录官方旗舰店，联系客服，查看复位操作视频。

充电时的注意事项

极端情况才会出现此类情况，发生后请参考耳机重置步骤，然后检查手机上的蓝牙连接状况，清除蓝牙设备后重新连接即可。

充电时遇到的问题

1、耳机充满电后，白灯常亮1分钟后熄灭，此时耳机处于待机状态。
2、充电仓没电会导致耳机无法充电，关盖无法关机/断连，开盖也无法开机。
3、充电盒充满电后，充电指示灯会亮起，此时若再次接入充电线，充电指示灯则不会提示，不代表充电盒不能充电。

小爱同学语音助手

小爱同学APP，是基于语音交互的人工智能助手。她可以帮你便捷地查询天气情况、问时间和日期、高效出行让效率飞速提升。还可以随时找小爱聊天，度过闲暇时光。连接蓝牙设备，还可远程操控，是手机必备的个人助理。
智能语音功能需下载小爱同学APP使用，扫描下方二维码二码即立即下载小爱同学APP。

连接小爱同学

设备快速连接下载并打开小爱同学APP。
将耳机放入充电盒，关盖靠贴近已解锁并开启蓝牙功能的手机，打开充电盒盖，按照手机界面提示操作连接耳机。

设备手动连接

开启蓝牙监听。
下载并打开小爱同学APP，点击APP首页的头像，然后点击“蓝牙设备”进入“我的设备”页面，点击“+”添加设备，按照手机界面提示操作连接耳机。

常用功能示例：

今天天气怎么样 “谢谢你”用法怎么说
我想听相声 暂停 今天是农历几号
声音大一点 定个明天早上八点的闹钟

包装内容物

耳机，充电盒，耳机3对（中号已装入耳机中）充电线，说明书。

耳机基本参数

通讯距离：10米（无障碍空旷环境）
电池容量：45mAh（单耳机）
充电时间：约2小时
通话时间：约4小时
待机时间：约60小时
输入参数：5V=100mA
电池类型：可充式锂离子电池
无线连接：蓝牙5.2

充电盒基本参数

输入参数：5V=500mA
输出参数：5V=150mA
充电时间：约2小时
电池容量：600mAh
电池类型：锂离子聚合物

日常维护

请勿佩戴耳机洗澡、淋雨，放入洗衣机及在异常温度情况等极端环境使用，每次正常使用后，请用干布等工具擦干耳机上的汗水或者雨水，可以有效延长耳机的使用时间。

注意事项

警告

1. 请勿以任何理由拆机、维修或改装耳机，否则可能会导致起火甚至彻底损坏本产品。
2. 请勿将该设备置于通过过低或过高（0℃以下或45℃以上）的环境下。
3. 使用产品指示灯时，请避开儿童或动物的眼睛。
4. 请勿在雷暴天气下使用本产品，雷暴可导致设备工作异常，并增加触电的危险。
5. 请勿使用酒精或其他挥发性液体擦拭本产品。
6. 请勿将本产品与液体接触。

注意

1. 使用产品前请仔细阅读本使用说明书并妥善保管。
2. 首次使用时，请先将本产品充满电。
3. 如果产品长期(超过2个星期)不用，请对其充电。
4. 必须选择正规厂家生产且经过国家CCC认证的充电器。
5. 长时间连续使用耳机会有热损力，请合理控制使用时间及时休息。
6. 使用耳机可能会对外界声音的感知力，请不要在可能威胁到安全的环境中使用耳机。

产品中有害物质的名称及含量

部件名称	铅(Pb)	镉(Cd)	汞(Hg)	六价铬(Cr(VI))	多溴联苯(PBBs)	多溴二苯醚(PBDEs)
耳机主体	○	○	○	○	○	○
电池	○	○	○	○	○	○
耳機	○	○	○	○	○	○
充電盒	○	○	○	○	○	○

三包凭证

产品名称	用户姓名	购买日期
产品信息	联系电话	邮政编码
	用户地址	
购买地点	销售商名	
	订单号码	

售后服务与支持

保修期：
自产品购买之日起12个月(请妥善保管购买凭证)
免费服务：
在产品保修期内，凡属产品本身质量问题引起的故障，请用户凭购买凭证与经销商取得联系以享受售后服务。
如有任何产品损害或瑕疵不可归责于产品质量问题，则不在保修范围内。有下列情形者不属于保修范围：
1、因天灾、地震、雷击、异常电压、环境因素而造成产品损坏或损毁的。
2、自行或委托非授权门店擅自对产品进行拆卸、改造或更换非原厂零件。
3、未按使用手册操作或因人为使用不当而造成损坏者，如产品进水、腐蚀、掉落、挤压或露在高温高湿度环境下。
若有售后服务需求，请联系Haylou客服
制造商：东莞市海楼电子科技有限公司
制造地址：广东省东莞市南城街道
服务热线：4008-551-401-410-410
网 址：www.haylou.com
客服电话：4008-551-403





Haylou X1 性能故障表

名称	性能故障
蓝牙耳机	1.使用耳机听不到声音。 2.通话过程中，对方听不到声音。 3.无法充电。

非保修条例

1、使用过程中正常磨损脏污方面：刮痕、颜色改变；因接触化学试剂、接触尖锐物体、掉落摔落等人为导致损伤。
2、未经授权的维修、误用、碰撞、撞击、滥用、过压、事故、改动、不正确的使用非本产品配件造成的损坏、涂改标记、仿伪标记。
3、已超过三包有效期限。
4、因不可抗力造成的损坏。
5、不符合《性能故障表》所列性能故障的情况。
6、因人为疏忽导致电子产品及其附件产生《产品性能故障表》所列性能故障。

说明书中的产品、配件、用户界面等插图均为示意图，仅供参考。由于产品的更新和升级，产品实物与示意图可能存在差异，请以实物为准。

Haylou X1 ANC & ENC True Wireless Earbuds User Manual 	Overview   How to Wear  Please adjust earbud to fit you best.  When calling, adjust Mic 1 towards mouth to gain better talking experience. How to Charge - Fully charge the charging case and earbuds before first use. - Insert the charging cable to simultaneously charge the earbuds and the charging case. Earbuds: Put them back into the case, the earbuds indicator light is solid red. After fully charged, the indicator light is solid white for 60s and then goes out. 	Battery Indicator of Charging Case Open/close the lid, the actual battery level will be displayed after three lights flash 3 times. When the battery is greater than 30%, the battery indicator will be on for 10s and then go out. (You need to close the case first then open to check battery level display again) Low battery prompt of charging case: less than 30%, LED flashes 3 times every 2s, and goes out after 1 minute of continuous circulation. <table border="1"> <thead> <tr> <th>Flashing status</th> <th>Battery percentage</th> </tr> </thead> <tbody> <tr> <td>✦ ✦ ✦</td> <td>70%-100%</td> </tr> <tr> <td>✦ ✦ ✦</td> <td>30%-69%</td> </tr> <tr> <td>✦ ✦ ✦</td> <td>0-29%</td> </tr> </tbody> </table> Power-on When the earbuds are in the charging case, open lid to power on. When the earbuds are outside the case and in power-off state, long press the MFB button for about 1.5s to power on.  LED glows white for 1s Long press for about 1.5s Power-off Put earbuds back into case and close the lid, they will automatically power off.	Flashing status	Battery percentage	✦ ✦ ✦	70%-100%	✦ ✦ ✦	30%-69%	✦ ✦ ✦	0-29%	How to Connect Take out both earbuds from the case simultaneously. Open device Bluetooth, search for "Haylou X1", and click to connect. If connection fails, put earbuds back into case and try again. After connection, earbuds will automatically re-connect to the last-paired device whenever powering on (Bluetooth needs to be turned on).  Switch between mono and stereo mode: Pick up two earbuds to auto enter stereo mode and push one back to enter mono mode. Or you can pick it up again to resume stereo mode. Manual connection: When earbuds are turned off, manually turn on the two earbuds. Wait 2-3s for the earbuds to turn on and connect with each other. When indicator lights on both earbuds flash white slowly, turn on device Bluetooth to connect.								
Flashing status	Battery percentage																		
✦ ✦ ✦	70%-100%																		
✦ ✦ ✦	30%-69%																		
✦ ✦ ✦	0-29%																		
How to Use  - Click MFB button Play/Pause music - Click MFB button Answer incoming call - Double click MFB button on L Skip track backward - Double click MFB button on R Skip track forward - Long press MFB button for about 4s Switch ANC mode - Triple click MFB button on R Turn on/off game mode when standby - Triple click MFB button on L Summon voice assistant when standby	Factory Setting If the earbuds cannot be connected and used normally, please refer to the following methods: When the earbuds are in the charging case and the charging case has power, long press MFB button for 10s, the earbuds will automatically be reset (the connection records between the two earbuds and device will be cleared). * If the operation fails, please repeat the above steps, or log in to the official store, contact customer service to view the reset operation video. Audio only Outputs from Single Earbud It's unusual indeed, please set earbuds to factory, remove connectivity record on phone and re-connect. Other Charging Problems - The earbuds won't be charged if the charging case is out of power. The earbuds can't power off/disconnect when closing lid and can't power on when opening lid. - LED doesn't turn on when charging the case. It means that the case has been fully charged so the light does not turn on. Package List Earbuds, charging case, 3 pairs of ear tips (M size has been pre-installed), charging cable, user manual. Basic Parameters(earbuds) Operation range: 10m (open space with no obstacle) Battery capacity: 45mAh(single earbud) Charging time: approx. 2hr Standby time: approx. 60hr Input parameter: 5V = 100mA Battery type: Rechargeable li-ion button battery Bluetooth version: V5.2 Basic Parameters(charging case) Input parameter: 5V = 500mA Output parameter: 5V = 150mA Charging time: approx. 3hr Battery capacity: 600mAh Battery type: li-ion polymer Caveats Warning - Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product. - Do not expose the product to environments where the temperature is too low or too high (below 0°C or above 45°C). - Keep the indicators away from the eyes of children and animals while using the earphones. - Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks. - Do not wipe and clean the earphones or their case with alcohol or other volatile liquids. - Avoid any contact with liquids. Note - Please read this user manual carefully before using the product and please properly store it. - When using for the first time, please fully charge this product. - Please charge the product, in case it has not been used over two weeks.	- Please use certificated charger. - Do not wear earphones for a long term to protect your hearing. - Do not wear earphones in any situations with potential risks as wearing them may reduce your perception to the outside world. Daily maintenance Please do not shower with earbuds. Do not wear them in rainy day. Do not leave them in washing machine or other extreme situations. Clean them with dry cloth. Warranty Card Warranty Period 12 months after you purchase this item. (or you may inquire your local shopper for more details.) Free Service Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. <table border="1"> <tr> <td>Model Number</td> <td></td> </tr> <tr> <td>Date of Purchasing</td> <td></td> </tr> <tr> <td>User' s Name</td> <td></td> </tr> <tr> <td>User' s Phone</td> <td></td> </tr> <tr> <td>User' s Address</td> <td></td> </tr> <tr> <td>Shop' s Name</td> <td></td> </tr> <tr> <td>Shop' s Address</td> <td></td> </tr> <tr> <td>Comments</td> <td></td> </tr> </table> Free exchange service will not be accessed under following circumstances: 1. Damages caused by unauthorized disassembly.	Model Number		Date of Purchasing		User' s Name		User' s Phone		User' s Address		Shop' s Name		Shop' s Address		Comments		- Defects or physical damages caused by leaking or dropping off. - Damages by act of God. - Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing. Manufacturer: Dongguan Liesheng Electronic Co., Ltd. Address: Room 401-410, Building 1, No. 86 Hongtu Road, Nancheng District, Dongguan City, Guangdong, China
Model Number																			
Date of Purchasing																			
User' s Name																			
User' s Phone																			
User' s Address																			
Shop' s Name																			
Shop' s Address																			
Comments																			




Haylou X1

双降噪真无线蓝牙耳机


使用说明书




产品介绍



佩戴耳机



将耳机轻轻塞入耳道，调整耳机达到最佳佩戴状态。



通话时，将耳机麦克风1朝向嘴部可使通话更清晰。

小爱同学语音助手

小爱同学，是基于语音交互的人工智能助手。她可以帮你便捷地查询天气情况、问时间和日期，高效省心让效率飞速提升。还可以随时找小爱聊天，度过闲暇时光。连接蓝牙设备，还可以远程操控，是手机必备的个人助理。智能语音功能需配合小爱同学APP使用，扫描下方二维码立即下载小爱同学APP。

连接小爱同学

设备快速连接下载并打开小爱同学APP。
将耳机放入充电盒，关盖并靠近已解锁且开启蓝牙功能的手机，打开充电盒盖，按照手机界面提示操作连接耳机。



小爱同学手机客户端

设备手动连接

开启手机蓝牙。
下载并打开小爱同学APP，点击APP首页的头像，然后点击“蓝牙设备”进入“我的设备”页面，点击“+”添加设备，按照手机界面提示操作连接耳机。

提示：

小米手机、苹果手机及其他安卓手机均支持小爱同学APP连接配合使用。成功连接后，可通过小爱同学APP为耳机升级固件。

常用功能示例：

和小爱同学手机客户端连接后，只需三击左耳多功能键即可激活智能语音助手，协助你通过语音完成任务。



包装内容物

耳机，充电盒，耳帽x3对（中号已装入耳机中）
充电线，说明书。

耳机基本参数

通讯距离：10米（无障碍空旷环境）
电池容量：45mAh（单耳机）
充电时间：约2小时
通话时间：约4小时
待机时间：约60小时
输入参数：5V = 100mA
电池类型：可充式锂离子纽扣电池
无线连接：蓝牙5.2

充电盒基本参数

输入参数：5V = 500mA
输出参数：5V = 150mA
充电时间：约3小时
电池容量：600mAh
电池类型：锂离子聚合物


日常维护

请勿佩戴耳机洗澡，淋雨，放入洗衣机及在异常温度情况等极端环境使用，每次正常使用后，请用干布等工具擦干耳机上的汗水或者雨水，可以有效延长耳机的使用时长。



充电

- 1、首次开机使用，将充电盒及耳机充满电。
- 2、插入充电线可同时给耳机和充电盒充电。
- 3、**耳机充电**：放入充电盒充电，红色灯常亮，充满后白灯亮60s后熄灭。




充电盒电量指示灯说明

打开/关闭盖子，三个灯闪烁3次后，显示实际电量。电量大于30%，电量指示灯才会常亮10s后熄灭。
(再次看电量显示，需要先关盒子，后再开盒子看电量)
充电盒低电量提示：低于30%，LED每隔2s闪烁3次，持续循环一分钟后熄灭。

闪烁状态	电量百分比
	70%-100%
	30%-69%
	0-29%

开机

耳机在充电盒内，开盖耳机自动开机。
耳机在充电盒外且关机状态下，长按MFB键约1.5秒开机。



关机

放入充电盒中关盖，耳机自动关机。

连接配对

自动连接：开盖耳机自动开机，打开设备蓝牙搜索“Haylou X1”并点击完成连接。
如果连接失败，将耳机放回充电盒，重复上述操作。首次连接后，耳机开机可自动回连上一次配对设备（蓝牙需开启）。



单耳/双耳自由切换：两只耳机连接成功后即为双耳连接；将任一耳机放回充电盒内关上充电盒，耳机关机，另一只耳机进入单耳模式，重新取出即可自动恢复双耳模式。
手动连接：在耳机关机时，手动打开两只耳机，等待2-3秒耳机开机串联，待双耳机白灯慢闪时，打开设备蓝牙进行连接。

注意事项

警告

- 1、请勿以任何理由拆开、维修或改装耳机，否则可能会导致起火甚至彻底损坏本产品。
- 2、请勿将设备置于温度过低或过高（0℃以下或45℃以上）的环境下。
- 3、使用产品指示灯时，请避开儿童或动物的眼睛。
- 4、请勿在雷暴天气下使用本产品，雷暴可导致设备工作异常，并增加触电的危险。
- 5、请勿使用酒精或其他挥发性液体擦拭本产品。
- 6、请勿将本产品与液体接触。

注意

- 1、使用产品前请仔细阅读本产品使用说明书并请妥善保管。
- 2、首次使用时，请先将本产品充满电。
- 3、如果产品长期(超过2个星期)不用，请对其充电。
- 4、必须选择正规厂家生产且经过国家CCC认证的充电器。
- 5、长时间连续使用耳机有损听力，请合理控制使用时间及音量。
- 6、使用耳机会降低对外界声音的感知力，请不要在可能威胁到安全的环境中使用耳机。

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
耳机主体	○	○	○	○	○	○
电 池	○	○	○	○	○	○
耳 帽	○	○	○	○	○	○
充 电 盒	○	○	○	○	○	○
本表格依据SJ/T 11364的规定编制。 O：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。 X：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。						



Haylou蓝牙耳机售后服务

Haylou蓝牙耳机售后服务承诺:严格按照《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务，服务内容如下：在三包有效期内，您可凭购物凭证依照本规定享受免费的修理、更换、退货的权利。


- 1、自您购买之日起7日内，本产品出现故障，经由Haylou售后服务中心确定为产品质量问题，可享受修理、更换、退货的服务。
- 2、自您购买之日15日内，本产品出现故障，经由Haylou售后服务中心确定为产品质量问题，可享受修理或更换的服务。
- 3、自您购买之日起12个月内，本产品出现故障，经由Haylou售后服务中心确定为产品质量问题，可享受修理的服务。

三包凭证

产品型号			
用户信息	用户姓名	购买日期	
	联系电话	邮政编码	
	用户地址		
购买信息	销售单位		
	订单编号		



功能说明



- 单击MFB键
音乐时，播放/暂停
- 单击MFB键
来电时，接听电话
- 双击左耳MFB键
音乐时，切换上一曲
- 双击右耳MFB键
音乐时，切换下一曲
- 长按MFB键约4s
切换ANC模式
- 三击右耳MFB键
待机时，启动/关闭游戏模式
- 三击左耳MFB键
待机时，启动语音助手

耳机重置

如果耳机无法正常连接使用，请参照以下方式：
耳机在充电盒内且充电盒有电情况下，长按双耳机MFB按键10秒，此时耳机自动恢复出厂设置（包括清除两只耳机串联记录和与设备配对的记录）。
* 若操作不成功，请重复以上步骤；或登录官方旗舰店，联系客服，查看复位操作视频。

耳机一边有声一边无声

极端情况才会出现此类情况，发生后请参考耳机重置步骤，然后检查手机的蓝牙连接状况，清除蓝牙设备后重新连接即可。

充电时遇到的其他情况

- 1、耳机充满电后，白灯常亮1分钟后熄灭，此时耳机处于满电状态。
- 2、充电仓没电会导致耳机无法充电，关盖无法关机/断连，开盖无法开机。
- 3、充电盒充满电后，充电指示灯会熄灭，此时若再次接入充电线，充电指示灯则不会提示，不代表充电盒不能充电。

Hayou X1 性能故障表

名称	性能故障
蓝牙耳机	1. 使用过程中听不到声音。 2. 通话过程中，对方听不到声音。 3. 无法充电。

非保修条例

- 1、使用造成的正常磨损脏污如：刮痕、颜色改变；因接触化学试剂、接触尖锐物体、掉落挤压等人为导致损坏。
- 2、未经授权的维修、误用、碰撞、疏忽、滥用、进液、事故、改动、不正确的使用非本产品配件或撕毁、涂改标贴、防伪标记。
- 3、已超过三包有效期。
- 4、因不可抗力造成的损坏。
- 5、不符合《性能故障表》所列性能故障的情况。
- 6、因人为原因导致本产品及其配件产生《产品性能故障表》所列性能故障。

说明书中的产品、配件、用户界面等插图均为示意图，仅供参考。由于产品的更新和升级，产品实物与示意图可能略有差异，请以实物为准。

售后服务与支持

保修期：

自产品购买之日起12个月(请妥善保管购买凭证)

免费服务：

在产品保修期内，凡属产品本身质量引起的故障，请用户凭购买凭证与经销商取得联系以享受售后服务。

如有任何产品损害或瑕疵非可归责于产品质量本身，则不在保修范围内。有下列情形者不属于保修范围内：

- 1、因天灾、地震、雷击、异常电压、环境因素而发生之故障或毁损的。
- 2、自行或委托未经原厂授权维修之厂商拆卸、改装或更换非原厂零件。
- 3、未按使用手册操作或因人为使用不当而造成损坏者，如产品浸水、腐蚀、掉落、挤压或露在异常温湿度环境下。

若有售后服务需求,请联系Haylou客服

制造商：东莞市猎声电子科技有限公司
制造商地址：广东省东莞市南城街道宏图路86号1栋 401-410室
网 址：www.haylou.com
客服电话：4008-555-083





Haylou X1

ANC & ENC True Wireless Earbuds


User Manual




Overview



How to Wear




Please adjust earbud to fit yourself best.



When calling, adjust Mic 1 towards mouth to gain better talking experience.

How to Use



- Click MFB button
Play/Pause music
- Click MFB button
Answer incoming call
- Double click MFB button on L
Skip track backward
- Double click MFB button on R
Skip track forward
- Long press MFB button for about 4s
Switch ANC mode
- Triple click MFB button on R
Turn on/off game mode when standby
- Triple click MFB button on L
Summon voice assistant when standby

Factory Setting

If the earbuds cannot be connected and used normally, please refer to the following methods: When the earbuds are in the charging case and the charging case has power, long press MFB button for 10s, the earbuds will automatically be reset (the connection records between the two earbuds and device will be cleared).

* If the operation fails, please repeat the above steps; or log in to the official store, contact customer service to view the reset operation video.

Audio only Outputs from Single Earbud

It's unusual indeed, please set earbuds to factory, remove connectivity record on phone and re-connect.

Other Charging Problems

1. White LED turns off after 1 minute. It means your earbuds have been fully charged.
2. The earbuds won't be charged if the charging case is out of power. The earbuds can't power off/disconnect when closing lid and can't power on when opening lid.
3. LED does not turn on when charging the case. It means that the case has been fully charged so the light does not turn on.

Package List

Earbuds, charging case, 3 pairs of ear tips (M size has been pre-installed), charging cable, user manual.

Basic Parameters(earbuds)

Operation range: 10m (open space with no obstacle)

Battery capacity: 45mAh(single earbud)

Charging time: approx. 2hr

Talk time: approx. 4hr

Standby time: approx. 60hr

Input parameter: 5V = 100mA

Battery type: Rechargeable li-ion button battery

Bluetooth version: V5.2

Basic Parameters(charging case)

Input parameter: 5V = 500mA

Output parameter: 5V = 150mA


Charging time: approx. 3hr

Battery capacity: 600mAh

Battery type: li-ion polymer

How to Charge

1. Fully charge the charging case and earbuds before first use.
2. Insert the charging cable to simultaneously charge the earbuds and the charging case.
3. **Earbuds:** Put them back into the case, the earbuds indicator light is solid red. After fully charged, the indicator light is solid white for 60s and then goes out.



Battery Indicator of Charging Case

Open/close the lid, the actual battery level will be displayed after three lights flash 3 times. When the battery is greater than 30%, the battery indicator will be on for 10s and then go out.

(You need to close the case first then open to check battery level display again)

Low battery prompt of charging case:


less than 30%, LED flashes 3 times every 2s, and goes out after 1 minute of continuous circulation.

Flashing status	Battery percentage
✱ ✱ ✱	70%-100%
✱ ✱ ○	30%-69%
✱ ○ ○	0-29%

Power-on

When the earbuds are in the charging case, open lid to power on.

When the earbuds are outside the case and in power-off state, long press the MFB button for about 1.5s to power on.



Power-off

Put earbuds back into case and close the lid, they will automatically power off.

Caveats

Warning

1. Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product.
2. Do not expose the product to environments where the temperature is too low or too high (below 0°C or above 45°C).
3. Keep the indicators away from the eyes of children and animals while using the earphones.
4. Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks.
5. Do not wipe and clean the earphones or their case with alcohol or other volatile liquids.
6. Avoid any contact with liquids.

Note

1. Please read this user manual carefully before using the product and please properly store it.
2. When using for the first time, please fully charge this product.
3. Please charge the product, in case it has not been used over two weeks.

4. Please use certificated charger.
5. Do not wear earphones for a long term to protect your hearing.
6. Do not wear earphones in any situations with potential risks as wearing them may reduce your perception to the outside world.

Daily maintenance

Please do not shower with earbuds. Do not wear them in rainy day. Do not leave them in washing machine or other extreme situations. Clean them with dry cloth.

Warranty Card

Warranty Period

12 months after you purchase this item.
(or you may inquire your local shopper for more details.)

Free Service

Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.

Model Number	
Date of Purchasing	
User' s Name	
User' s Phone	
User' s Address	
Shop' s Name	
Shop' s Address	
Comments	


Free exchange service will not be accessed under following circumstances:

1. Damages caused by unauthorized disassembly.



How to Connect

Take out both earbuds from the case simultaneously. Open device Bluetooth, search for “Haylou X1” and click to connect. If connection fails, put earbuds back into case and try again. After connection, earbuds will automatically re-connect to the last-paired device whenever powering on (Bluetooth needs to be turned on).



Switch between mono and stereo mode:

Pick up two earbuds to auto enter stereo mode and push one back to enter mono mode. Or you can pick it up again to resume stereo mode.

Manual connection: When earbuds are turned off, manually turn on the two earbuds. Wait 2-3s for the earbuds to turn on and connect with each other. When indicator lights on both earbuds flash white slowly, turn on device Bluetooth to connect.

2. Defects or physical damages caused by leaking or dropping off.
3. Damages by act of God.
Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

Manufacturer: Dongguan Liesheng Electronic Co., Ltd.
Address: Room 401-410, Building 1, No. 86 Hongtu Road, Nancheng District, Dongguan City, Guangdong, China

